QuantaGrid Series



Compact 1U Server with full feature User's Guide

Version: 1.0

Copyright

Copyright © 2015 Quanta Computer Inc. This publication, including all photographs, illustrations and software, is protected under international copyright laws, with all rights reserved. Neither this guide, nor any of the material contained herein, may be reproduced without the express written consent of the manufacturer. All trademarks and logos are copyrights of their respective owners.

Version 1.0 / September 22, 2015

Disclaimer

The information in this document is subject to change without notice. The manufacturer makes no representations or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. Furthermore, the manufacturer reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of the manufacturer to notify any person of such revision or changes.

For the latest information and updates please see www.QCT.io

All the illustrations in this technical guide are for reference only and are subject to change without prior notice.

TABLE OF CONTENT

About the System

Introduction	1-1
Package Contents	1-3
A Tour of the System	
System Overview	1-4
System Front View	1-6
Front Control Panel (FCP)	1-6
System Rear View	1-7
System Rear I/O	1-8
Power Sub-System (Redundant PSU SKU)	1-8
Power Sub-System (Fixed PSU SKU)	1-9
LED Status Definitions	1-9
Front Control Panel LED	1-9
LAN LED	
BMC Management Port LED	
HDD LED	

BIOS

DS Setup Utility
Operation
Setup Page Layout 2-1
Entering BIOS Setup 2-1
Keyboard Commands 2-2
Menu Selection Bar 2-4
Server Platform Setup Utility Screens
Main Screen
Advanced Screen 2-6

Chipset Screen 2-7
Server Management Screen 2-8
Boot Options Screen 2-9
Security Screen
Exit Screen
Loading BIOS Defaults 2-14
BIOS Update Utility
BIOS Update Utility 2-15
AFULNX:
ME Region Update 2-15
BIOS Setting Utility 2-16
BIOS Revision 2-16
Clear CMOS 2-19
Clear Password
Server Management
Console Redirection 2-20
Serial Configuration Settings 2-20
Keystroke Mapping 2-20
Reset
Limitations
Interface to Server Management (Optional)
Network BIOS Support 2-22
PXE Boot
Checkpoints
Standard Checkpoint 2-22
ACPI/ASL Checkpoints
OEM-Reserved Checkpoint Ranges

BMC

Server Management Software	3-1
Server System Overview	3-1

BMC Key Features and Functions
Power System
Front Panel User Interface 3-2
Power Button 3-2
ID Button
LEDs
LAN Interface 3-2
Session and User 3-3
Serial Over LAN
Time Sync
SEL
Platform Event
Platform Event Filter 3-3
BMC Firmware Update 3-4
DOS Recovery Utility 3-4
WebUI Update 3-4
BMC Recovery
Recovery Process in DOS System
Recovery Process in Linux System
Recovery Process in Windows System
SMASH
System Level Commands
BMC Information
Web Graphical User Interface (GLII) for ESMS 3-12
Using the Web GUI
Login
Dashboard
Device Information
Network Information 3-15
Sensor Monitoring 3-15
Event Logs

Server Information 3-16
FRU Information 3-16
Server Component 3-18
Server identify 3-19
BIOS POST Code 3-20
Server Health Group 3-20
Sensor Readings 3-21
Event Log
Configuration Group 3-26
Active Directory 3-26
DNS 3-30
LDAP/E-Directory 3-34
Mouse Mode 3-37
Network
PEF
RADIUS
Remote Session 3-52
SMTP 3-53
SOL
SSL
User Management 3-62
Virtual Media 3-66
Services
LAN Port Settings 3-70
Remote Control 3-70
Console Redirection 3-71
Server Power Control
Java SOL
Maintenance Group 3-85
Preserve Configuration
Restore Factory Defaults 3-88
Firmware Update
BMC Firmware Update

BIOS Update	3-96
Log Out	3-96
User Privilege	3-96

Regulatory and Compliance Information

Electromagnetic Compatibility Notices 4-1
FCC Verification Statement (USA) 4-1
Europe (CE Declaration of Conformity)
VCCI (Japan) 4-1
BSMI (Taiwan)
Regulated Specified Components 4-2
Restriction of Hazardous Substances (RoHS) Compliance
End of Life / Product Recycling 4-2
Product Regulatory Compliance Markings 4-3

Conventions

Several different typographic conventions are used throughout this manual. Refer to the following examples for common usage.

Bold type face denotes menu items, buttons and application names.

Italic type face denotes references to other sections, and the names of the folders, menus, programs, and files.

<Enter> type face denotes keyboard keys.

.Warning information appears before the text it references and should not be ignored as the content may prevent damage to the device.



WARNING!

Warning information appears before the text it references and should not be ignored as the content may prevent damage to the device.



CAUTION!

CAUTIONS APPEAR BEFORE THE TEXT IT REFERENCES, SIMILAR TO NOTES AND WARNINGS. CAUTIONS, HOWEVER, APPEAR IN CAPITAL LETTERS AND CONTAIN VITAL HEALTH AND SAFETY INFORMATION.

Note:

Highlights general or useful information and tips.

Precautionary Measures

Read all caution and safety statements in this document before performing any of the instructions. To reduce the risk of bodily injury, electrical shock, fire, and equipment damage, read and observe all warnings and precautions in this chapter before installing or maintaining your system. To avoid personal injury or property damage, before you begin installing the product, read, observe, and adhere to all of the following instructions and information. The following symbols may be used throughout this guide and may be marked on the product and / or the product packaging.

Safety Instructions about your system

In the event of a conflict between the information in this guide and information provided with the product or on the website for a particular product, the product documentation takes precedence.

Your system should be integrated and serviced only by technically qualified persons.

You must adhere to the guidelines in this guide and the assembly instructions in related chapters to ensure and maintain compliance with existing product certifications and approvals. Use only the described, regulated components specified in this guide. Use of other products / components will void the UL Listing and other regulatory approvals of the product, and may result in noncompliance with product regulations in the region(s) in which the product is sold.

CAUTION	Indicates the presence of a hazard that may cause minor personal injury or property damage if the CAUTION is ignored.
WARNING	Indicates the presence of a hazard that may result in serious personal injury if the WARNING is ignored.
	Indicates potential hazard if indicated information is ignored.
	Indicates shock hazards that result in serious injury or death if safety instructions are not followed.
	Indicates hot components or surfaces.
	Indicates do not touch fan blades, may result in injury.
	Remove the system from the rack to disconnect power system.

Table 1: Warning and Cautions

Table 1: Warning and Cautions (Continued)

The enclosure is designed to carry only the weight of the system sled. Do not use this equipment as a workspace. Do not place additional load onto any equipment in this system.
Indicates two people are required to safely handle the system.
Restricted Access Location: The system is intended for installation only in a Server Room or Computer Room where both these conditions apply:
• access can only be gained by SERVICE PERSONS or by USERS who have been instructed about the reasons for the restrictions applied to the location and about any precautions that shall be taken; and
• access is through the use of a TOOL or lock and key, or other means of security, and is controlled by the authority responsible for the location.

Intended Application Uses

This product was evaluated as Information Technology Equipment (ITE), which may be installed in offices, schools, computer rooms, and similar commercial type locations. The suitability of this product for other product categories and environments (such as medical, industrial, residential, alarm systems, and test equipment), other than an ITE application, may require further evaluation.

Site Selection

The system is designed to operate in a typical office environment. Choose a site that is:

- Clean, dry, and free of airborne particles (other than normal room dust).
- Well-ventilated and away from sources of heat including direct sunlight and radiators.
- Away from sources of vibration or physical shock.
- Isolated from strong electromagnetic fields produced by electrical devices.
- In regions that are susceptible to electrical storms, we recommend you plug your system into a surge suppressor and disconnect telecommunication lines to your modem during an electrical storm.
- Provided with a properly grounded wall outlet.
- Provided with sufficient space to access the power system, because they serve as the product's main power disconnect.
- Provided with either two independent DC power system or two independent phases from a single power system.

Equipment Handling Practices

Reduce the risk of personal injury or equipment damage:

- Conform to local occupational health and safety requirements when moving and lifting equipment.
- Use mechanical assistance or other suitable assistance when moving and lifting equipment.
- To reduce the weight for easier handling, remove any easily detachable components.
- Never lift or move your system soley by the handle on the component.

Power and Electrical Warnings



CAUTION!

Make sure the system is removed from the rack before servicing any non-hot plug components. The bus bar clips must be disconnected from the power system inorder to fully separate the system from the power source.



CAUTION!

TO AVOID RISK OF ELECTRIC SHOCK, DISCONNECT ALL CABLING FROM THE SYSTEM AND REMOVE THE SYSTEM FROM THE RACK.

System Access Warnings



CAUTION!

TO AVOID PERSONAL INJURY OR PROPERTY DAMAGE, THE FOLLOWING SAFETY INSTRUCTIONS APPLY WHENEVER ACCESSING THE INSIDE OF THE PRODUCT:

- Disconnect from the power source by removing the system from the rack.
- Disconnect all cabling running into the system.
- Retain all screws or other fasteners when servicing. Upon completion servicing, sercure with original screws or fasteners.



CAUTION!

IF THE SERVER HAS BEEN RUNNING, ANY INSTALLED HDD MODULES MAY BE HOT.



CAUTION!

UNLESS YOU ARE ADDING OR REMOVING A HOT-PLUG COMPONENT, ALLOW THE SYSTEM TO COOL BEFORE SER-VICING.



CAUTION!

TO AVOID INJURY DO NOT CONTACT MOVING FAN BLADES. IF YOUR SYSTEM IS SUPPLIED WITH A GUARD OVER THE FAN, DO NOT OPERATE THE SYSTEM WITHOUT THE FAN GUARD IN PLACE.

Rack Mount Warnings

The following installation guidelines are required by UL for maintaining safety compliance when installing your system into a rack.

The equipment rack must be anchored to an unmovable support to prevent it from tipping when your system or piece of equipment is extended from it. The equipment rack must be installed according to the rack manufacturer's instructions.

Install equipment in the rack from the bottom up, with the heaviest equipment at the bottom of the rack.

Extend only one piece of equipment from the rack at a time.

You are responsible for installing a main power disconnect for the entire rack unit. This main disconnect must be readily accessible, and it must be labeled as controlling power to the entire unit, not just to the system(s).

To avoid risk of potential electric shock, a proper safety ground must be implemented for the rack and each piece of equipment installed in it.

Elevated Operating Ambient - If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (Tma) specified by the manufacturer.

Reduced Air Flow - Installation of the equipment in a rack should be such that the amount of air flow required for safe operation of the equipment is not compromised.

Mechanical Loading - Mounting of the equipment in the rack should be such that a hazardous condition is not achieved due to uneven mechanical loading.

Circuit Overloading - Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on over-current protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.

Reliable Earthing - Reliable earthing of rack-mounted equipment should be maintained.

Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g. use of power strips).

Electrostatic Discharge (ESD)



CAUTION!

ESD CAN DAMAGE DRIVES, BOARDS, AND OTHER PARTS. WE RECOMMEND THAT YOU PERFORM ALL PROCEDURES AT AN ESD WORKSTATION. IF ONE IS NOT AVAILABLE, PROVIDE SOME ESD PROTECTION BY WEARING AN ANTI-STATIC WRIST STRAP ATTACHED TO CHASSIS GROUND -- ANY UNPAINTED METAL SURFACE -- ON YOUR SERVER WHEN HANDLING PARTS.

Always handle boards carefully. They can be extremely sensitive to ESD. Hold boards only by their edges without any component and pin touching. After removing a board from its protective wrapper or from the system, place the board component side up on a grounded, static free surface. Use a conductive foam pad if available but not the board wrapper. Do not slide board over any surface.

Cooling and Airflow



CAUTION!

CAREFULLY ROUTE CABLES AS DIRECTED TO MINIMIZE AIRFLOW BLOCKAGE AND COOLING PROBLEMS. FOR PROPER COOLING AND AIRFLOW, OPERATE THE SYSTEM ONLY WITH THE CHASSIS COVERS* / AIR DUCT INSTALLED. OPERATING THE SYSTEM WITHOUT THE COVERS / AIR DUCT IN PLACE CAN DAMAGE SYSTEM PARTS . TO INSTALL THE COVERS* / AIR DUCT:

- Check first to make sure you have not left loose tools or parts inside the system.
- Check that cables, add-in cards, and other components are properly installed. Attach the covers* / air duct to the chassis according to the product instructions. * May not apply to all systems.

Please be aware that slots and openings on the front and rear side of the chassis are designed for ventilation; to make sure reliable operation of your system and to protect it from overheating, these openings must not be covered or blocked. The openings should never be covered or blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should never be placed near or over a radiator or heat register, or in a built-in installation unless proper ventilation is provided.

Laser Peripherals or Devices



CAUTION!

TO AVOID RISK OF RADIATION EXPOSURE AND / OR PERSONAL INJURY:

- Do not open the enclosure of any laser peripheral or device.
- Laser peripherals or devices are not serviceable.
- Return to manufacturer for servicing.

Use certified and rated Laser Class I for Optical Transceiver product.

Heed safety instructions: Before working with the system, whether using this manual or any other resource as a reference, pay close attention to the safety instructions. Adhere to the assembly instructions in this manual to ensure and maintain compliance with existing product certifications and approvals. Use only the described, regulated components spec-

ified in this manual. Use of other products / components will void the UL listing and other regulatory approvals of the product and will most likely result in non-compliance with product regulations in the region(s) in which the product is sold.

System power on/off: To remove power from system, you must remove the system from rack. Make sure the system is removed from the rack before opening the chassis, adding, or removing any non hot-plug components.

Hazardous conditions, devices and cables: Hazardous electrical conditions may be present on power, telephone, and communication cables. Turn off the system and disconnect the cables attached to the system before opening it. Otherwise, personal injury or equipment damage can result.

Electrostatic discharge (ESD) and ESD protection: ESD can damage drives, boards, and other parts. We recommend that you perform all procedures in this chapter only at an ESD workstation. If one is not available, provide some ESD protection by wearing an antistatic wrist strap attached to chassis ground any unpainted metal surface on the server when handling parts.

ESD and handling boards: Always handle boards carefully. They can be extremely sensitive to electrostatic discharge (ESD). Hold boards only by their edges. After removing a board from its protective wrapper or from the server, place the board component side up on a grounded, static free surface. Use a conductive foam pad if available but not the board wrapper. Do not slide board over any surface.

Installing or removing jumpers: A jumper is a small plastic encased conductor that slips over two jumper pins. Some jumpers have a small tab on top that can be gripped with fingertips or with a pair of fine needle nosed pliers. If the jumpers do not have such a tab, take care when using needle nosed pliers to remove or install a jumper; grip the narrow sides of the jumper with the pliers, never the wide sides. Gripping the wide sides can damage the contacts inside the jumper, causing intermittent problems with the function controlled by that jumper. Take care to grip with, but not squeeze, the pliers or other tool used to remove a jumper, or the pins on the board may bend or break.

General Information

The information about rack and the wording "rack" in this guide supports the organization of Open Compute definition.

The term *Rack* as found in this guide referes to the term *Rack* or *Open Rack* as described and used in the Open Compute Project definition.

Before servicing this system, it is recommened to read this technical guide completely to be aware of any safety issues or requirements involved in the servicing of this system.

Assembly Safety Guidelines

The power system in this product contains no user-serviceable parts. Refer servicing only to qualified personnel.
 The system is designed to operate in a typical office environment. Choose a site that is: Clean and free of airborne particles (other than normal room dust). Well ventilated and away from sources of heat including direct sunlight. Away from sources of vibration or physical shock. Isolated from strong electromagnetic fields produced by electrical devices. In regions that are susceptible to electrical storms, we recommend you plug your system into a surge suppressor and disconnect telecommunication lines to your modem during an electrical storm. Provided with a properly grounded wall outlet. Provided with sufficient space to access the power system, because they serve as the product's main power disconnect.
WARNING! The system is safety certified as rack-mounted equipment for use in a server room or computer room, using an approved customer rack. The enclosure is designed to carry only the weight of the system sled. Do not place additional load onto any equipment.
Heavy object. Indicates two people are required to safely handle the system.

Structure of this guide

• Chapter 1: About the System

"This section introduces the system, its different configuration(s) and the main features."

• Chapter 2: BIOS

"This section provides information regarding the BIOS architecture, BIOS update utility, server management, checkpoints, and error handling found in the system."

• Chapter 3: BMC

"This section provides information and key features of BMC (Baseboard Management Controller)."

• Chapter 4: Regulatory and Compliance Information

"This section provides regulatory and compliance information applicable to this system."

About the System

Chapter 1

This section introduces the system, its different configuration(s) and the main features.

1.1 Introduction

System Features

The QuantaGrid S31A-1U with four 3.5" HDD is available in two models, a fixed PSU model and a redundant PSU model. The compact 1U server is built on the Intel[®] C236 chipset, featuring the Intel[®] Xeon[®] processor E3-1200 v5.

The system is optimized for the dedicated hosting, front-end web, content delivery networks (CDN), and cloud computing applications..

• Greener and More Powerful

Powered by the Intel[®] Xeon[®] processor E3-1200 v5 product family and DDR4 memory technology, the QuantaGrid S31A-1U allows owners to upgrade computing performance without overextending power consumption. With Quanta's enhanced thermal design, the server can operate under ambient temperatures as high as 40°C. This allows owners to save unnecessary costs associated with datacenter cooling needs and achieve higher data center infrastructure efficiency (DCIE) value.

• Flexible and Scalable I/O options

QuantaGrid S31A-1U provides flexible I/O scalability for today's diverse data center application requirements. It features OCP LAN mezzanine card solutions in addition to dual GbE or 10GbE LAN on motherboards (LoM). The onboard SAS controller offers multiple QCT SAS mezzanine card options with different RAID levels and data transfer bandwidth so customers can tailor the SAS controller for specific application needs.

Specifications

Specifications	DESCRIPTION
Form factor	1U rack mount
Chassis dimensions	17.24 x 1.7 x 24 inches
(WXHXD)	438 x 43.2 x 609.6 mm
	Processor type:
	Intel [®] Xeon [®] processor E3-1200 v5 product family
Processor	Max. TDP support: 80W
	Number of processor: 1
	Last Level Cache (LLC): Up to 8 MB
Chipset	Intel [®] C236
	Total slots: 4
Memory	Capacity: Up to 64GB ECC UDIMM
	Memory type: 2133 MHz DDR4 ECC UDIMM
	Memory size: 16 GB, 8 GB, 4GB ECC UDIMM

Table 1.1: System Specifications

Table 1.1: System Specifications (Continued)

Specifications	DESCRIPTION	
Storage controller	 Onboard (Intel® C236): 2 mini-SAS HD connectors suppoting 8x SATA 6Gb/s ports 2x M.2 connector supporting SATA or PCIe SSD Optional controller: Please refer to our Compatible Component List for more information 	
Networking	LOM: • 2x Intel [®] I210 GbE port • Dedicated GbE management port Optional NIC: • Please refer to our Compatible Component List for more information	
Expansion slot	 Riser PCIe Expansion Card Riser: One x 8 PCIe 3.0, Low profile MD-2 QCT mezzanine Riser: One x8 PCIe 3.0, SAS mezzanine slot OCP mezzanine slot One x8 PCIe 3.0 slot 	
Storage	 4x 3.5" hot-plug SAS/SATA HDD/SSD 2x 2.5" internal SATA SSD 	
Onboard storage	2x M.2 SSD (SATA or PCle)	
Video	Integrated Aspeed AST2400 with 8MB DDR3 video memory	
Front I/O	 Power/ID/Reset Buttons LAN/HDD/Status/ID LEDs 2x USB 2.0 ports 	
Rear I/O	 2x USB 3.0 ports 1x VGA port 1x RS232 serial port 2x GbE RJ45 port 1x GbE RJ45 management port 1x ID button with LED 	
ТРМ	Yes (optional)	
Power supply	ly SKU1: 1+1 redundant hot-plug PSU, 80 Plus Platinum 3Y 700W 100-240Vac, 50-60Hz, 10-5A 3Y 400W 100-240Vac, 50-60Hz, 6-3A Acbel 700W 100-127/200-240Vac, 50/60Hz, 9.5/5A Acbel 400W 100-127/200-240Vac, 50/60Hz, 6/3A SKU2: 1x fixed PSU, 80 Plus Platinum	
Rating (per PSU inlet)	100-127/200-240Vac, 50/60Hz, 4/2A	
Fan	3x dual rotor fans (5+1 redundant)	
System management	IPMI v2.0 Compliant, on board "KVM over IP" support	
Operating environment	 Operating temperature: 5°C to 40°C (41°F to 104°F) Non-operating temperature: -40°C to 70°C (-40°F to 158°F) Operating relative humidity: 50% to 85%RH. Non-operating relative humidity: 20% to 90%RH 	

1.2 Package Contents

- (1) S31A-1U system
- (1) processor heat sink
- (1) power supply unit
- (1) power cord (optional)
- (1) utility CD (This Guide included)
- (1) rail kit

Note:

Note: For exact shipping contents, contact your sales representative.

1.3 A Tour of the System

System Overview

The server is available as a redundant PSU (SKU1) and fixed PSU (SKU2) configuration.

The redundant PSU SKU configuration system overview is displayed in the following image:



Figure 1-1. Redundant PSU System (SKU1) Component Overview



The fixed PSU configuration system overview is displayed in the following image:



	Tal	ble	2:	Com	poner	יס th	vervi	iew
--	-----	-----	----	-----	-------	-------	-------	-----

No.	Ітем	DESCRIPTION	
1	Fan module	(3) System fan modules	
2	CPU socket	LGA 1151 socket	
3	OCP mezz slot	Support OCP mezzanine card, PCIe x8, Gen 3.0	
4	Riser assembly	 Support PCle expansion card, PCle x 8, Gen 3.0 Support QCT SAS mezzanine card, PCle x 8, Gen 3.0 	
5	DIMM slots	(4) DDR4 DIMM slots	
6	PSU assembly	SKU1: Redundant power supply unit assemblySKU2: Fixed power supply unit assembly	
7	Mainboard	System mainboard	
8	Backup battery	Backup battery for SAS mezzanine card	
9	Front control panel	See Front Control Panel (FCP) on page 1-6	
10	HDD assembly	4 x 3.5" SAS/SATA hard disk drive assemblies	
11	SSD assembly	2 x solid state disk drive assemblies.	

System Front View



Figure 1-3. System Front View

Table 3: Front Panel View

No.	Name	DESCRIPTION	
1	Front control panel	See Front Control Panel LED on page 1-9 for further information.	
2	2 HDD bays 4 x 3.5" SAS/SATA HDD		
3	SSD tray	2 x SSD	

Front Control Panel (FCP)

For purposes of this procedure, the FCP is used for the numbering indicators.



Figure 1-4. Front Control Panel

Table 4: Front Control Panel Definition

No.	ICON	ΝΑΜΕ	DESCRIPTION
1	¢,	USB ports	USB ports 1 & 2
2		Reset button	Soft reset system function
3	망	LAN2 LED	LAN access
4	융	LAN1 LED	LAN access
5	0	HDD activity LED	Hard disk drive access
6	Â	Fault LED	Provides critical and non-critical failure notification

Table 4: Front Control Panel Definition (Continued)

No.	ICON	NAME	DESCRIPTION
7		Identification LED	Activate ID LED to identify system
8		ID button	Toggles ID LED
9	Ċ	Power button	Power on / off

System Rear View



Figure 1-5. System Rear View

No.	Feature	DESCRIPTION	
1	Power sub-systemUpper: Redundant power supply unit. Bottom: Fixed power supply unit. See Power Sub-System (Redundant PSU SKU) on page 1-8.		
2	System I/O ports	See System Rear I/O on page 1-8	
3	Expansion slot	PCIe expansion slot with PCIe x8 signal	
4	OCP mezzanine slot	Support OCP mezzanine card with PCIe x 8 signal	

System Rear I/O



Figure 1-6. System Rear I/O

Table 6: System	n Rear I/O Defintition
-----------------	------------------------

No.	ICON	Name	DESCRIPTION
1	i	ID button with LED	Toggle the identification when pressing
2	10101	COM port	DB9 port for debug or terminal concentrator
3		VGA connector	Maximum display resolution: 1920x1200 32bpp@60Hz (reduced blanking)
4	SS<↔	USB ports	USB 3.0 ports
5	2/2	Dedicated NIC	Dedicated RJ45 connector
6	중공	LAN2	RJ45 connector featuring share NIC
7	중	LAN1	RJ45 connector

Power Sub-System (Redundant PSU SKU)



Figure 1-7. Redundant PSU to Mainboard Module Description

A single power supply unit (default) and power distribution board (PDB) are supplied in the system. A secondary PSU is available for redundacy functionality.

Table 7: Power Supply Units by Model

PSU	AC INPUT	
2 x 400W high efficiency redundant PSU	100-240V AC 50/60Hz	

Power Sub-System (Fixed PSU SKU)





A fixed power supply unit is supplied in the system.

Table 8: Power Supply Units by Model

PSU	AC INPUT
1 x 400W high efficiency PSU	100-240V AC 50/60Hz

LED Status Definitions

Front Control Panel LED

For further information and location of the FCP LEDs, see *Front Control Panel LED* on page 1-9.

	940
Ø:	

Figure 1-9. Sys	em Front Control Panel LEDs
-----------------	-----------------------------

Table 9: Front Control Panel LED Behavior

ΝΑΜΕ	COLOR	CONDITION	DESCRIPTION
PowerLED	Blue	On	System power on
	Diac	Off	System power off
Identification	Blue Blinking Off	Blinking	Unit selected for identification
lacitimention		Off	No identification request

Table 9: Front Control Panel LED Behavior (Continued)

ΝΑΜΕ	Color	CONDITION	DESCRIPTION	
	Amber	Blinking	Critical Failure: critical fan, voltage, temperature state.	
Fault LED			Non-Critical Failure: non-critical fan, voltage, temperature state, CPU thermal trip, DC off.	
		Off	SEL cleared	
			Last pending warning or error has been de-asserted.	
HDD activity Blu	Blue	Blinking	Hard disk drive access (only on board SATA port)	
		Off	No access (non-SAS)	
	Blue	On	Link	
	Dide	Blinking		LAN access (off when there is traffic)
	Blue	On	Link	
		Blinking	LAN access (off when there is traffic)	

LAN LED

The system mainboard includes dual GbE network with GbE dedicated management port. Each RJ45 connector has two built-in LEDs. See the following illustration and table for details.



Figure 1-10. RJ45 LAN Connector

Table 10: RJ45 LED Description

Condition	Link	Αςτινιτγ
Unplugged	Off	Off
1G active link	On amber	Blinking green
100M active link	On green	Blinking green
10M active link	Off	Blinking green

BMC Management Port LED

The system mainboard includes GbE dedicated management port. The RJ45 connector has two built-in LEDs. See the following illustration and table for details.



Figure 1-11. RJ45 LAN Connector

Table 11: RJ45 LED Description

Condition	Link	Αςτινιτγ
Unplugged	Off	Off
1G active link	On amber	Blinking green
100M active link	On green	Blinking green
10M active link	Off	Blinking green

HDD LED

The following LED behavior table represents LED conditions when a driver is online and the slot is not empty.

Table 12: HDD LED Status Behavior

ICON	Name	Color	CONDITION	DESCRIPTION
	HDD Present	Blue	On	Drive is online
-9-	HDD Fault	Amber	On	HDD failure
0	HDD Access Blue	Blue	Blinking	HDD access is active
		Off	No access	

* Only support SATA/SAS HDD/SSD.

BIOS

Chapter 2

This section provides information regarding the BIOS architecture, BIOS update utility, server management, checkpoints, and error handling found in the system.

2.1 BIOS Setup Utility

The BIOS Setup utility is provided to perform system configuration changes and to display current settings and environment information.

The BIOS Setup utility stores configuration settings in system non-volatile storage. Changes affected by BIOS Setup will not take effect until the system is rebooted. The BIOS Setup Utility can be accessed during POST by using the **** or **<F2>** key.

The following sections describe the look and behavior for platform Setup.

Operation

BIOS Setup has the following features:

- The server board BIOS will only be available in English.
- BIOS Setup is functional via console redirection over various terminal emulation standards. This may limit some functionality for compatibility, e.g., usage of colors, some keys or key sequences, or support of pointing devices.

Setup Page Layout

The setup page layout is sectioned into functional areas. Each occupies a specific area of the screen and has dedicated functionality. The following table lists and describes each functional area.

FUNCTIONAL AREA	DESCRIPTION
Title Bar	The title bar is located at the top of the screen and displays the title of the form (page) the user is currently viewing. It may also display navigational information.
Setup Item List	The Setup Item List is a set of controllable and informational items. Each item in the list occupies the left column of the screen. A Setup Item may also open a new window with more options for that functional- ity on the board.
Item Specific Help Area	The Item Specific Help area is located on the right side of the screen and contains help text for the highlighted Setup Item. Help information may include the mean- ing and usage of the item, allowable values, effects of the options, etc.
Keyboard Com- mand Bar	The Keyboard Command Bar is located at the bottom right of the screen and con- tinuously displays help for keyboard special keys and navigation keys.

Table 1: BIOS Setup Page Layout

Entering BIOS Setup

BIOS Setup is started by pressing <**DEL**> or <**F2**> during boot time when the OEM (Quanta) logo is displayed.

When Quiet Boot is disabled, the message "press <**DEL**> or <**F2**> to enter setup" will be displayed on the diagnostics screen.

Keyboard Commands

The bottom right portion of the Setup screen provides a list of commands that are used to navigate through the Setup utility. These commands are displayed at all times.

Each Setup menu page contains a number of features. Except those used for informative purposes, each feature is associated with a value field. This field contains user-selectable parameters. Depending on the security option chosen and in effect by the password, a menu feature's value may or may not be changeable. If a value is non-changeable, the feature's value field is inaccessible and displays as "grayed out."

Key	Option	DESCRIPTION
<enter></enter>	Execute Command	The < Enter > key is used to activate sub-menus when the selected feature is a sub-menu, or to display a pick list if a selected option has a value field, or to select a sub-field for multi-valued features like time and date. If a pick list is displayed, the < Enter > key will select the currently highlighted item, undo the pick list, and return the focus to the parent menu.
<esc></esc>	Exit	The <esc< b="">> key provides a mechanism for backing out of any field. When the <esc< b="">> key is pressed while editing any field or selecting features of a menu, the parent menu is re-entered. When the <esc< b="">> key is pressed in any sub-menu, the parent menu is re-entered. When the <esc< b="">> key is pressed in any major menu, the exit confirmation window is displayed and the user is asked whether changes can be discarded. If "No" is selected and the <enter< b="">> key is pressed, or if the <esc< b="">> key is pressed, the screen is returned to the one before pressing the <esc< b="">> key, without affecting any existing any settings. If "Yes" is selected and the <enter< b="">> key is pressed, setup is exited and the BIOS returns to the main System Options Menu screen.</enter<></esc<></esc<></enter<></esc<></esc<></esc<></esc<>
Ţ	Select Item	The up arrow is used to select the previous value in a pick list, or the previous option in a menu item's option list. The selected item must then be activated by pressing the <enter></enter> key.
↓	Select Item	The down arrow is used to select the next value in a menu item's option list, or a value field's pick list. The selected item must then be activated by pressing the < Enter > key.
$\leftarrow \rightarrow$	Select Menu	The left and right arrow keys are used to move between the major menu pages. The keys have no affect if a sub-menu or pick list is dis- played.
<tab></tab>	Select Field	The < Tab > key is used to move between fields. For example, < Tab > can be used to move from hours to minutes in the time item in the main menu.

Table 2: Keyboard Commands

Table 2: Key	yboard Comm	ands (Continued)
--------------	-------------	------------------

Key	Option	DESCRIPTION		
-	Change Value	The minus key on the keypad is used to change the value of the cur- rent item to the previous value. This key scrolls through the values in the associated pick list without displaying the full list.		
+	Change Value	The plus key on the keypad is used to change the value of the current menu item to the next value. This key scrolls through the values in the associated pick list without displaying the full list. On 106-key Japanese keyboards, the plus key has a different scan code than the plus key on the other keyboard, but will have the same effect.		
k	Scroll Bar	The k key is used to scroll up in the item specific help area. The scroll bar keys have no affect if help string was not longer than the maximum allocated space in item specific help area.		
m	Scroll Bar	The m key is used to scroll down in the item specific help area. The scroll bar keys have no affect if help string was not longer than the maximum allocated space in item specific help area.		
< F8 >	Previous Values	Pressing < F8 > causes the following to appear: Load Optimized Defaults? Yes No If Yes is highlighted and < Enter > is pressed, all Setup fields are set to their previous values. If No is highlighted and < Enter > is pressed, or if the < Esc > key is pressed, the screen is returned to the one before < F8 > was pressed without affecting any existing field values		
<f9></f9>	Setup Defaults	Pressing < F9 > causes the following to appear: Load Optimized Defaults? Yes No If Yes is highlighted and < Enter > is pressed, all Setup fields are set to their default values. If No is highlighted and < Enter > is pressed, or if the < Esc > key is pressed, the screen is returned to the one before < F9 > was pressed without affecting any existing field values		
<f10></f10>	Save and Exit	Pressing <f10> causes the following message to appear: Save configuration and exit? Yes No If Yes is highlighted and <enter> is pressed, all changes are saved and Setup is exited. If No is highlighted and <enter> is pressed, all changes are saved the <esc> key is pressed, the screen is returned to the one before <f10> was pressed without affecting any existing values.</f10></esc></enter></enter></f10>		

Menu Selection Bar

The Menu Selection Bar is located at the top of the BIOS Setup Utility screen. It displays the major menu selections available to the user. By using the left and right arrow keys, the user can select the menus listed here.

Server Platform Setup Utility Screens

The sections below describe the screens available for the configuration of a server platform. In these sections, tables are used to describe the contents of each screen. These tables follow the following guidelines:

- The text and values in the Setup Item, Options, and Help columns in the tables are displayed on the BIOS Setup screens.
- **Bold text** in the Options column of the tables indicates default values. These values are not displayed in bold on the setup screen. The bold text in this document is to serve as a reference point.
- The Comments column provides additional information where it may be helpful. This information does not appear in the BIOS Setup screens.
- Information in the screen shots that is enclosed in brackets (< >) indicates text that varies, depending on the option(s) installed. For example <Current Date> is replaced by the actual current date.
- Information that is enclosed in square brackets ([]) in the tables indicates areas where the user needs to type in text instead of selecting from a provided option.
- Whenever information is changed (except Date and Time) the systems requires a save and reboot to take place. Pressing <**ESC**> will discard the changes and boot the system according to the boot order set from the last boot.

Main Screen

Aptio Setup Util: Main Advanced Chipset	ity - Copyright (C) 2015 American M Server Mgmt Boot SecuritySave	egatrends, Inc. & Exit
BIOS Information BIOS Vendor Core Version BIOS Compliancy Project Version Build Date and Time Memory Information Total Memory Access Level	American Megatrends 5.010 UEFI 2.4; PI 1.3 S3A_1A01 01/07/2015 17:42:01 32768 MB Administrator	Set the Date, Use Tab to switch between data elements.
System Date System Time	[Fri 01/09/2015] [09:21:44]	<pre>→ ←: Select Screen ↑↓ : Select Item Enter: Select +/-: Change Opt. F1: General Help F8: Previous Values F9: Optimized Defaults F10: Save & Reset ESC: Exit</pre>

Figure 2-1. Main Screen

Table 3: Main Screen Description

SETUP ITEM	Options	HELP TEXT	Comments
BIOS Vendor			Information only. Displays the BIOS Vendor.
Core Version			Information only. Displays the AMI BIOS Core version.
Compliancy			Information only. Displays the BIOS compliancy.
Project Version			Information only. Displays the Project version.
Build Date and Time			Information only. Displays the BIOS build date.
Total Memory			Information only. Displays the Total System Memory Size.
Access Level			Information only. Displays the Total System Memory Size.
System Date	[Day of week MM/DD/YYYY]	Set the Date. Use Tab to switch between Date elements.	Valid range of year : 1998~2099.
System Time	[HH:MM:SS]	Set the Time. Use Tab to switch between Time elements.	

Advanced Screen

The Advanced screen provides an access point to configure several options. On this screen, the user selects the option that is to be configured. Configurations are performed on the selected screen, not directly on the Advanced screen.

To access this screen from the Main screen, press the right arrow until the Advanced screen is chosen.

Aptio Setup Utility - Copyright (C) 2015 American Mega Main <mark>Advanced</mark> Chipset Server Mgmt Boot SecuritySave & B	atrends, Inc. Exit
 Trusted Computing Runtime Error Logging Super IO Configuration Serial Port Console Redirection CPU Configuration SATA Configuration CSM Configuration USB Configuration WHEA Configuration Onboard Device Configuration iSCSI Configuration 	frusted Computing Settings
	<pre>→ ←: Select Screen ↑↓ : Select Item Enter: Select +/-: Change Opt. F1: General Help F8: Previous Values F9: Optimized Defaults F10: Save & Reset ESC: Exit</pre>

Figure 2-2. Advanced Screen

Table 4: Advanced Screen Description

Setup Item	Options	HELP TEXT	Comments
Trusted Computing		Trusted Computing Settings	
Runtime Error Logging		Runtime Erro Logging Support Setup Options	
Super IO Configuration		System Super IO Chip Parameters.	
Serial Port Console Redirection		Serial Port Console Redirection	
CPU Configuration		CPU Configuration Parameters	
SATA Configuration		SATA Device Opton Settings	
CSM Configuration		CSM configuration: Enable/Disable, Option ROM execution settings, etc.	
USB Configuration		USB Configuration Parameters	
WHEA Configuration		General WHEA Configuration Settings	

Table 4: Advanced Screen	Description (Continued)
--------------------------	-------------------------

Setup Item	Options	HELP TEXT	Comments
Onboard Device Configuration		Onboard Device Parameters	
iSCSI Configuration		Configure the iSCSI Parameters	Dynamic

Chipset Screen

The Chiptset screen provides an access point to configure several options. On this screen, the user selects the option that is to be configured. Configurations are performed on the selected screen, not directly on the Chipset screen.

To access this screen from the Main screen, press the right arrow until the Chipset screen is chosen.

Aptio Setup Utility - Copyright (C) 2015 American Mega Main Advanced Chipset Server Mgmt Boot SecuritySave & H	atrends, Inc. Exit
<pre>Pwr/Perf Profiles [Custom] > Intel Server Platform Services > System Agent (SA) Configuration > PCH-IO Configuration</pre>	Configure your own power and performance settings under Custom or adopt quick setting profiles.
	<pre>→ ←: Select Screen ↑↓ : Select Item Enter: Select +/-: Change Opt. F1: General Help F8: Previous Values F9: Optimized Defaults F10: Save & Reset ESC: Exit</pre>

Figure 2-3. Chipset Screen

Table 5: Chipset Scr	reen Description
----------------------	------------------

Setup Item	Options	Help Text	COMMENTS
Pwr/Perf Profiles	[Custom] [Energy-Saving Mode] [Balanced Mode] [Virtualization Mode] [HPC Mode]	Configure your own power and performance settings under Custom or adopt quick setting profiles.	
Intel Server Platform Services		Intel Server Platform Services Parameters	
SETUP ITEM	Options	Help Text	COMMENTS
---------------------------------	---------	------------------------------	----------
System Agent (SA) Configuration		System Agent (SA) Parameters	
PCH-IO Configuration		PCH Parameters	

Table 5: Chipset Screen Description (Continued)

Server Management Screen

The Server Management screen displays information of the BMC, and allows the user to configure desired settings.

To access this screen from the Main screen, select Server Mgmt Options.

Aptio Setup Utility - Copyright (C) 2015 American Megatrends, Inc.			
Main Advanced Chipset Server	Mgmt Boot Security	Save & Exit	
BMC Self Test Status	PASSED	Enable or Disable FRB2	
BMC firmware version	00.01.00	timer(POST timer)	
IPMI version	2.0		
FRB-2 TImer			
FRB-2 Timer timeout	[6 minutes]		
FRB-2 Timer Policy	[Reset]		
OS Watchdog Timer	[Disabled]		
OS Wtd Timer Timeout	[10 minutes]		
OS Wtd Timer Policy	[Reset]		
System Event Log			
View FRU information			
BMC network configuration		\rightarrow \leftarrow : Select Screen	
Restore on AC Power Loss	[No Change]	↑↓ : Select Item	
Current Restore on AC Power Loss	Power Off	Enter: Select	
		+/-: Change Opt.	
		F1: General Help	
		F8: Previous Values	
		F10. Save & Reset	
		ESC: Exit	
		LOOT LALO	

Figure 2-4. Server Management Screen

Table 6: Server Management Screen Description

SETUP ITEM	Options	Help Text	Comments
BMC Self Test Status			Information only. Displays the BMC Self Test Status.
BMC firmware version			Information only. Displays the BMC firmware version.
IPMI version			Information only. Displays the IPMI version.
FRB-2 Timer	[Enabled] [Disabled]	Enable or Disable FRB2 timer (POST timer)	

Table 6: Server Management Screen De	escription (Continued)
--------------------------------------	------------------------

SETUP ITEM	Options	Help Text	Comments
FRB-2 Timer timeout	[3 minutes] [4 minutes] [5 minutes] [6 minutes]	Enter value Between 3 to 6 min for FRB-2 Timer Expiration value	Not available if FRB2 Timer is dis- abled.
FRB-2 Timer Pol- icy	[Do Nothing] [Reset] [Power Down]	Configure how the system should respond if the FRB2 Timer expires. Not available if FRB2 Timer is disabled.	Not available if FRB2 Timer is dis- abled.
OS Watchdog Timer	[Enabled] [Disabled]	If enabled, starts a BIOS timer which can only be shut off by Intel Management Software after the OS loads. Helps determine that the OS successfully loaded or follows the O/S Boot Watch- dog Timer policy.	
OS Wtd Timer Timeout	[5 minutes] [10 minutes] [15 minutes] [20 minutes]	Configure the length of the OS Boot Watchdog Timer. Not avail- able if OS Boot Watchdog Timer is disabled.	
OS Wtd Timer Policy	[Do Nothing] [Reset] [Power Down]	Configure how the system should respond if the O/S Boot Watchdog Timer expires. Not available if O/S Boot Watchdog Timer is disabled.	
System Event Log		Press < Enter > to change the SEL event log configuration.	
View FRU infor- mation		Press < Enter > to view FRU infor- mation.	
BMC network configuration		Configure BMC network parame- ters	
Restore on AC Power Loss	[Power Off] [Power On] [Last State] [No Change]	System action to take on AC power loss	
Current Restore on AC Power Loss			Current system action to take on AC power loss.

Boot Options Screen

The Boot Options screen displays any bootable media encountered during POST, and allows the user to configure desired boot device.

If no boot devices are available – for example, both onboard LAN are disabled and no bootable device connected when Boot Mode is set to Legacy – the system will auto boot into BIOS setup menu.

Aptio Setup Utility - Copyright (C) 2015 American Megatrends, Inc. Main Advanced Chipset Server Mgmt Boot SecuritySave & Exit Boot Configuration Number of seconds to wait for setup 5 activation key. Default Bootup NumLock State [On] is 5 seconds, max is 10 POST Error Pause [Disabled] and min is 1. Quiet Boot [Enabled] Boot mode select [UEFI] FIXED BOOT ORDER Priorities Boot Option #1 [USB] Boot Option #2 [Network] Boot Option #3 [Hard Disk] Boot Option #4 [CD/DVD] UEFI Hard Drive BBS Priorities UEFI Network Device BBS Priorities \rightarrow \leftarrow : Select Screen UEFI CD/DVD ROM Drive BBS Priorities $\uparrow\downarrow$: Select Item UEFI Floppy Drive BBS Priorities Enter: Select +/-: Change Opt. F1: General Help F8: Previous Values F9: Optimized Defaults F10: Save & Reset ESC: Exit

To access this screen from the Main screen, select Boot Options.

Figure 2-5. Boot Options Screen

Table 7: Boot	Options Screen	Description
	options server	Description

SETUP ITEM	Options	Help Text	Comments
Setup Prompt Timeout	[<number>}</number>	Number of seconds to wait for setup activation key. Default is 5 seconds, max is 10 and min is 1.	
Bootup Num- Lock State	[On] [Off]	Select the keyboard NumLock state	
POST Error Pause	[Disabled] [Enabled]	Enables or disables POST Error Pause	
Quiet Boot	[Disabled] [Enabled]	Enables or disables Quiet Boot option	
Boot mode select	[LEGACY] [UEFI]	Select boot mode LEGACY/ UEFI	This item decides what devices (Legacy or UEFI) BIOS should try to boot when let the system auto boot up without manually select boot device.

Table 7: Boot Options Screen Description (Continued

SETUP ITEM	Options	HELP TEXT	Comments
Boot Option #1	[<device 1="" string="">] [<device 2="" string="">] [Disabled]</device></device>	Sets the system boot order	
Boot Option #2	[<device 1="" string="">] [<device 2="" string="">] [Disabled]</device></device>	Sets the system boot order	
Boot Option #3	[<device 1="" string="">] [<device 2="" string="">] [Disabled]</device></device>	Sets the system boot order	
Boot Option #4	[<device 1="" string="">] [<device 2="" string="">] [Disabled]</device></device>	Sets the system boot order	
Hard Drive BBS Priorities		Set the order of the legacy devices in this group	Only appears when at least one Hard Disk is detected.
Network Device BBS Priorities		Set the order of the legacy devices in this group	
CD/DVD ROM Drive BBS Priori- ties		Set the order of the legacy devices in this group	Only appears when at least one CD/DVD Drive is detected.
Floppy Drive BBS Priorities		Set the order of the legacy devices in this group	

Security Screen

The Security screen provides fields to enable and set the user and administrative password and to lockout the front panel buttons so they cannot be used.

Aptio Setup Utility - Copyright (C) 2015 American Megatrends, Inc. Server Mgmt Boot Security Save & Exit Set Administrator Password Password Description If ONLY the Administrator's password is set, then this only limits access to Setup and is only asked for when entering Setup. If BOTH the Administrator's password and the User's password are set, then the password is prompted during POST. If the Administrator's /User's password is entered, Administrator/User privilege is granted in the Setup Menu. The password must be in the following range: 3 Minimum length Maximum length 20 \rightarrow \leftarrow : Select Screen ↑↓ : Select Item Enter: Select +/-: Change Opt. User Password F1: General Help F8: Previous Values F9: Optimized Defaults Secure Boot menu F10: Save & Reset ESC: Exit

To access this screen from the Main screen, select the Security option.

Figure 2-6. Security Screen

Table 8: BIOS Screen Description

Setup Item	Options	Help Text	Comments
Administrator Password		Set Administrator Password	
User Password		Set User Password	
Secure Boot menu		Customizable Secure Boot settings	

Exit Screen

The Exit screen allows the user to choose to save or discard the configuration changes made on the other screens. It also provides a method to restore the server to the factory defaults or to save or restore a set of user defined default values. If Restore Defaults is selected, the default settings, noted in bold in the tables in this chapter, will be applied. If

Restore User Default Values is selected, the system is restored to the default values that the user saved earlier, instead of being restored to the factory defaults.

	Exit system setup withou
Save Changes and Reset	saving any changes.
Discard Changes	
Restore Defaults	
Save as User Defaults	
Restore User Defaults	
Boot Override	
UEFI: NIC1 IP4 Intel(R) I350 Gigabit Network Connection	
UEFI: NIC1 IP6 Intel(R) I350 Gigabit Network Connection	
UEFI: NIC2 IP4 Intel(R) I350 Gigabit Network Connection	
UEFI: NIC2 IP6 Intel(R) I350 Gigabit Network Connection	\rightarrow \leftarrow : Select Screen
UEFI: Built-in EFI Shell	↑↓ : Select Item
IBA GE Slot 0500 v1381	Enter: Select
IBA GE Slot 0501 v1381	+/-: Change Opt.
P1 FUJITSU MHZ2250BK G3	F1: General Help
	F8: Previous Values
	F9: Optimized Defaults
	F10: Save & Reset
	ESC: Exit

Figure 2-7. Exit Screen

Table 9: Exit Screen Description

SETUP ITEM	Options	Help Text	Comments
Discard Changes and Exit		Exit system setup without saving any changes.	
Save Changes and Reset		Reset the system after saving the changes.	
Discard Changes		Discards changes done so far to any of the setup options.	
Restore Defaults		Restore/Load Default values for all the setup options.	
Save as User Defaults		Save the changes done so far as User Defaults.	
Restore User Defaults		Restore the User Defaults to all the setup options.	
[<device string<br="">1>]</device>			Boot with Device <device string<br="">1></device>
[<device string<br="">2>]</device>			Boot with Device <device 2="" string=""></device>
[<device string<br="">3>]</device>			Boot with Device <device string<br="">3></device>
[<device string<br="">4>]</device>			Boot with Device <device string<br="">4></device>
[<device string<br="">5>]</device>			Boot with Device <device 5="" string=""></device>

Table 9: Exit Screen Description (Continued)

SETUP ITEM	Options	Help Text	Comments
[<device string<br="">6>]</device>			Boot with Device <device string<br="">6></device>

Loading BIOS Defaults

Different mechanisms exist for resetting the system configuration to the default values. When a request to reset the system configuration is detected, the BIOS loads the default system configuration values during the next POST. The request to reset the system to the defaults can be sent in the following ways:

- Pressing <**F9**> from within the BIOS Setup utility
- Load BIOS defaults by jumper as follows:
- 1. Power down the system.
- 2. Move CMOS clear jumper from pins 2-3 to pins 1-2 for a few seconds.
- 3. Move CMOS clear jumper back to pins 2-3.
- 4. System automatically powers on.
- 5. Check BIOS defaults are loaded.

2.2 BIOS Update Utility

The flash ROM contains system initialization routines, the BIOS Setup Utility, and runtime support routines. The exact layout is subject to change, as determined by BIOS. The flash ROM also contains initialization code in compressed form for onboard peripherals, like SCSI, NIC and video controllers. The complete ROM is visible, starting at physical address 4 GB minus the size of the flash ROM device.

A 16-KB parameter block in the flash ROM is dedicated to storing configuration data that controls the system configuration (ESCD). Application software must use standard APIs to access these areas; application software cannot access the data directly.

BIOS Update Utility

Server platforms support DOS-based, Windows-based, and Linux-based firmware update utilities. It is very important to follow the rule, and use official provided package to update BIOS under DOS/Linux/ EFI shell environment. Using incorrect flash option to flash BIOS may cause damage to your system. This utility loads a fresh copy of the BIOS into the flash ROM.

The BIOS update may affect the following items:

- The system BIOS, including the setup utility and strings.
- Onboard video BIOS, RAID BIOS, and other option ROMS for the devices embedded on the server board.
- Memory reference code.
- Microcode updates.

AFULNX:

- 1. Please refer to the README.txt that each official release BIOS attached.
- 2. Reboot system then new BIOS runs.

ME Region Update

Update utility also provide ME region update function, please refer to the README.txt that each official release BIOS attached.

The BIOS update may affect the following items:

- The system BIOS, including the setup utility and strings.
- Onboard video BIOS, RAID BIOS, and other option ROMS for the devices embedded on the server board.
- Memory reference code.

- Microcode updates.
- ME Firmware.

BIOS Setting Utility

Use AMISCE to import/export BIOS setting in Linux:

- 1. Export BIOS setting and generate script file: /o /s NVRAM.txt
- 2. Import BIOS setting with script file: /i /s NVRAM.txt

BIOS Revision

The BIOS revision is used to identify the BIOS image and BIOS phase.

Table 10: Terminology

Term	Description	
ACPI	Advanced Configuration and Power Interface. ACPI is an open industry specification pro- posed by Intel, Microsoft and Toshiba. ACPI enables and supports reliable power man- agement through improved hardware and OS coordination.	
AHCI	Advanced Host Controller Interface, a SATA controller standard.	
ANSI	American National Standards Institute.	
API	Application Programming Interface. A software abstraction provided by the BIOS to applications and/or the OS.	
ASCII	American Standard Code for Information Interchange. An 8-level code (7 bits plus parity check) widely used in data processing and data communications systems.	
ATA	Advanced Technology Attachment, a disk interface standard.	
BAR	Base Address Register. Device configuration registers that define the start address, length and type of memory space required by a device.	
BIOS	Basic Input/Output System – Firmware interface to the system hardware.	
BIST	Built-in Self Test.	
BMC	Baseboard Management Controller.	
BSP	Boot strap processor. The processor selected at boot time to be the primary processor in a multi-processor system.	
CATERR	Catastrophic Error Signal.	
CE	Correctable Error (memory ECC error).	
CMOS	Complementary Metal-oxide-semiconductor.	
COM1	Communication Port 1, serial port 1.	
DCA	Direct Cache Access.	
DDR4	Double Data Rate 4 is a high bandwidth memory technology.	
DIMM	Dual In-line Memory Module, a plug-in memory module with signal and power pins on both sides of the internal printed circuit board (front and back).	

Term	Description	
DMA	Direct Memory Access.	
DMI	Direct Media Interface – connection from the processor to the PCH.	
DRAM	Dynamic Random Access Memory, memory chips from which DIMMs are constructed.	
DXE	Driver Execution Environment. Component of Intel® Platform Innovation Framework for EFI architecture.	
ECC	Error Correction Code. Refers to a memory system that has extra bit(s) to support limited detection/correction of memory errors.	
EEPROM	Electrically Erasable Programmable Read Only Memory – called "Flash memory".	
EFI	Extensible Firmware Interface (see also UEFI).	
EHCI	Enhanced Host Controller Interface, a USB controller standard.	
Flash	Short for "Flash Memory", solid-state memory based on EEPROMs.	
FRU	Field Replaceable Unit.	
FV	Firmware Volume.	
GbE	Gigabit Ethernet, an Ethernet connection operating at gigabit/second speed.	
GUID	Globally Unique Identifier.	
HotKey	A "HotKey" is a key combination recognized as an unprompted command input. For example, pressing <f2> during POST will take the operator to the Setup Utility.</f2>	
HT	Intel® Hyper-Threading Technology.	
IBMC	Integrated Baseboard Management Controller.	
ICH	I/O Control Hub, a chipset component.	
IDE	Integrated Drive Electronics, a disk interface standard.	
lio	Integrated I/O – I/O controller integrated into the processor chip.	
IMC	Integrated Memory Controller – memory controller integrated into the processor chip.	
INTR	Interrupt Request.	
I/O	Input/Output.	
IPMI	Intelligent Platform Management Interface – an industry standard that defines standard- ized, abstracted interfaces to platform management hardware.	
IRQ	Interrupt Request.	
кум	Keyboard, Video, and Mouse – an attachment that mimics those devices, and connects them to a remote I/O user.	
LAN	Local Area Network.	
LED	Light Emitting Diode.	
LRDIMM	Load Reduced DIMM memory modules have buffer registers for both address and data between the SDRAM modules and the system's memory controller.	
MCA	Machine Check Architecture.	
MCE	Machine Check Exception.	
MMIO	Memory Mapped I/O.	
MRC	Memory Reference Code.	

Table 10: Terminology (Continued)

Term	Description	
MSR	Model Specific Register.	
NIC	Network Interface Card.	
NM	Node Manager – now "Intel® Intelligent Power Node Manager".	
NMI	Non-Maskable Interrupt.	
OEM	Original Equipment Manufacturer.	
OS	Operating System.	
РСН	Platform Controller Hub.	
PCI	Peripheral Component Interconnect, or PCI Local Bus Standard – also called "Conven- tional PCI".	
PCle	PCI Express* an updated form of PCI offering better throughput and better error man- agement.	
PCR	Platform Configuration Register.	
PECI	Platform Environmental Control Interface.	
PEI	Pre EFI Initialization. Component of Intel® Platform Innovation Framework for EFI archi- tecture.	
PERR	Parity Error.	
PIC	Programmable Interrupt Controller.	
PMI	Platform Management Interrupt.	
PnP	Plug and Play. Used as "PnP BIOS" and "PnP ISA".	
POST	Power On Self Test – BIOS activity from the time on Power On until Operating System boot begins.	
PXE	Pre-execution Environment.	
QPI	Intel® QuickPath Interconnect.	
RAID	Redundant Array of Inexpensive Disks – provides data security by spreading data over multiple disk drives. RAID 0, RAID 1, RAID 10, and RAID 5 are different patterns of data on varying numbers of disks to provide varying degrees of security and performance.	
RAS	Reliability, Availability, and Serviceability.	
RDIMM	Registered DIMM (also called buffered) memory modules have an address buffer register between the SDRAM modules and the system's memory controller.	
ROM	Read-Only Memory.	
RTC	Real Time Clock.	
SAS	Serial Attached SCSI, a high speed serial data version of SCSI.	
SATA	Serial ATA, a high speed serial data version of the disk ATA interface.	
SCI	System Control Interrupt.	
SCSI	Small Computer System Interface, a connection usually used for disks of various types.	
SDR	Sensor Data Record.	
SEL	System Event Log.	
SERR	System Error.	

Table 10: Terminology (Continued)

	1	
Term	Description	
SKU	Stock Keeping Unit – indicates a specific marketing package, in this sense based around a server board configuration.	
SMBIOS	System Management BIOS.	
SMI	System Management Interrupt.	
SMM	System Management Mode.	
SOL	Serial Over LAN.	
SPI	Serial Peripheral Interface, a serial data interface used for Flash memory.	
UDIMM	Unbuffered DIMM (also called Unregistered) memory modules do not have a register between the SDRAM modules and the system's memory controller.	
UE or UCE	Uncorrectable Error (memory ECC error).	
UEFI	Unified Extensible Firmware Interface – replacement for Legacy BIOS and the Legacy DOS interface.	
USB	Universal Serial Bus, a standard serial expansion bus meant for connecting peripherals.	
UUID	Universally Unique Identifier. See also GUID.	
WHEA	Windows Hardware Error Architecture.	

Table 10: Terminology (Continued)

Clear CMOS

The following steps will load the BIOS defaults by jumper:

- 1. Power down the system.
- 2. Move CMOS clear jumper from pins 2-3 to pins 1-2 for a few seconds.
- 3. Move CMOS clear jumper back to pins 2-3.
- 4. System automatically powers on.
- 5. Check BIOS defaults are loaded.

Clear Password

- 1. Power down the system.
- 2. Move password clear jumper from pins 2-3 to pins 1-2.
- 3. Power on the system.
- 4. Make sure password is cleared.
- 5. Power down the system.
- 6. Move password clear jumper from pins 1-2 back to pins 2-3.
- 7. Power on the system.
- 8. Set new password.

2.3 Server Management

The BIOS supports many standard-based server management features and several proprietary features. The Intelligent Platform Management Interface (IPMI) is an industry standard and defines standardized, abstracted interfaces to platform management hardware. The BIOS implements many proprietary features that are allowed by the IPMI specification, but these features are outside the scope of the IPMI specification. This section describes the implementation of the standard and proprietary features.

Console Redirection

The BIOS supports redirection of both video and keyboard via a serial link (serial port). When console redirection is enabled, the local, or host server, keyboard input and video output are passed both to the local keyboard and video connections, and to the remote console through the serial link. Keyboard inputs from both sources are considered valid and video is displayed to both outputs.

As an option, the system can be operated without a host keyboard or monitor attached to the system and run entirely via the remote console. Utilities that can be executed remotely include BIOS Setup.

Serial Configuration Settings

The BIOS does not require that the splash logo be turned off for console redirection to function. The BIOS supports multiple consoles, some of which are in graphics mode and some in text mode. The graphics consoles can display the logo and the text consoles receive the redirected text.

Keystroke Mapping

During console redirection, the remote terminal sends keystrokes to the local server. The remote terminal can be a dumb terminal with a direct connection and running a communication program. The keystroke mapping follows VT-UTF8 format with the following extensions.

Кеү	ANSI ESCAPE SEQUENCE	WINDOWS PLATFORM DESIGN NOTE
F1	<esc><shift>op</shift></esc>	<esc>1</esc>
F2	<esc><shift>oq</shift></esc>	<esc>2</esc>
F3	<esc><shift>or</shift></esc>	<esc>3</esc>
F4	<esc><shift>os</shift></esc>	<esc>4</esc>
F5		<esc>5</esc>
F6		<esc>6</esc>
F7		<esc>7</esc>

Table 11: Keystroke Mappings

Кеү	ANSI ESCAPE SEQUENCE	WINDOWS PLATFORM DESIGN NOTE
F8		<esc>8</esc>
F9		<esc>9</esc>
F10		<esc>0</esc>
F11		<esc>!</esc>
F12		<esc>@</esc>
Home	<esc>[<shift>h</shift></esc>	<esc>h</esc>
End	<esc>[<shift>k</shift></esc>	<esc>k</esc>
Ins		<esc>+</esc>
Del		<esc>-</esc>
Page Up		<esc>?</esc>
Page Down		<esc>/</esc>
Reset		<esc>R<esc>r<esc>R</esc></esc></esc>

Table 11: Keystroke Mappings (Continued)

Standalone <Esc> Key for Headless Operation

The Microsoft Headless Design Guidelines describes a specific implementation for the <**Esc**> key as a single standalone keystroke:

To complete an escape sequence, the timeout must be two seconds for entering additional characters following an escape.

- **<Esc>** followed by a two-second pause must be interpreted as a single escape.
- <**Esc**> followed within two seconds by one or more characters that do not form a sequence described in this specification must be interpreted as <**Esc**> plus the character or characters, not as an escape sequence.

The escape sequence in the following table is an input sequence. This means it is sent to the BIOS from the remote terminal.

Reset

BIOS provides another friendly method to reset system from console. User could use $\langle Ctrl \rangle + \langle Shift \rangle + '-'$ to reboot system from remote console.

Limitations

- BIOS Console redirection terminates after an operating system has being loaded. The operating system is responsible for continuing console redirection after that.
- BIOS console redirection is a text console. Graphical data, such as a logo, are not redirected.

If the BIOS determines that console redirection is enabled, it will read the current baud rate and pass this value to the appropriate management controller via the Intelligent Platform Management Bus (IPMB).

Network BIOS Support

PXE Boot

The BIOS supports the EFI PXE implementation. To utilize this, the user must load EFI Simple Network Protocol driver and the UNDI driver specific for the network interface card being used. The UNDI driver should be included with the network interface card. The Simple Network Protocol driver can be obtained from http://developer.intel.com/technology/framework.

The BIOS supports legacy PXE option ROMs in legacy mode and includes the necessary PXE ROMs in the BIOS image for the onboard controllers. The legacy PXE ROM is required to boot a non-EFI operating system over the network.

Checkpoints

A checkpoint is either a byte or word value output to Debug port. The BIOS outputs checkpoints throughout bootblock and Power-On Self Test (POST) to indicate the task the system is currently executing. Checkpoints are very useful in aiding software developers or technicians in debugging problems that occur during the pre-boot process.

Checkpoints can be defined as follow:

- Standard Checkpoint
- ACPI/ASL Checkpoint
- OEM-Reserved Checkpoint
- MRC POST Code Checkpoints

Standard Checkpoint

A checkpoint is either a byte or word value output to Debug port. The BIOS outputs checkpoints throughout bootblock and Power-On Self Test (POST) to indicate the task the system is currently executing. Checkpoints are very useful in aiding software developers or technicians in debugging problems that occur during the pre-boot process.

Status Code Range	DESCRIPTION	
0x01 – 0x0B	SEC execution	
0x0C – 0x0F	SEC errors	
0x10 – 0x2F	PEI execution up to and including memory detection	
0x30 – 0x4F	PEI execution after memory detection	
0x50 – 0x5F	PEI errors	
0x60 – 0x8F	DXE execution up to BDS	
0x90 – 0xCF	BDS execution	
0xD0 – 0xDF	DXE errors	
0xD0 – 0xDF	S3 Resume (PEI)	
0xE9 – 0xEF	S3 Resume errors (PEI)	

Table 12: Checkpoint Range Description

SEC Phase

Table 13: SEC Phase

Status Code	DESCRIPTION	
0x00	Not used	
Progress Codes		
0x01	Power on. Reset type detection (soft/hard).	
0x02	AP initialization before microcode loading	
0x03	North Bridge initialization before microcode loading	
0x04	South Bridge initialization before microcode loading	
0x05	OEM initialization before microcode loading	
0x06	Microcode loading	
0x07	AP initialization after microcode loading	
0x08	North Bridge initialization after microcode loading	
0x09	South Bridge initialization after microcode loading	
0x0A	OEM initialization after microcode loading	
0x0B	Cache initialization	
SEC Error Codes		
0x0C – 0x0D	Reserved for future AMI SEC error codes	
0x0E	Microcode not found	
0x0F	Microcode not loaded	

PEI Phase

Table 14: PEI Phase

STATUS CODE	DESCRIPTION	
Progress Codes		
0x10	PEI Core is started	
0x11	Pre-memory CPU initialization is started	
0x12	Pre-memory CPU initialization (CPU module specific)	
0x13	Pre-memory CPU initialization (CPU module specific)	
0x14	Pre-memory CPU initialization (CPU module specific)	
0x15	Pre-memory North Bridge initialization is started	
0x16	Pre-Memory North Bridge initialization (North Bridge module specific)	
0x17	Pre-Memory North Bridge initialization (North Bridge module specific)	
0x18	Pre-Memory North Bridge initialization (North Bridge module specific)	
0x19	Pre-memory South Bridge initialization is started	
0x1A	Pre-memory South Bridge initialization (South Bridge module specific)	
0x1B	Pre-memory South Bridge initialization (South Bridge module specific)	
0x1C	Pre-memory South Bridge initialization (South Bridge module specific)	
0x1D	Waiting BMC initialization	
0x1E – 0x2A	OEM pre-memory initialization codes	
0x2B	Memory initialization. Serial Presence Detect (SPD) data reading	
0x2C	Memory initialization. Memory presence detection	
0x2D	Memory initialization. Programming memory timing information	
0x2E	Memory initialization. Configuring memory	
0x2F	Memory initialization (other).	
0x30	Reserved for ASL (see ASL Status Codes section below)	
0x31	Memory Installed	
0x32	CPU post-memory initialization is started	
0x33	CPU post-memory initialization. Cache initialization	
0x34	CPU post-memory initialization. Application Processor(s) (AP) initialization	
0x35	CPU post-memory initialization. Boot Strap Processor (BSP) selection	
0x36	CPU post-memory initialization. System Management Mode (SMM) initialization	
0x37	Post-Memory North Bridge initialization is started	
0x38	Post-Memory North Bridge initialization (North Bridge module specific)	
0x39	Post-Memory North Bridge initialization (North Bridge module specific)	
0x3A	Post-Memory North Bridge initialization (North Bridge module specific)	
0x3B	Post-Memory South Bridge initialization is started	
0x3C	Post-Memory South Bridge initialization (South Bridge module specific)	
0x3D	Post-Memory South Bridge initialization (South Bridge module specific)	

Status Code	DESCRIPTION	
0x3E	Post-Memory South Bridge initialization (South Bridge module specific)	
0x3F – 0x4E	OEM post memory initialization codes	
0x4F	DXE IPL is started	
PEI Error Codes	•	
0x50	Memory initialization error. Invalid memory type or incompatible memory speed	
0x51	Memory initialization error. SPD reading has failed	
0x52	Memory initialization error. Invalid memory size or memory modules do not match.	
0x53	Memory initialization error. No usable memory detected	
0x54	Unspecified memory initialization error.	
0x55	Memory not installed	
0x56	Invalid CPU type or Speed	
0x57	CPU mismatch	
0x58	CPU self test failed or possible CPU cache error	
0x59	CPU micro-code is not found or micro-code update is failed	
0x5A	Internal CPU error	
0x5B	reset PPI is not available	
0x5C-0x5F	Reserved for future AMI error codes	
S3 Resume Progress Codes		
0xE0	S3 Resume is stared (S3 Resume PPI is called by the DXE IPL)	
0xE1	S3 Boot Script execution	
0xE2	Video repost	
0xE3	OS S3 wake vector call	
0xE4 – 0xE7	Reserved for future AMI progress codes	
S3 Resume Error Codes		
0xE8	S3 Resume Failed	
0xE9	S3 Resume PPI not Found	
0xEA	S3 Resume Boot Script Error	
0xEB	S3 OS Wake Error	
0xEC – 0xEF	Reserved for future AMI error codes	

Table 14: PEI Phase (Continued)

DXE Phase

Table 15: DXE Phase

Status Code	DESCRIPTION
0x60	DXE Core is started
0x61	NVRAM initialization

Status Code	DESCRIPTION
0x62	Installation of the South Bridge Runtime Services
0x63	CPU DXE initialization is started
0x64	CPU DXE initialization (CPU module specific)
0x65	CPU DXE initialization (CPU module specific)
0x66	CPU DXE initialization (CPU module specific)
0x67	CPU DXE initialization (CPU module specific)
0x68	PCI host bridge initialization
0x69	North Bridge DXE initialization is started
0x6A	North Bridge DXE SMM initialization is started
0x6B	North Bridge DXE initialization (North Bridge module specific)
0x6C	North Bridge DXE initialization (North Bridge module specific)
0x6D	North Bridge DXE initialization (North Bridge module specific)
0x6E	North Bridge DXE initialization (North Bridge module specific)
0x6F	North Bridge DXE initialization (North Bridge module specific)
0x70	South Bridge DXE initialization is started
0x71	South Bridge DXE SMM initialization is started
0x72	South Bridge devices initialization
0x73	South Bridge DXE Initialization (South Bridge module specific)
0x74	South Bridge DXE Initialization (South Bridge module specific)
0x75	South Bridge DXE Initialization (South Bridge module specific)
0x76	South Bridge DXE Initialization (South Bridge module specific)
0x77	South Bridge DXE Initialization (South Bridge module specific)
0x78	ACPI module initialization
0x79	CSM initialization
0x7A – 0x7F	Reserved for future AMI DXE codes
0x80 – 0x8F	OEM DXE initialization codes
0x90	Boot Device Selection (BDS) phase is started
0x91	Driver connecting is started
0x92	PCI Bus initialization is started
0x93	PCI Bus Hot Plug Controller Initialization
0x94	PCI Bus Enumeration
0x95	PCI Bus Request Resources
0x96	PCI Bus Assign Resources
0x97	Console Output devices connect
0x98	Console input devices connect
0x99	Super IO Initialization

Table 15: DXE Phase (Continued)

STATUS CODE	DESCRIPTION
0x9A	USB initialization is started
0x9B	USB Reset
0x9C	USB Detect
0x9D	USB Enable
0x9E – 0x9F	Reserved for future AMI codes
0xA0	IDE initialization is started
0xA1	IDE Reset
0xA2	IDE Detect
0xA3	IDE Enable
0xA4	SCSI initialization is started
0xA5	SCSI Reset
0xA6	SCSI Detect
0xA7	SCSI Enable
0xA8	Setup Verifying Password
0xA9	Start of Setup
0xAA	Reserved for ASL (see ASL Status Codes section below)
0xAB	Setup Input Wait
0xAC	Reserved for ASL (see ASL Status Codes section below)
0xAD	Ready To Boot event
0xAE	Legacy Boot event
0xAF	Exit Boot Services event
0xB0	Runtime Set Virtual Address MAP Begin
0xB1	Runtime Set Virtual Address MAP End
0xB2	Legacy Option ROM Initialization
0xB3	System Reset
0xB4	USB hot plug
0xB5	PCI bus hot plug
0xB6	Clean-up of NVRAM
0xB7	Clean-up of NVRAM
0xB8 – 0xBF	Reserved for future AMI codes
0xC0 – 0xCF	OEM BDS initialization codes
DXE Error Codes	
0xD0	CPU initialization error
0xD1	North Bridge initialization error
0xD2	South Bridge initialization error
0xD3	Some of the Architectural Protocols are not available

Table 15: DXE Phase (Continued)

Status Code	DESCRIPTION
0xD4	PCI resource allocation error. Out of Resources
0xD5	No Space for Legacy Option ROM
0xD6	No Console Output Devices are found
0xD7	No Console Input Devices are found
0xD8	Invalid password
0xD9	Error loading Boot Option (LoadImage returned error)
0xDA	Boot Option is failed (StartImage returned error)
0xDB	Flash update is failed
0xDC	Reset protocol is not available

Table 15: DXE Phase (Continued)

ACPI/ASL Checkpoints

Table 16: ACPI/ASL Checkpoints

Status Code	DESCRIPTION
0x01	System is entering S1 sleep state
0x02	System is entering S2 sleep state
0x03	System is entering S3 sleep state
0x04	System is entering S4 sleep state
0x05	System is entering S5 sleep state
0x10	System is waking up from the S1 sleep state
0x20	System is waking up from the S2 sleep state
0x30	System is waking up from the S3 sleep state
0x40	System is waking up from the S4 sleep state
0xAC	System has transitioned into ACPI mode. Interrupt controller is in PIC mode.
0xAA	System has transitioned into ACPI mode. Interrupt controller is in APIC mode.

OEM-Reserved Checkpoint Ranges

Table 17: OEM Reserved Checkpoint Ranges

Status Code	DESCRIPTION
0x05	OEM SEC initialization before microcode loading
0x0A	OEM SEC initialization after microcode loading
0x1D – 0x2A	OEM pre-memory initialization codes
0x3F – 0x4E	OEM PEI post memory initialization codes
0x80 – 0x8F	OEM DXE initialization codes
0xC0 – 0xCF	OEM BDS initialization codes

BMC

Chapter 3

This section provides information and key features of BMC (Baseboard Management Controller).

3.1 Server Management Software

Server System Overview

In a server system, BMC is an independent system of the host server system. This independent system has its own processor and memory; the host system can be managed by the BMC system even if the host hardware or OS hangs or is unable to function.

BMC Key Features and Functions

- Supports IPMI v1.5 and v2.0.
- Support SNMP v1,v2c and v3.
- Support SMASH.
- Support delivers alerts such as SNMP traps in the Platform Event Trap (PET) format.
- Out-of-band monitoring and control for sever management over LAN.
- Share NIC for remote management via network.
- The FRU information report includes main board part number, product name, manufacturer, etc.).
- Health status/Hardware monitoring report.
- Events log, view, and clear.
- Event notification via lighting chassis LED indicator and Platform Event Trap (by SNMP trap) or Mail (by Simple Mail Transfer Protocol).
- Platform Event Filtering (PEF) to take selected actions for selected events, including NMI.
- Chassis management includes power control and a status report, front panel buttons and LED control.
- Watchdog and auto server restart and recovery.
- Supports multi-session users, and alert destination for LAN channel.
- Support IPMB connecter that advanced server management card can communicate with BMC.

Power System

BMC controls system power through GPIO pins and IPMI chassis commands.

Front Panel User Interface

The BMC provides control panel interface functionality including indicators (Fault/status and Identify LEDs) and buttons (Power/ID).

Power Button

The Power buttons allow to control the system status.

ID Button

The control panel Chassis Identify button toggles the state of the Chassis ID LED. If the ID LED is off, then a button press will turn the LED on (blinking). If the LED is on, a button press or IPMI Chassis Identify command will turn the LED off.

LEDs

The following table contains information on Status, ID and Heartbeat LED's.

LEDs	Color	Status	DESCRIPTION
	Amber (Status LED)	Blinking	System Event
Status LED		Off	Normal status
	Blue	On	Power on
	blue	Off	Power off
		Off	Normal status
ID LED	Blue	Blinking	Identify the system with interval
		Solid ON	Identify the system
Heartbeat LED	Green	On/Off	BMC is not Ready
		Blinking	BMC is Ready

Table 3.1: Status LED, ID LED, and Heartbeat LED

LAN Interface

BMC LAN interface in AST2400 is assigned to its Shared NIC LAN and a dedicated NIC (Default) in the system. IPMI Specification v2.0 defines how IPMI messages, encapsulated in RMCP/RMCP+ packet format, can be sent to and from the BMC. This capability allows a remote console application to access the BMC and perform the following operations:

- Chassis control: obtain chassis status, reset and power-up the chassis
- Obtain system sensor status
- Obtain and Set system boot options
- Obtain Field Replaceable Unit (FRU) information

- Obtain System Event Log (SEL) entries
- Obtain Sensor Data Records (SDR)
- Set Platform Event Filtering (PEF)
- Set LAN configurations

In addition, the BMC supports LAN alerting in the form of SNMP traps that conform to the IPMI Platform Event Trap (PET) format.

Session and User

This BMC supports ten (10) user accounts. Each can have a different user name, password and privilege level. Four accounts can login simultaneously. The available user privilege levels are User, Operator, and Administrator.

Serial Over LAN

BMC supports 1 IPMI (Spec v2.0) specific SOL session. BMC supports redirect data from UART interface.

Time Sync

In BMC design, BMC does not have a local RTC to know what time it is. Each time BMC will get the current time from system PCH after BMC boot. The current time is updated periodically from the PCH. The remote console program interpret this time as pre-initial.

SEL

BMC supports IPMI 1.5/2.0 standard SEL operation. It can keep SEL log. Event happened in BIOS side will be logged by using Add SEL Entry command. BMC will store them in FLASH, the time stamp field will be filled by BMC. When SEL is full, the new SEL won't be logged but will go through PEF as usual. If AC powers off, all SELs will remain in NV.

Platform Event

Platform Event Filter

The BMC implements selectable action on an event or LAN alerting base on event. By default, no any PEF entries or actions exist, applications need to configure it to enable.

- Dedicated and Shared NIC
- The policy to match an event to Platform Event Filter Table entry is IPMI 1.5 standard.
- The action support Power off, Power Reset, Power Cycle and NMI.

BMC

- All Platform Event Filter Table is default disabled.
- PEF Startup Delay and Last Processed Event tracking is not supported.
- PEF table lookup isn't correlated to log SEL to SEL Repository.
- Serial Alerting is no support.

BMC Firmware Update

The BMC will allow users to upgrade firmware image on following entities:

- BMC
- All other upgradable entities

The update capability is provided by local and remote interfaces.

DOS Recovery Utility

SOCFLASH Utility.

WebUI Update

Remote update can be performed through the remote Web console.

This section provides guidelines on BMC recovery process in DOS and Linux systems.

Recovery Process in DOS System

To recover BMC on a DOS system, do as follows:

- 1. Copy BMC firmware package to your USB key.
- 2. Boot into DOS.
- 3. Run dos.bat.

The BMC recovery is complete.

Recovery Process in Linux System

To recover BMC on a Linux system, do as follows:

- 1. Copy BMC firmware package to your USB drive.
- 2. Boot into Linux.
- 3. Run linux.sh.

The BMC recovery is complete.

Recovery Process in Windows System

To recover BMC on a Windows system, do as follows:

- 1. Copy BMC firmware package to your USB key.
- 2. Boot into Windows.
- 3. Run win.bat.

The BMC recovery is complete.

3.3 SMASH

Quanta SMASH is a tool that allows you to use Secure Shell (SSH) to login in the embedded Linux of BMC from remote terminal and gather information as well as give you control over things like power resets, power off. The basic structure is shown as below:



Figure 3-1. Using SSH to login in

Here presents an activity diagram, user could use SSH to login in embedded Linux of BMC from remote terminal. After login in successfully, SMASH would be executed automatically. In this time, SMASH is running and allowing user to input commands. The connection will be terminated if the terminal console is idle more than five minutes.

Default SSH UserName / Password (User Account in Linux): sysadmin / superuser



Input command in Linux: ssh sysadmin@<Server IP>



Here provides you the commands about system level and BMC level.

System Level Commands

The system level commands provide you the information and power state control.

Related Targets					Su	JPPORTE	D VERBS				
	CD	EXIT	HELP	CREATE	DELETE	SET	SHOW	RESET	START	STOP	VERSION
/	v	v	v				v				v
/SYS	v	v	v				v	v	v	v	v
/SYS/voltage	v	v	v				v				v
/SYS/fan	v	v	v				v				v
/SYS/temperature	v	v	v				v				v
/SYS/powerSupply	v	v	v				v				v

• Displays information for the board

show /SYS

Power-on system

start /SYS

• Power-off system

stop /SYS

• Power-reset system

reset /SYS

- Display all system voltage show /SYS/voltage
- Display all system fan show /SYS/fan
- Display all system temperature show /SYS/temperature
- Display all system power supply show /SYS/powerSupply

/SYS

This command provides you the high-level status of the system chassis and main power subsystem.

Tab	le	3	.3:	/S	YS
100		-		, 0	

PROPERTY NAME	VALID VALUE	Access	DESCRIPTION
LOM/OCP Mezz/QCT Mezz	System MAC Address	R	Dynamically to show System MAC address by LOM/OCP/ QCT /SYS Targets: voltage fan temperature powerSuply Properties: 0CP Mezz = 08:79:18:09:143:10 Quanta Mezz = 04:70:78:A0:10:70 Quanta Mezz = 04:70:78:A0:10:70 ChassiSStatus = powerIsOFF Target Commands: show cd start stop reset
ChassisStatus	powerlsOFF powerlsON	R	ChassisStatus provides the high-level status of the system chassis and main power subsystem. PowerIsOFF : indicates the system power is off PowerIsON : indicates the system power is on.

Q&A

Q: I tried to turn system power off by IPMI command "**power soft**" when there is no response from operating system and system could not be shutdown. What is the Chassis Status?

A: The status of ChassisStatus is "powerIsON."

/SYS/voltage

This command returns a high level version of the system voltages health status.

Table 3.4: /SYS/voltage

PROPERTY NAME	VALID VALUE	Access	DESCRIPTION
Sensor name list of voltage	na ok nonCritical critical	R	na indicates the status not available /unknown (typically because system power is off) ok indicates the monitored parameters within normal operating ranges nonCritical indicates the hardware outside normal operating range critical indicates the hardware exceeding specified ratings

*The sensor name list depends on the Server Hardware.

/SYS/fan

This command returns a high level version of the system fan health status.

Table 3.5: /SYS/fan

PROPERTY NAME	VALID VALUE	Access	Description
Sensor name list of fan	na ok nonCritical critical	R	na indicates the status not available /unknown (typically because system power is off) ok indicates the monitored parameters within normal operating ranges nonCritical indicates the hardware outside normal operating range critical indicates the hardware exceeding specified ratings

*The sensor name list depends on the Server Hardware.

/SYS/temperature

This command returns a high level version of the system temperature health status.

Table 3.6: /SYS/temperature

PROPERTY NAME	VALID VALUE	Access	DESCRIPTION
Sensor name list of temperature	na ok nonCritical critical	R	na indicates the status not available /unknown (typically because system power is off) ok indicates the monitored parameters within normal operating ranges nonCritical indicates the hardware outside normal operating range critical indicates the hardware exceeding specified ratings

*The sensor name list depends on the Server Hardware.

/SYS/powerSupply

This command provides the specification of the Sensor Type sensor-specific event.

Table 3.7: /SYS/powerSupply

PROPERTY NAME	VALID VALUE	Access	DESCRIPTION
Sensor name list of power supply	Presence* Power Supply Fail- ure Detected* Predictive Fail* Power Supply Input Lost (AC/DC)* All Deasserted (*Note: Only for certain models.)	R	Presence Detected indicates the Power Supply Presence detected Power Supply Failure Detected indicates the Power Supply Failure detected Predictive Fail indicates the Power Supply Predictive Failure Power Supply Input Lost (AC/DC) indicates the Power Supply input lost, such as power cord not inserted All Deasserted indicates the power supply is not inserted
Redundancy	Fully Redundant Redundancy Lost	R	Fully Redundant Indicates the power redundancy is OK. Redundancy Lost Indicates the power redundancy is fail. One PSU is removed or AC lost. na When system powered off, the state is not available.

*The sensor name list depends on the Server Hardware.

Q&A:

Q1: My system supports two power supply slots and only one power supply unit connected. What is the other power supply status?

A1: The other power supply status is " AllDeasserted ".

Q2: My system supports two power supply slots and two power supply units connected. But only one power cord plugged. What is the other power supply status?

A2: The other power supply status shows "Presence Detected, Predictive Fail, Power Supply Input Lost (AC/DC) ".

BMC Information

The BMC level commands provide several options to configure and display parameters of the management agent.

Table 3.8: Targets and Verbs

Related Targets		SUPPORTED VERBS									
	CD	EXIT	HELP	CREATE	DELETE	SET	SHOW	RESET	START	STOP	VERSION
/	v	v	v				v				v
/SP	v	v	v			v	v	v			v

• Displays information for the board

show /SP

• Reset BMC

reset /SP

- Set server identify LED to be off set /SP ServerIdentify=off
- Set server identify LED to be on set /SP ServerIdentify=on
- Set server identify LED to be blinking set /SP ServerIdentify=blinking

/SP

Table 3.9: /SYS/fan

PROPERTY NAME	VALID VALUE	Access	DESCRIPTION		
BMCVersion		R	Display BMC firmware revision		
BMCGUID		R	Display BMC GUID		
Serverldentify	off on blinking	R/W	Configuring server identify LED		
BMCMAC		R	Display the NIC physical address used by server management agent		

3.4 Web Graphical User Interface (GUI) for ESMS

Using the Web GUI

The BMC firmware features an embedded web server enabling users to connect to the BMC using a Web browser (e.g. Microsoft Internet Explorer). The Web GUI shows system information, system events, system status of managed servers, and other system-related information.

The Web-based GUI is supported on the following browsers:

- Internet Explorer 7 and above
- Firefox 8.0 and above
- Google Chrome 2.0 and above

Login

Enter the IP address or URL (default DHCP\static IP address) into the address bar of the web browser.

When connecting to the BMC the Login screen prompts for the username and password. This authentication with SSL protection prevents unauthorized intruders from gaining access to the BMC web server.

When a user is authenticated they can manage the server according to the privilege of their role.

The OEM Proprietary, Administrator and Operator privilege levels are authorized to login to the web interface. The User and No Access privilege levels do not allow access through the BMC web GUI.

User ID	
Password	_
Login	
Required Browser Settings	
* Allow popups from this site	
* Allow file download from this site.	
* Enable javascript for this site 🥝	
* Enable cookies for this site 🥝	

Figure 3-3. Login Web Page

Field	DEFAULT				
Username	qct.admin				
Password	qct.admin				

Table 4: Default Username and Password

After passing authentication, the following web page appears.

Note:

The default username and password are in lowercase characters. It is advised to change the admin password once you have logged in.

Click the **Help** button on the right corner of the page for assistance, the **Refresh** button to refresh the page, or the **Logout** button to exit.





Table 5: Main Web Page

Menu Item	DESCRIPTION				
Dashboard	Displays the device, network, sensor monitoring and event logs infor- mation.				
Server information	Shows system information.				
Server Health	Monitoring status of the server.				
Configuration	Configuration of the IPMI settings.				
Remote Control	Launch KVM console and perform power control.				
Maintenance	Allows the user to configure the preserve configuration items.				
Firmware Update	Allows the user to do firmware update				

Dashboard

In MegaRAC GUI, the Dashboard page displays the overall information on status of the device.

To open the **Dashboard** page, click Dashboard from the main menu. A sample screenshot of the Dashboard page is as follows:

Device Information	1		Sensor Moni	toring	
Firmware Revision: 2. Firmware Build Time: Ju	01.75933 I 23 2015 12:34:23 CST	Status	Sensor	Reading	
BIOS Version: SS	IA_2A01	•	Temp_Inlet	26 ° C	م
System MAC	edicated-NIC	•	Temp_Outlet	29 ° C	ĥ
- 1 : LOM :2C:60:0	C:83:FB:17	•	Temp_FP	25 ° C	م
BMC Date & Time: Fr	i, 09 Jan 2009 20:27:16	•	Volt_P3V3_AUX	3.339 Volts	ç
BMC Chipset : AS	ST2400(A1)	•	Volt_P5V_AUX	5.009 Volts	a,
PSU1 MFR Revision: A03 PSU1 Firmware Version:05.00.06 PSU1 MFR Revision: A03 PSU1 Firmware Version:05.00.06	03 05.00.06	•	Volt_P3V_BAT	3.074 Volts	ç
	03 05.00.06	•	Volt_P1V_PCH	1.009 Volts	م
Network Informati	op (53%)	•	Volt_P1V538_AUX	1.528 Volts	\$
Host Name:	OCT2C600C83FD0C	•	Volt_P1V26_AUX	1.264 Volts	ç
MAC Address:	2C:60:0C:83:FD:0C	•	Volt_P1V2_AUX	1.205 Volts	ç
V4 Network Mode:	DHCP				
IPv4 Address:	10.10.14.43				

Figure 3-5. Dashboard

A brief description of the Dashboard page is given in the next section.

Device Information

The Device Information displays the following information:

Table 6: Device Information Page

Ітем	DESCRIPTION				
Firmware Revision	The revision number of the firmware.				
Firmware Build Time	Firmware date and time.				
BIOS Version	The current BIOS firmware version.				
PSU1 MFR Revision	Display PSU1 manufacture revision.				
PSU1 Firmware version	Display PSU1 Firmware version.				
PSU2 MFR Revision	Display PSU2 manufacture revision.				
PSU2 Firmware version	Display PSU2 firmware version.				
PDB Firmware Version	The current PDB (Power Distribution Board) firmware version.				
FCB Version	The current FCB (Fan Control Board) firmware version.				
PSU Max output Power	Display power supply max output power (Watts).				
MB Position	Display the current position of the mainboard within the chassis.				
Blackplane F/W version	Display current backplane firmware version.				
BMC NIC	Display current used NIC.				
System MAC	The maximum MAC address of system LAN port is 8. From Grantley plat- form, BMC supports to show LAN Card Type (LOM/OCP Mezzanine/ Quanta Mezzanine) for System MAC.				
Table 6: Device Information Page (Continued)

Ітем	DESCRIPTION
BMC Date & Time	The current time of BMC system.
BMC Chipset	This field shows BMC chipset type.

Note:

BMC Chipset type support list:

- (1) AST2300/AST2400: support virtual KVM function and related setting item.
- (2) AST2300/AST2400 without RKVM: not support virtual KVM function and related setting item.
- (3) AST2050/AST2150: support virtual KVM function and related setting item.
- If BMC Chipset type is "AST2300/AST2400 without RKVM", Console Redirection, Mouse Mode, Remote Session, and Virtual Media menu item will be removed.

Network Information

The Network Information of the device with the following fields is shown in the following table. To edit the network Information, click **Edit**.

Table 7: Network Information

Ітем	DESCRIPTION
Host Name	Read only field showing the DNS Hostname of the device.
MAC Address	Read only field showing the BMC MAC address of the device.
V4 Network Mode	The v4 network mode options are static or DHCP.
IPv4 Address	The IPv4 address of the device (could be static or DHCP).
V6 Network Mode	The v6 network mode options are static or DHCP.
IPv6 Address:	The IPv6 address of the device.
IPv6 Link Local Address	The IPv6 link local address of the device.

Sensor Monitoring

Lists all the available sensors on the device.

The status column displays the state of the device as follows:

Table 3	8-1:
---------	------

Status (Icon)	DESCRIPTION
۲	Normal state

Table 3-1:

Status (Icon)	DESCRIPTION
1	Warning state
	Critical state

If you click on \mathcal{P} , the sensor page for that particular sensor will be displayed.

Event Logs

A graphical representation of all events incurred by various sensors as well as occupied/ available space in logs. Clicking on the color-coded rectangle in the Legend for the chart, allows to view a list of specific events only.

Server Information

The Server Information Group consists of the following items:

- FRU Information
- Server Component
- Server Identify
- BIOS POST Code

The following screenshot displays the Server Information menu items:

					admin(Administ	rator)	Refresh	Print	Logout
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firm	ware Updat	te	HELP
Elete De	FRU Information	(5011)							<u> </u>
Field Re	Server Component	(FRU)							
This page give	Server Identify	or the various FRU o	levices present in t	his system.					
BIOS POST Code									
Basic Infor	mation:	-1							
FRU Devic	ce ID			•					
FRU Devic	ce Name	м	B_FRU						
Chassis In	formation:								•

Figure 3-6. Server Information – Menu

FRU Information

In the MegaRAC GUI, the FRU Information Page displays the BMC FRU file information. The information displayed in this page is Basic Information, Common Header Information, Chassis Information, Board Information and Product Information of the FRU device.

To open the FRU Information Page, click on **FRU Information** on top menu. Select a FRU Device ID from the Basic Information section to view the details of the selected device. A screenshot of FRU Information page is shown as follows:

							admin(Administrator)	Refresh	Print	Logou	t
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmware Update				HEL	P
Field F	Replaceable Uni	t(FRU)								ł	<u></u>
This name (nives detailed information (for the various ER	Il devices present i	in this system						_	
THIS PAGE (o de noes present	in the system.							
Basic In	formation:										
FRU	Device ID	ſ	0	•							
FRU	Device Name	1	IB_FRU								
Chassie	Information										
Chassis	s information:										
Chase	sis Information Area Form	nat Version 1									
Chase	sis Type	F	Rack Mount Chassis	5							
Chase	sis Part Number	1	N/A								
Chase	sis Serial Number										-
Chase	sis Extra		N/A N/A								
Board II	nformation:										
Board	Information Area Forma	t Version 1									
Langu	uage	E	English								
Manuf	facture Date Time	I	Thu Jan 1 12:12:00	2009							
Board	i Manufacturer	c	Quanta Computer In	10.							
Board	I Product Name	5	53A								
Board	d Serial Number		lfghfdhfg							6	•

Figure 3-7. FRU Information Page

A brief description of the fields is given in the following sections.

Basic Information

Table 4: Basic Information

Ітем	DESCRIPTION
FRU device ID	The ID of the device.
FRU Device Name	The device name of the selected FRU device.

Chassis Information

- Chassis Information Area Format Version
- Chassis Type
- Chassis Part Number
- Chassis Serial Number
- Chassis Extra

Board Information

- Board Information Area Format Version
- Language

- Manufacture Date Time
- Board Manufacturer
- Board Product Name
- Board Serial Number
- Board Part Number
- FRU File ID
- Board Extra

Product Information

- Product Information Area Format Version
- Language
- Manufacturer Name
- Product Name
- Product Part Number
- Product Version
- Product Serial Number
- Asset Tag

Server Component

The Component Information page displays the CPU and memory information. The Number of CPU Socket field and the Number of Memory Slot field display the total number of the motherboard supported.

						admin(Adr	ninistrator)	Refresh	Print	Logout
Dashbo	ard Serv	er Information	Server Health	Configuration	Remote Control	Maintenance	Firmware	e Update		HELP
Com	ponent	Informatio	on							
This pa column CPU	ge displays c header. Sele Information	component inform oct a component ty	ation. You can choo /pe category:	ise a category from t	he pull-down box to fil	ter the component:	s, and also s Nun	sort them by c nber of CPU S	icking or ocket: 1 s	i a sockets
ID A	Status 🛆	Socket Δ	Manufacturer .	۵ Model	Δ			Frequency	- Δ	
1	Enable	CPU	Intel	Skylake	S			2600MHz		
									Re	fresh

Figure 3-8. Component Information Page

Ітем	DESCRIPTION
CPU Information	Displays the following information: • CPU ID, • Status, • Socket, • Manufacturer, • Model, • Frequency
Memory Information	Displays the following information: Memory ID, Status, Socket, Module Size, Model, Frequency

Table 5: Component Information Page

Server identify

The Server Identify page displays the indicator LED status. You can select a Server Identify Operation to control the indicator LED.

					admin(Ad	ministrator)	Refresh	Print	Logout
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmwar	e Update		HELP
Server lo	dentify								1
View server ide	entify current status and	perform a server ide	entify operation.						
Identify Sta Server Ide	atus is currently off entify Operation								
ON									
O OFF									
C Blink									
Server Ide	entify Timeout	5	Second(s)						

Figure 3-9. Server Identify Page

Table 6: Server Identity Page	Tab	le 6:	Server	Identify	Page
-------------------------------	-----	-------	--------	----------	------

Ітем	DESCRIPTION
Current Server Identify Status	The server status: On or Off.
Server Identify Operation	 Server identify LED operation with the following options: ON OFF Blink
Server Identify Timeout	Setup server timeout value when a Blink Identify Operation is selected. For Blink Operation the time period must be from 1 to 255 seconds. When 255 seconds is selected, the blinking is continuous.

Table 6: Server Identify Page (Continued)

Ітем	DESCRIPTION
Perform Action	Executes the selected Server Identify Operation.

BIOS POST Code

The page displays recent BIOS Port 80h POST code.

										admin(A	dministrator)	Refresh	Print	Logou
Dashboard	Server Information	Serv	er Health	Conf	iguration	Ren	note C	ontrol	Mainte	nance	Firmware	Update		HEL
BIOS PO	OST Code													
This page dis	plays recent BIOS Port	80h POS	T codes.											
										_				
Curre	nt Codes:	N/A								*				
Previo	ous Codes:	01 03 D3 55	04 02 (03 04 0	5 OC 0I) 15 1	9 00 :	1E 20	FE 53	*				

Figure 3-10. BIOS POST Code

Table 7: BIOS POST Code Page

Ітем	DESCRIPTION
Current Codes	Current BIOS Port 80h POST code
Previous Codes	Previous BIOS Port 80h POST code

Server Health Group

The Server Health Group consists of the following items:

- Sensor Readings
- Event Log

The Server Health screenshot allows to select Sensor Readings or Event Log as shown in the following image:

					admin	Administrator)	Refresh	Print	Logo
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmware	Update		HEL
0	Destination	Sensor Reading	js						
Sensor	Readings	Event Log							
All sensor rela	ated information will be d	splayed here. Doub	le click on a record	I to toggle (ON / OFF) t	he live widget for th	nat particular s	ensor.		

Figure 3-11. Server Health – Menu

Sensor Readings

In MegaRAC GUI, the Sensor Readings page displays all the sensor related information.

To open the Sensor readings page, click **Server Health** > **Sensor Readings** from the top menu. Click on a record to display more information on a particular sensor, including thresholds and a graphical representation of all associated events. A screenshot of Sensor Readings page is shown in the following image:

							admin(Administrator)	Refresh	Print	Lo
Dashboard	Server Information Server H	lealth Configuration Remot	e Control I	Maintenance	Firmware Upda	ate				н
All Sensors	•							Sensor Co sensors	ount: 40	
Sensor Na	me 🔺 🦷 Status 🔺	Current Reading 🔺								
CPU	Detected	e 0x8080	CPU: 0	x8080			PROCESSO	PRESENCE	DETECTED	
Temp_CPU	Normal	N/A								
Temp_CPU_	DTS Normal	N/A	Threshol	lds for this sen	sor			Live W	idget N/A	
HDD0	All deasserted	N/A								
HDD1	All deasserted	N/A	Lower No	on-Recoverable	(LNR): N/A		Upper Non-	Recoverable (UNR): N/A	
HDD2	All deasserted	N/A	Lower Cr	ritical (LC):	N/A		Upper Criti	cal (UC):	N/A	
HDD3	All deasserted	N/A	Lower No	on-Critical (LNC)): N/A		Upper Non-	-Critical (UNC):	: N/A	
Temp_Inlet	Normal	26 ° C						Threshold	Settings	E 1
Temp_Outlet	Normal	29 ° C								4
Temp_DIMM	_Area Normal	N/A								
Temp_FP	Normal	25 ° C	Graphica	al View of this	sensor's event	5				
Temp_OCP	Normal	N/A								
Fan_SYS0_1	I Normal	N/A		(0)						
Fan_SYS0_2	2 Normal	N/A	LNR	(0)						
Fan_SYS1_1	I Normal	N/A	LC ((⁰)						
Fan_SYS1_2	2 Normal	N/A								
Fan_SYS2_1	I Normal	N/A	LNC	(0)						
Fan_SYS2_2	2 Normal	N/A	UNR	(0)						
Volt_P3V3	Normal	N/A		(-)						
Volt_P5V	Normal	N/A	UC ((0)						
Volt_P12V	Normal	N/A	UNC	(0)						
Volt_P2V5_V	/PP Normal	N/A		(0)						
Volt_P3V3_A	UX Normal	3.354 Volts	Other ((0)						
Volt_P5V_AU	JX Normal	5.009 Volts		~						
Volt_P3V_B4	AT Normal	3.074 Volts	Uiscrete ((0)						
Volt_P1V_P0	CH Normal	1.009 Volts	0		3	6 9	13			
VAH 011/620	ALLY Normal	1 529 Valte				Number of Entries				
•										

Figure 3-12. Sensor Readings Page

A brief description of the Sensor Readings page fields is given in the following sections.

Sensor Type

This drop down menu allows you to select the type of sensor. The List of sensors with the Sensor Name, Status and Current Reading will be displayed in the list. If you select All Sensors, all the available sensor details will appear else you can choose the sensor type that

you want to display in the list. Some examples of other sensors include Temperature Sensors, Fan Sensors, and Voltage Sensors etc.

Select a particular sensor from the list. You can view the Thresholds for this sensor on the right hand side of the screen.

Thresholds are of six types:

- Lower Non-Recoverable (LNR)
- Lower Critical (LC)
- Lower Non-Critical (LNC)
- Upper Non-Recoverable (UNR)
- Upper Critical (UC)
- Upper Non-Critical (UNC)

The threshold states could be:

Lower Non-critical - going low, Lower Non-critical - going high, Lower Critical - going low, Lower Critical - going high, Lower Non-recoverable - going low, Lower Non-recoverable - going high, Upper Non-critical - going low, Upper Non-critical - going high, Upper Critical - going low, Upper Critical - going high, Upper Non-recoverable - going low, Upper Non-recoverable - going high.

A graphical view of these events (Number of event logs vs. Thresholds) can be viewed as shown in the Sensor Readings Page screenshot.

Live Widget

The widget window can be turned On and Off for a selected sensor. Widget provides a dynamic representation of the readings for the sensor. The following image shows an example widget:



Figure 3-13. Widget Window

Note:

Widgets are little gadgets, which provide real time information about a particular sensor. User can track a sensor's behavior over a specific amount of time at specific intervals. The result will be displayed as a line graph in the widget. The session will not expire, until the widgets gets a live data of the last widget that is kept opened.

View this Event Log

View the Event Log page for the selected sensor.

Sensor Reading status

You can read currently sensor status in this page, each sensor name has its SDR setting data, the status according SDR setting will display as following matrix:

Table 8: Sensor Readings status

Status	CURRENT READING				
N/A	N/A				
All deasserted	0x80xx(*2)				
Normal	Value with unit				
Event string(*1)					
(*1) Please refer IPMI2.0 standard specification chapter 42. (*2) Please refer IPMI2.0 standard specification chapter 42 and SDR setting in BMC function specifica					

Event Log

In MegaRAC GUI, this page displays the list of event logs occurred by the different sensors on this device. Double click on a record to see the details of that entry. You can use the

sensor type or sensor name filter options to view those specific events or you can also sort the list of entries by clicking on any of the column headers.

To open the Event Log page, click **Server Health** > **Event Log** from the top menu. A sample screenshot of the Event Log page is shown as follows.

		aurini	1(Administrator)	Refresh	Print	Log
ver Health Configuratio	on Remote Control	Maintenance	Firmware U	pdate		H
ed here. Double-click on a rec	cord to see the description					
▼ filter by: All Se	ensors 🔻		Event L	og: 13 event e	entries, <mark>1</mark> p	age(s
JTC Offset: (GMT+05:00)			<<	< 1	>	>>
verity) Conner Name)	Concer Time	Description				
Power Unit	Power Unit	Power Off / Pov		erted		
Button	Button / Switch	Power Button F	Pressed - Asse	rted		
CATERR	Processor	IERR - Asserte	d			
5007 F		System Firmwa	are Error No sv	stem memory	is physic	allv
		Save Ever	nt Loas	Clear All	Event Lo	as
			Save Ever	Save Event Logs	Save Event Logs Clear All	Save Event Logs Clear All Event Lo

Figure 3-14. Event Log Page

Save Event Logs

Note:

The size of event log is 909 records for maximum and $909 \times 75\% = 681$ records for almost full. The status LED blinks with color amber when the event logs reach almost full. It stops recording new events when full.

You could click on **Save Event Logs** button to save your system's event logs.



The Event Log page consists of the following fields.

Ітем	DESCRIPTION
Event Log Category	 The category options: All Events, System Event Records, BIOS Generated Events, SMI Handler Events, System Management Software Events, System Software - OEM Events, Remote Console Software Events, Terminal Mode Remote Console Software Events.
Filter Type	 Filtering can be done with the sensors mentioned in the list. Once the Event Log category and Filter type are selected, the list of events will be displayed with: Event ID Time Stamp Sensor Type Sensor Name Description
BMC Timezone	BMC UTC offset timestamp value of the events.
Client Timezone	Events of client UTC offset timestamp.
UTC Offse	Displays the current UTC Offset value based on which event Time Stamps will be updated. Navigational arrows can be used to selectively access different pages of the Event Log.
Clear All Event Logs	Deletes all the existing records for all the sensors.
Save Event Logs	To save all the existing Event Log records.

Procedure:

- 1. Select the event categories from the **Event Log Category** drop-down menu.
- 2. Select the sensor name filter to view the event for the selected filter from the **Filter Type** drop-down list.
- 3. Select either **BMC Timezone** or **Client Timezone**. The list of events is listed.
- 4. Click the **Clear All Event Logs** button to clear all events from the list.
- 5. To save all the existing event logs, click on **Save Event Logs** button.

SEL Severity

The Event Log page specifies the severity of the SEL to identify the event severity code as follows:

- ①: Severity Information
- 🔼: Severity Warning
- 🔞: Severity Critical

• @: Severity Unspecified

Configuration Group

Configuration Group page allows to access various configuration settings. A screenshot of the Configuration Group menu is shown in the following figure:

					admin	(Administrator)	Refresh	Print	Logou	
ashboard	Server Informa	tion Server Health	Configuration	Remote Control	Maintenance	Firmware L	Jpdate		HEL	
			Active Directory	1						
Active [Directory Se	ettings	DNS							
			LDAP/E-Directo	iry						
The 'Active Di	irectory is currently	disabled. To enable Active	Mouse Mode	eits settings. Clic	k on 'Advanced Sei	tings' button	Adv	anced Si	ettings	
The Floave Di	in colory to currently (Network	, no obtaingo. One	a on maraneou ou	ango button.				
The list below	w shows the current	list of configured Role Gr	o LAN Port	o delete or modify	p delete or modify a role group, select the name from the list and click Delete Ro					
Group or Moo	dify Role Group. To a	add a new Role Group, se	PEF	pt and click Add R	ole Group.					
			RADIUS			Numb	er of configur	ed Role g	roups: 0	
Role Group	ID Δ G	roup Name 🔺	Remote Session	n pup Domain 🔺		G	roup Privileg	e 🛆		
1		~	Services	~			~			
2		~	SMTP	~			~			
3		~		~			~			
4		~	SOL	~			~			
5		~	SSL	~			~			
			Users				_		_	
			Virtual Media	Add R	ole Group N	odify Role Gro	up Del	ete Role (Group	

Figure 3-15. Configuration Group Menu

A detailed description of the Configuration menu is given in the following sections.

Active Directory

An active directory is a directory structure used on Microsoft Windows-based computers and servers to store information and data about networks and domains. An active directory (sometimes referred to as an AD) does a variety of functions including the ability to provide information on objects, helps organize these objects for easy retrieval and access, allows access by end users and administrators and allows the administrator to set up security for the directory.

This page in MegaRAC SP-X, allows you to configure Active Directory Server Settings.

To open Active Directory Settings page, click on **Configuration** > **Active Directory** from the main menu. A sample screenshot of Active Directory Settings Page is shown in the screenshot below.

					ad	min(Administrator)	Refresh	n Print	Logout
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenand	e Firmware	Update		HELF
Active E	irectory Settin	igs							
The 'Active Di	rectory' is currently disabl	ed. To enable Active	e Directory and conf	igure its settings. Clicl	k on 'Advanced	Settings' button.	1	Advanced S	ettings
The list below Group or Mod	/ shows the current list of ify Role Group. To add a	configured Role G new Role Group, se	roups. If you would I elect an unconfigure	ike to delete or modify ed slot and click Add Ro	a role group, s ole Group.	elect the name fro Num	om the list a ber of config	nd click Dele gured Role g	ete Role roups: 0
Role Group	D 🛆 Group I	lame ∆		Group Domain 🔺		(Group Privil	ege ∆	
1	-			~			~		
2				~			~		
3		u l		~			~		
4	-	v		~			~		
5	-	-		~			~		

Figure 3-16. Active Directory Settings Page

Table 10: Active Directory Settings Page

Ітем	DESCRIPTION
Advanced Settings	This option is used to configure Active Directory Advanced Settings. Options are: Enable Active Directory Authentication, User Domain name, Time Out and
	up to three Domain Controller Server Addresses.
Role Group ID	The ID that identifies the role group in the Active Directory.
Group Name	 This name identifies the role group in Active Directory. Note: Role Group Name is a string of 64 alpha-numeric characters. Special symbols (hyphen and underscore) are allowed.
Group Domain	 The domain where the role group is located. Note: Domain Name is a string of 255 alpha-numeric characters. Special symbols (hyphen and underscore) and dot are allowed.
Group Privilege	The level of privilege to assign this role group.
Add Role Group	To add a new role group to the device.
Modify Role Group	To modify that role group. Alternatively, double click on the configured slot.
Delete Role Group	To delete an existing Role Group.

Procedure:

Entering the details in Advanced Active Directory Settings Page

1. Click on Advanced Settings to open the Advanced Active Directory Settings Page.

Advanced Active Directory Settings		X
Active Directory Authentication Secret Username Secret Password User Domain Name	Enable]]
Domain Controller Server Address1 Domain Controller Server Address2 Domain Controller Server Address3]]
		Save Cancel

Figure 3-17. Advanced Active Directory Settings Page

2. In the Active Directory Settings page, select or unselect the Enable check box to enable or disable Active Directory Authentication respectively..

Note:

If you have enabled Active Directory Authentication, enter the required information to access the Active Directory server.

3. Specify the Secret user name and password in the Secret User Name and Secret Password fields respectively.

Note:

Enter the required information to access the Active Directory server if Active Directory Authentication enabled.

- Secret username/password for AD is not mandatory. if the AD's secret username/password is not provided, AD should be kept in the last location in PAM order.

- User Name is a string of 1 to 64 alpha-numeric characters.
- It must start with an alphabetical character.
- It is case-sensitive.

- Special characters like comma, period, colon, semicolon, slash, backslash, square brackets, angle brackets, pipe, equal, plus, asterisk, question mark, ampersand, double quotes, space are not allowed.

- Password must be at least 6 character long and will not allow more than 127 characters.
- White space is not allowed.
- 4. Specify the Domain Name for the user in the **User Domain Name** field. e.g. MyDomain.com.
- 5. Specify the time (in seconds) to wait for Active Directory queries to complete in the **Time Out** field.

- Default Time out value: 120 seconds.
- Range from 15 to 300 allowed.
- 6. Configure IP addresses in **Domain Controller Server Address1**, **Domain Control-Ier Server Address2** & **Domain Controller Server Address3**.

Note:

IP address of Active Directory server: At least one Domain Controller Server Address must be configured.

- IP Address made of 4 numbers separated by dots as in "xxx.xxx.xxx.xxx".
- Each number ranges from 0 to 255.
- First number must not be 0.

Domain Controller Server Addresses will support IPv4 Address format and IPv6 Address format.

- 7. Click **Save** to save the settings and return to Active Directory Settings Page.
- 8. Click **Cancel** to cancel the entry and return to Active Directory Settings Page.

To add a new Role Group

1. Select a blank row and click **Add Role Group** in the Active Directory Settings Page to open the Add Role Group Page as shown in the screenshot below.

Add Role Group		X
Role Group Name Role Group Domain		
Role Group Privilege	Administrator -	
Extended Privileges	KVM VMedia	
	A	id Cancel

Figure 3-18. Add Role Group Page

2. Enter the name that identifies the role group in the Active Directory from the **Role Group Name** field.

Note:

- Role Group Name is a string of 255 alpha-numeric characters.
- Special symbols hyphen and underscore are allowed.
- 3. Enter the domain where the role group is located in the Role Group Domain field.

Note:

- Domain Name is a string of 255 alpha-numeric characters.
- Special symbols hyphen, underscore and dot are allowed.
- 4. Enter the level of privilege to assign this role group in the **Role Group Privilege** field.

- 5. Select the required options (KVM or VMedia) in the Extended Privilege.
- 6. Click **Add** to save the new role group and return to the Role Group List.
- 7. Click **Cancel** to cancel the settings and return to the Role Group List.

To modify a Role Group

- 1. Select the row or double click the row that you would like to modify and click **Modify Role Group** in the Advanced Directory Settings Page.
- 2. Make the necessary changes and click **Save**.

To delete a Role Group

Select the row to delete and click **Delete Role Group**, in the Advanced Directory Settings Page.

DNS

The **Domain Name System (DNS)** is a distributed hierarchical naming system for computers, services, or any resource connected to the Internet or a private network. It associates the information with domain names assigned to each of the participants. Most importantly, it translates domain names meaningful to humans into the numerical (binary) identifiers associated with networking equipment for the purpose of locating and addressing these devices worldwide.

In Mega-RAC GUI, the DNS Server settings page is used to manage the DNS settings of a device.

In DNS Server Settings page, you can click **Configuration** > **DNS** from the main menu. A DNS Server Settings Page is shown in the screenshot below.

					admin(A	dministrator)	Refresh	Print	Logout
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmware	Update		HELP
DNS Se	rver Settings								-
Manage DNS	settings of the device.								
Domain Nan DNS Ser	ne Service Configuratio rvice	n IZ E	nable						
Multicast DN mDNS S	IS ettings	Ē	nable						
Host Config	uration								
Host Set	ttings	Auton	natic	•					
Host Na	me	QCT2	C600C83FD0C	_					
Register BM	с								
bond0		Re @	gister BMC Nsupdate O D	HCP Client FQDN	O Hostname				
Domain Nan	e Configuration								
Domain	Settings	bond0	_v4	•					
Domain	Name	gate20	04.local	_					
Domain Nan	e Server Configuration	1							
DNS Ser	rver Settings	bond	•	•					
IP Prior	ity	IPv	4 O IPv6						
DNS Ser	rver1	168.95	5.1.1	_					
DNS Ser	rver2	10.10.	10.204	_					

Figure 3-19. DNS Server Settings Page

The fields of DNS Server Settings page are explained below.

Table 11:	DNS	Server	Settings	Page
-----------	-----	--------	----------	------

Ітем		DESCRIPTION	
Domain Name Service Configuratio N	DNS Service	To enable/disable all the DNS Service Configurations.	
MULTICAST DNS SUPPORT	mDNS Settings	To enable/disable the mDNS Support Configurations.	
	Host Settings	Choose either Automatic or Manual settings.	
		It displays hostname of the device. If the Host setting is chosen as Man- ual, then specify the hostname of the device.	
HOST CONFIGURATION	Host Name	Note: - Value ranges from 1 to 64 alpha-numeric characters. - Special characters '-'(hyphen) and '_'(underscore) are allowed. - It must not start or end with a '-'(hyphen). IE browsers won't work correctly if any part of the host name contain underscore (_) character.	

	Ітем	DESCRIPTION
REGISTER BMC		To enable/disable Register BMC.
	TSIG Authentica- tion	To enable/disable TSIG authentication while registering in DNS via Direct Dynamic DNS.
TSIG Configuratio	Current TSIG Pri- vate File	The information of Current TSIG private file along with its up¬loaded date/time will be displayed (read only).
N	New TSIG Private File	Browse and navigate to the TSIG private file. Note: TSIG file should be of private type.
Domain Settings		It lists the option for domain interface as Manual, v4 or v6 for multiLAN channels.
Domain Name Configuratio		Note: If you choose DHCP, then select v4 or v6 for DHCP servers.
N	Domain Name	It displays the domain name of the device. If the Domain setting is cho- sen as Manual, then specify the domain name of the device. If you chose Automatic, the Domain Name cannot be configured as it will be done automatically. The field will be disabled.
	DNS Server Settings	It lists the option for DNS settings for the device, Manual and available LAN interfaces. If you choose Manual setting, you have to configure the DNS Server IP addresses. If you have chosen DHCP, then you have to select the interface from which the IP address is to be received.
	IP Priority	If IP Priority is IPv4, it will have 2 IPv4 DNS servers and 1 IPv6 DNS server. If IP Priority is IPv6, it will have 2 IPv6 DNS servers and 1 IPv4 DNS server. Note: It is not applicable for Manual configuration.
Domain Name Server Con- Figuration	DNS Server1, DNS Server2, and DNS Server3	 Specify the DNS (Domain Name System) server address to be configured for the BMC. IPv4 Address made of 4 numbers separated by dots as in "xxx.xxx.xxx.xxx". Each number ranges from 0 to 255. First number must not be 0. DNS Server Address will support the following: IPv4 Address format. IPv6 Address format. IPv6 Address format. If IP Priority is IPv4 then DNS Server1, DNS Server2 will be IPv4 and DNS Server3 will be IPv6. If IP Priority is IPv6 then DNS Server1, DNS Server2 will be IPv6 and DNS Server3 will be IPv4. If no IP, DNS Server field will be empty.
SAVE		To save the entered changes.
Reset		To reset the entered changes.

Table 11: DNS Server Settings Page (Continued)

Procedure:

- 1. In Domain Name Service Configuration, Enable DNS Service.
 - Check the option **Enable** to enable all the DNS Service Configurations.
- 2. Choose the Host Configuration either Automatic or Manual.

If you choose Automatic, you need not enter the Host Name and if you choose Manual, you need to enter the Host Name.

- 3. Enter the Host Name in the given field if you have chosen Manual Configuration.
- 4. Under **Register BMC**, choose the BMC's network port to register with DNS settings.
 - Check the option **Register BMC** to register with this DNS settings.
 - **Nsupdate** Choose **Nsupdate** option to register with DNS server using nsupdate ap-plication.
 - **DHCP Client FQDN** Choose **DHCP Client FQDN** option to register with DNS Server using DHCP option 81.
 - **Hostname** Choose **Hostname** option to register with DNS server using DHCP option 12.

Note:

Hostname option should be selected if the DHCP client FQDN option is not supported by DHCP server.

- 5. Enable TSIG Authentication in TSIG Configuration.
 - The current file name will be displayed in Current TSIG private file.
 - To view a new one, browse and navigate to the TSIG private file.
- 6. In the **Domain Name Configuration**,
 - Select the **Domain Settings** from the drop-down list.
 - Enter the **Domain Name** in the given field if the option "**Manual**" is being selected in domain settings field.
- 7. In the Domain Name Server Configuration,
 - Select the DNS Server Settings from the drop-down list.
 - In the IP Priority, set IPV4 or IPV6 as a top priority.
 - In the DNS Server1/DNS Server2/DNS Server3 field,

If the DNS Server Settings is setting to Manual mode, user needs to fill those fields with DNS IP address manually according to IPv4 or IPv6 format. Otherwise, if it is in non-Manual mode, DNS server IP address is assigned by DHCP server.

- 8. Click **Save** to save the entries.
- 9. Click **Reset** to reset the entries.

LDAP/E-Directory

The **Lightweight Directory Access Protocol (LDAP)** is an application protocol for querying and modifying data of directory services implemented in Internet Protocol (IP) networks.

In MegaRAC GUI, LDAP is an Internet protocol that MegaRAC[®] card can use to authenticate users. If you have an LDAP server configured on your network, you can use it as an easy way to add, manage and authenticate MegaRAC[®] card users. This is done by passing login requests to your LDAP Server. This means that there is no need to define an additional authentication mechanism, when using the MegaRAC card. Since your existing LDAP Server keeps an authentication centralized, you will always know who is accessing the network resources and can easily define the user or group-based policies to control access.

To open LDAP Settings page, click **Configuration** > **LDAP** from the main menu. A sample screenshot of LDAP Settings Page is shown in the screenshot below.

					dam	in(Administratory	Reliesh	1 1111	LUYU
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmware U	pdate		HEL
LDAP/E	-Directory Sett	ings							
LDAP/E-Direc	ctory is currently disabled.	. To enable LDAP/E-	Directory and confi	gure its settings. Click	on 'Advanced Se	ttings' button.	Ac	lvanced Se	ettings
The list below Group or Mod	v shows the current list of lify Role Group. To add a	f configured Role Gr new Role Group, se	oups. If you would lect an unconfigure	like to delete or modify ed slot and click Add R	a role group, sel ole Group.	ect the name fror	m the list an	d click Dele	ete Role
						Numb	er of configu	ired Role a	rouns: 0
									roups. o
Role Group I	ID → Group M	Name 🔺	(د Group Search Base		Gi	roup Privile	ge ∆	roups. o
Role Group I 1	ID △ Group I	Name 🛆	(لا Group Search Base		Gi	roup Privile ~	ge ⊥	ioups. o
Role Group I 1 2	ID → Group N	Name 🗅	(Group Search Base 그 ~ ~		Gi	roup Privile ~ ~	ge 🛆	
Role Group I 1 2 3	ID → Group I	Name 🗅 - -	(Group Search Base _ ~ ~ ~		Gi	roup Privileg ~ ~ ~	ge 🛆	
Role Group I 1 2 3 4	ID -> Group I	Name 🗅 V V	(Group Search Base ~ ~ ~ ~		Gi	roup Privileg ~ ~ ~ ~	ge \	
Role Group I 1 2 3 4 5	ID J Group I	Name ⊥ • • •	(Sroup Search Base 2 ~ ~ ~ ~ ~		Gi	roup Privileg ~ ~ ~ ~ ~	ge \	

Figure 3-20. LDAP Settings Page

The fields of LDAP Settings Page are explained below.

Table 12: LDAP Settings Page

Ітем	DESCRIPTION
Advanced Settings	To configure LDAP Advanced Settings. Options are Enable LDAP Authentication, IP Address, Port and Search base.
Add Role Group	To add a new role group to the device. Alternatively, double click on a free slot to add a role group.
Modify Role Group	To modify the particular role group.
Delete Role Group	To delete a role group from the list.

Procedure:

Entering the details in Advanced LDAP/E-Directory Settings Page

1. In the LDAP Settings Page, click Advanced Settings. A sample screenshot of LDAP/E-Directory Settings page is given below.

Advanced LDAP/E-Directory Settings	×
LDAP/E-Directory Authentication	✓ Enable
Encrypted Type	SSL
Common Name Type	IP Address
Server Address	
Port	389
Bind DN	
Password	
Search Base	
Attribute of User Login	cn 💌
CA Certificate File	Browse
Certificate File	Browse
Private Key	Browse
	Save Cancel

Figure 3-21. Advanced LDAP/E-Directory Settings

2. To enable/disable LDAP/E-Directory Authentication, check or uncheck the **Enable** checkbox respectively.

Note:

During login prompt, use username to login as an LDAP Group member.

3. Select the encryption type for LDAP/E-Directory from the Encrypted Type dropdown list.

Note:

Configure proper port number, when SSL is enabled.

- 4. Select the Common Name Type as IP Address.
- 5. Enter the IP address of LDAP server in the Server Address field.

Note:

- IP Address made of 4 numbers separated by dots as in 'xxx.xxx.xxx.
- Each Number ranges from 0 to 255.
- First Number must not be 0.
- Supports IPv4 Address format and IPv6 Address format.
- 6. Specify the LDAP Port in the **Port** field.

Note:

Default Port is 389. For Secure SSL connection, default port is 636. The Port value ranges from 1 to 65535.

7. Specify the **Bind DN** that is used during bind operation, which authenticates the client to the server.

- Bind DN is a string of 4 to 64 alpha-numeric characters.
- It must start with an alphabetical character.
- Special Symbols like dot(.), comma(,), hyphen(-), underscore(_), equal-to(=) are allowed.
- Example: cn=manager, ou=login, dc=domain, dc=com .
- 8. Enter the password in the **Password** field.

Note:

- Password must be at least one character long.
- White space is not allowed.
- This field will not allow more than 48 characters.
- 9. Enter the **Search Base**. The Search base tells the LDAP server which part of the external directory tree to search. The search base may be something equivalent to the organization, group of external directory.

Note:

- Search base is a string of 4 to 63 alpha-numeric characters.
- It must start with an alphabetical character.
- Special Symbols like dot (.), comma (,), hyphen(-), underscore (_), equal-to (=) are allowed.
- Example: ou=login, dc=domain, dc=com
- 10. Select **Attribute of User Login** to find the LDAP/E-Directory server which attribute should be used to identify the user.

Note:

It only supports cn or uid.

- 11. Select **CA Certificate File** from the Browse field to identify the certificate of the trusted CA certs.
- 12. Select the Certificate File to find the client certificate filename.
- 13. Select **Private Key** to find the client private key filename.

Note:

All the 3 files are required, when StartTLS is enabled.

- 14. Click **Save** to save the settings.
- 15. Click **Cancel** to cancel the modified changes.

To add a Role Group

1. Select a blank row and click **Add Role Group** to open the Add Role Group Page as shown in the screenshot below from the LDAP/E-Directory Settings Page.

Add Role Group	×
Role Group Name Role Group Domain	
Role Group Privilege	Administrator -
Extended Privileges	KVM VMedia
	Add Cancel



2. Enter the name that identifies the role group in the **Role Group Name** field.

Note:

- Role Group Name is a string of 255 alpha-numeric characters.
- Special symbols hyphen and underscore are allowed.
- 3. Enter the path from where the role group is located to Base DN in the **Role Group Search Base** field.

Note:

- Search Base is a string of 255 alpha-numeric characters.
- Special symbols hyphen, underscore and dot are allowed.
- 4. Enter the level of privilege to assign to this role group in the **Role Group Privilege** field.
- 5. Select the required options (KVM or VMedia) in the Extended Privileges option.
- 6. Click Add to save the new role group and return to the Role Group List.
- 7. Click **Cancel** to cancel the settings and return to the Role Group List.

To Modify Role Group

- 1. Select the row or double click that you would like to modify and click **Modify Role Group** in the LDAP/E-Directory Settings Page.
- 2. Make the necessary changes and click **Save**.

To Delete a Role Group

Select the row that you wish to delete and click on **Delete Role Group** in the LDAP/ E-Directory Settings Page.

Mouse Mode

In MegaRAC GUI, Redirection Console handles mouse emulation from local window to remote screen in either of two methods. User has to be an Administrator to configure this option. To open Mouse Mode page, click **Configuration > Mouse Mode** from the main

menu. A sample screenshot of Mouse Mode Settings Page is shown in the screenshot below.



Figure 3-23. Mouse Mode Settings Page

The fields of Mouse Mode Settings page are explained below.

Table 13: Mouse Mode Settings Pa	qe
----------------------------------	----

Ітем	DESCRIPTION
Absolute Mode	The absolute position of the local mouse is sent to the server.
Relative Mode	Relative mode sends the calculated relative mouse position displace- ment to the server.
Other Mode	For the Host OS which is neither Absolute Mode nor Relative Mode.
Save	To save any changes made.
Reset	To Reset the modified changes.

Procedure:

- 1. Choose either of the following as your requirement:
 - Set mode to Absolute

Note:

Applicable for all Windows versions; RHEL Linux versions not below than RHEL6; Fedora Linux versions not below than FC14.

• Set mode to Relative

Note:

Applicable for RHEL Linux versions below than RHEL6; Fedora Linux versions below than FC14; SLES Linux versions below than SLES11.

• Set mode to Other

Applicable for SLES Linux version SLES11.

- 2. Click **Save** button to save the changes made.
- 3. Click **Reset** to reset the modified changes.

Network

In MegaRAC GUI, the Network Settings Page is used to configure the network settings for the available LAN channels.

To open Network Settings page, click **Configuration > Network** from the main menu. A sample screenshot of Network Settings Page is shown in the screenshot below.

					admin(Administ	rator) F	Refresh	Print	Logout
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmwa	ire Upda	te	HELP
Networ	k Settings								
Manage netw	vork settings of the device.	_							
LAN Inte	rface	b	ond0	•					
LAN Set	tings		Enable						
MAC Ad	dress	2	C:60:0C:83:FD:0C						
IPv4 Configu	ration								
IPv4 Set	tings		Enable						
Obtain a	n IP address automatical	lly 🔽	Use DHCP						
IPv4 Add	Iress	1	0.10.14.43						
Subnet I	Mask	2	55.255.0.0						
Default	Gateway	1	0.10.10.204						
IDv6 Configu	ration								
IDv6 Configu	tinge	5							
iPv0 Set	unyo	14	Enable						
Obtain a	n IP address automatical	lly 🔽	Use DHCP						
IPv6 Add	Iress	Г							-

Figure 3-24. Network Settings Page

The fields of Network Settings page are explained below.

Ітем	DESCRIPTION				
LAN Interface	Lists the LAN interfaces.				
LAN Settings	To enable or disable the LAN Settings.				
MAC Address	This field displays the MAC Address of the device. This is a read only field.				
IPv4 Settings	 This option lists the IPv4 configuration settings. Obtain IP Address automatically: This option is to dynamically configure IPv4 address using DHCP (Dynamic Host Configuration Protocol). IPv4 Address, Subnet Mask, and Default Gateway: These fields are for specifying the static IPv4 address, Subnet Mask and Default Gateway to be configured to the device. 				
	 Note: IP Address made of 4 numbers separated by dots as in "xxx.xxx.xxx.xxx". Each Number ranges from 0 to 255. 				
IPv6 Configuration	 This option lists the following IPv6 configuration settings. IPv6 Settings: This option is to enable the IPv6 settings in the device. Obtain an IPv6 address automatically: This option is to dynamically configure IPv6 address using DHCP (Dynamic Host Configuration Protocol). IPv6 Address: To specify a static IPv6 address to be configured to the device. Eg: 2004:2010 Subnet prefix length: To specify the subnet prefix length for the IPv6 settings. Note: Value ranges from 0 to 128. Default Gateway: Specify v6 default gateway for the IPv6 settings. Reserved IPv6 Address: Some IPv6 addresses are reserved by IETF. List is showed as below, so when users set these Blocking IPv6 addresses, WebUI will pop-up warning message. 				
VLAN Configuration	 It lists the VLAN configuration settings. VLAN Settings: To enable/disable the VLAN support for selected interface. VLAN ID: The Identification for VLAN configuration. Value ranges from 2 to 4094. VLAN Priority: The priority for VLAN configuration. Value ranges from 0 to 7. 7 is the highest priority for VLAN. 				
Save	To save the entries.				
Reset	To Reset the modified changes.				

Table 14: Network Settings Page

lable 15: Reserve	ed IPv6 Address	
IPv6 Prefix	ALLOCATION	Reference
0000::/8	Reserved by IETF	[RFC4291]
0100::/8	Reserved by IETF	[RFC4291]
0200::/7	Reserved by IETF	[RFC4048]
0400::/6	Reserved by IETF	[RFC4291]
0800::/5	Reserved by IETF	[RFC4291]
1000::/4	Reserved by IETF	[RFC4291]
4000::/3	Reserved by IETF	[RFC4291]
6000::/3	Reserved by IETF	[RFC4291]
8000::/3	Reserved by IETF	[RFC4291]
a000::/3	Reserved by IETF	[RFC4291]
c000::/3	Reserved by IETF	[RFC4291]

[4291] [4291] [4291] [4291] e000::/4 **Reserved by IETF** [RFC4291] f000::/5 Reserved by IETF [RFC4291] f800::/6 Reserved by IETF [RFC4291] fe00::/9 Reserved by IETF [RFC4291] fe80::/10 Link-Scoped Unicast [RFC4291] fec0::/10 **Reserved by IETF** [RFC3879] ff00::/8 Multicast [RFC4291] 2001::/32 Reserved by IETF [RFC4380]

Procedure

- 1. Select the LAN Interface from the drop down list.
- 2. Check Enable to enable the LAN Settings.
- 3. In IPv4 Configuration, enable Use DHCP to Obtain an IP address automatically to dynamically configure IPv4 address using DHCP.
- 4. If the field is disabled, enter the IPv4 Address, Subnet Mask and Default Gateway in the respective fields.
- 5. In IPv6 Configuration, if you wish to enable the IPv6 settings, check **Enable**.
- 6. If the IPv6 setting is enabled, enable or disable the option Use DHCP for obtaining the IP address automatically.
- 7. If the field is disabled, enter the IPv6 Address, Subnet Prefix length and Default **Gateway** in the given field.
- 8. In VLAN Configuration, if you wish to enable the VLAN settings, check **Enable**.
- 9. Enter the VLAN ID in the specified field.
- 10. Enter the VLAN Priority in the specified field.
- 11. Click **Save** to save the entries.

PEF

Platform Event Filtering (PEF) provides a mechanism for configuring the BMC to take selected actions on event messages that it receives or has internally generated. These actions include operations such as system power-off, system reset, as well as triggering the generation of an alert.

In MegaRAC GUI, the PEF Management is used to configure the following:

- Event Filter
- Alert Policy
- LAN Destination

To open PEF Management Settings page, click **Configurations** > **PEF** from the main menu. A sample screenshot of PEF Management Settings Page is shown in the screen shot below. Each tab is explained below.

Event Filter Tab

A PEF implementation is recommended to provide at least 16 entries in the event filter table. A subset of these entries should be pre-configured for common system failure events, such as over-temperature, power system failure, fan failure events, etc. Remaining entries can be made available for 'OEM' or System Management Software configured events. Note that individual entries can be tagged as being reserved for system use - so this ratio of pre-configured entries to run-time configurable entries can be reallocated if necessary.

					admin(Administr	rator) Refresh P	rint Logout
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmware Update	HELP
PEF Mar Use this page a new entry, s	nagement e to configure Event Filter, elect an unconfigured slo	Alert Policy and LA t and click "Add".	N Destination. To (delete or modify a entry,	select it in the list	and click "Delete" or "Mo	odify". To add
Event	Filter Alert	Policy	AN Destination			Configured Event Filte	er count: 15
PEF ID	스 Filter Configuratio	on 스 Ev	ent Filter Action	ے Event Se	everity 🔺	Sensor Name	<u>م</u> د
1	Enabled		[Alert]	Unsp	ecified	Any	
2	Enabled		[Alert]	Unsp	ecified	Any	
3	Enabled		[Alert]	Unsp	ecified	Any	
4	Enabled		[Alert]	Unsp	ecified	Any	
5	Enabled		[Alert]	Unsp	ecified	Any	
6	Enabled		[Alert]	Unsp	ecified	Any	
7	Enabled		[Alert]	Unsp	ecified	Any	
8	Enabled		[Alert]	Unsp	ecified	Any	
9	Enabled		[Alert]	Unsp	ecified	Any	_
						Add Modify	Delete

Figure 3-25. PEF Management – Event Filter

The fields of PEF Management – Event Filter Tab are explained below.

This page contains the list of configured PEF's.

Table 16: PET Management - Event Filter

Ітем	DESCRIPTION
PEF ID	This field displays the ID for the newly configured PEF entry (read-only).
Filter configuration	Check box to enable the PEF settings.
Event Filter Action	Check box to enable PEF Alert action. This is a mandatory field.
Event Severity	To choose any one of the Event severity from the list.
Sensor Name	To choose the particular sensor from the sensor list.
Add	To add the new event filter entry and return to Event filter list.
Modify	To modify the existing entries.
Delete	To delete Event filter list.

Procedure:

- 1. Click the **Event Filter** Tab to configure the event filters in the available slots.
- 2. To Add an Event Filter entry, select a free slot and click **Add** or alternatively double click the empty slot to open the Add event Filter entry Page. A sample screenshot of Add Event Filter Page is shown below.

Add Event Filter entry		X
Event Filter Configuration		_
PEF ID	16	
Filter Configuration	Enable	
Event Severity	Unspecified 💌	
ene a comencia de		•
		Add Cancel

Figure 3-26. Add Event Filter Entry Page

- 3. In the Event Filter Configuration section,
 - **PEF ID** displays the ID for configured PEF entry (read-only).
 - In Filter Configuration, check the box to enable the PEF settings.
 - In **Event Severity**, select any one of the Event severity from the list.
- 4. In the Filter Action configuration section,
 - Event Filter Action is a mandatory field and checked by default, which enable PEF Alert action (read-only).

- Select any one of the Power action either Power down, Power reset or Power cycle from the drop down list
- Choose any one of the configured alert policy number from the drop down list.

Alert Policy has to be configured - under **Configuration** -> **PEF** -> **Alert Policy**.

- 5. In the Generator ID configuration section,
 - Check **Generator ID Data** option to fill the Generator ID with raw data.
 - **Generator ID 1** field is used to give raw generator ID1 data value.
 - Generator ID 2 field is used to give raw generator ID2 data value.

Note:

In **RAW** data field, specify hexadecimal value prefix with '0x'.

- In the **Event Generator** section, choose the event generator as Slave Address if event was generated from IPMB. Otherwise as System Software ID if event was generated from sys-tem software.
- In the **Slave Address/Software ID** field, specify corresponding I2C Slave Address or System Software ID.
- Choose the particular **Channel Number** that event message was received over. Or choose '0' if the event message was received via the system interface, primary IPMB, or internally generated by the BMC.
- Choose the corresponding IPMB Device LUN if event generated by IPMB.
- 6. In the Sensor configuration section,
 - Select the sensor type of sensor that will trigger the event filter action.
 - In the sensor name field, choose the particular sensor from the sensor list.
 - Choose event option to be either All Events or Sensor Specific Events.
- 7. In the Event Data configuration section,
 - Event Trigger field is used to give Event/Reading type value.

Note:

Value ranges from 1 to 255.

• Event Data 1 AND Mask field is used to indicate wildcarded or compared bits.

Note:

Value ranges from 0 to 255.

• Event Data 1 Compare 1 & Event Data 1 Compare 2 field is used to indicate whether each bit position's comparison is an exact comparison or not.

Value ranges from 0 to 255.

- 8. In the Event Data 2 Configuration section,
 - Event Data 2 AND Mask field is similar to Event Data 1 AND Mask.
 - Event Data 2 Compare 1 & Event Data 2 Compare 2 fields are similar to Event Data 1 Compare 1 and Event Data 1 Compare 2 respectively.
- 9. In the Event Data 3 Configuration section,
 - Event Data 3 AND Mask field is similar to Event Data 1 AND Mask.
 - Event Data 3 Compare 1 & Event Data 3 Compare 2 fields are similar to Event Data 1 Compare 1 and Event Data 1 Compare 2 respectively.

10. Click on Add to save the modification and return to Event filter list.

- 11. Click on **Cancel** to cancel the modification and return to Event filter list.
- 12. In the **Event filter list**, select the configured slot and click **Modify** or alternatively double click the configured slot to modify the existing event filter entry.
- 13. In the Event filter list, click Delete to delete the existing filter.

Alert Policy Tab

This page is used to configure the Alert Policy and LAN destination. You can add, delete or modify an entry in this page.

					admin(Admini	istrator)	Refresh	Print	Logo
hboard Server	r Information	Server Health Con	nfiguration Re	emote Control	Maintenance	Firmwa	are Update		HE
EF Manager	nent								
e this page to confi <u>c</u> w entry, select an un	ure Event Filter, A configured slot an	lert Policy and LAN Dest nd click "Add".	tination. To delete	or modify a entry,	select it in the list	and click	"Delete" or "M	odify". To	add a
Event Filter	Alert Po	olicy LAN De	stination						
						Config	gured Alert Po	olicy cou	nt: 15
Policy Entry # \ P	olicy Number \	Policy Configuration	\ Pr	licy Set	Channel	Config	Jured Alert Po	olicy cou	nt: 15
Policy Entry # 스 P 1	'olicy Number → 1	Policy Configuration	Always send a	olicy Set ⊃ Ilert to this destina	Channel I	Confi <u>c</u> Number 1	gured Alert Po → Destinatio	olicy cou n Selecto 0	nt: 15
Policy Entry # 스 P	lolicy Number 스 1 2	Policy Configuration A Disabled Disabled	Always send a Always send a	blicy Set 그 Ilert to this destina Ilert to this destina	Channel I ation	Config Number 1	gured Alert Po	olicy cou n Selecto 0 0	nt: 15
Policy Entry # 스 P 1 2 3	Nolicy Number 스 1 2 3	Policy Configuration Disabled Disabled Disabled	Always send a Always send a Always send a Always send a	olicy Set 스 alert to this destina alert to this destina alert to this destina	Channel I ation ation	Config Number 1 1	gured Alert Po → Destination	olicy cou n Selecto 0 0 0	nt: 15
Policy Entry # → P 1 2 3 4	lolicy Number △ 1 2 3 4	Policy Configuration Disabled Disabled Disabled Disabled Disabled	Always send a Always send a Always send a Always send a Always send a	Dicy Set ⊃ Ilert to this destina Ilert to this destina Ilert to this destina Ilert to this destina	Channel I ation ation ation ation	Config Number 1 1 1	gured Alert Po → Destination	olicy cou o Selecto o o o o	nt: 15
Policy Entry # △ P 1 2 3 4 5	loficy Number ⊥ 1 2 3 4 5	Policy Configuration Disabled Disabled Disabled Disabled Disabled	Always send a Always send a Always send a Always send a Always send a Always send a	Dicy Set ⊃ Ilert to this destina Ilert to this destina Ilert to this destina Ilert to this destina Ilert to this destina	Channel I ation ation ation ation	Config Number 1 1 1 1	J Destination	n Selecto 0 0 0 0 0	nt: 15
Policy Entry # → P 1 2 3 4 5 6	lolicy Number ⊥ 1 2 3 4 5 6	Policy Configuration Disabled Disabled Disabled Disabled Disabled Disabled	Always send a Always send a Always send a Always send a Always send a Always send a Always send a	Nicy Set 스 Ilert to this destina Ilert to this destina Ilert to this destina Ilert to this destina Ilert to this destina	Channel I ation ation ation ation ation	Config Number 1 1 1 1 1 1	Jured Alert Po	n Selecto 0 0 0 0 0 0 0 0	nt: 15
Policy Entry # → P 1 2 3 4 5 6 7	00licy Number △ 1 2 3 4 5 6 7	Policy Configuration Disabled Disabled Disabled Disabled Disabled Disabled Disabled	Always send a Always send a Always send a Always send a Always send a Always send a Always send a	Dicy Set → Ilert to this destina Ilert to this destina	Channel I ation ation ation ation ation ation	Config Number 1 1 1 1 1 1 1	ured Alert Po	n Selecto 0 0 0 0 0 0 0 0 0	nt: 15
Policy Entry # → P 1 2 3 4 5 6 7 8	00licy Number △ 1 2 3 4 5 6 7 8	Policy Configuration 3 Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled	Always send a Always send a	Dicy Set alert to this destination alert to this destination	Channel I ation ation ation ation ation ation ation ation	Config Number 1 1 1 1 1 1 1 1	ured Alert Po	n Selecto 0 0 0 0 0 0 0 0 0 0 0 0	nt: 15

Figure 3-27. PEF Management – Alert Policy

The fields of the PEF Management – Alert Policy Tabs are explained below.

Ітем	DESCRIPTION			
Policy Entry #	Displays Policy entry number for the newly configured entry (read- only).			
Policy Number	Displays the Policy number of the configuration.			
Policy Configuration	To enable or disable the policy settings.			
Policy Set	 To choose any one of the Policy set values from the list. O: Always send alert to this destination. 1: If alert to previous destination was successful, do not send alert to this destination. Proceed to next entry in this policy set. 2: If alert to previous destination was successful, do not send alert to this destination. Do not process any more entries in this policy set. 3: If alert to previous destination was successful, do not send alert to this destination. Proceed to next entry in this policy set. 3: If alert to previous destination was successful, do not send alert to this destination. Proceed to next entry in this policy set that is to a different channel. 4: If alert to previous destination was successful, do not send alert to this destination. Proceed to next entry in this policy set that is to a different channel. 			
Channel Number	To choose a particular channel from the available channel list.			
Destination Selector	To choose a particular destination from the configured destination list. Note: LAN Destination has to be configured - under Configuration -> PEF -> LAN Destination .			
Modify	To modify the existing entries.			
Delete	To delete Alert Policy list.			

Table 17: PEF Management - Alert Policy

Procedure:

- 1. In the Alert Policy Tab, select the slot for which you have to configure the Alert policy. That is, In the **Event Filter Entry Page**, if you have chosen Alert Policy number as 4, you have to configure the 4th slot (the slot with Policy Number 4) in the Alert Policy Tab.
- 2. Double click the slot and click **Add** to open the **Add Alert Policy Entry Page** as shown in the screenshot below.

Add Alert Policy entry	
Policy Entry #	3
Policy Number	1
Policy Configuration	Enable
Policy Set	0
Channel Number	1 💌
Destination Selector	1
Alert String	Event Specific
Alert String Key	0
	Add Cancel

Figure 3-28. Add Alert Policy Entry Page

- 3. Policy Entry # is a read-only field.
- 4. Select the Policy Number from the list.
- 5. In the **Policy Configuration** field, check **Enable** if you wish to enable the policy settings.
- 6. In the Policy Set field, choose any of the Policy set from the list.
- 7. In the **Channel Number field**, choose particular channel from the available channel list.
- 8. In the **Destination Selector field**, choose particular destination from the configured destination list.

LAN Destination has to be configured under **Configuration** -> **PEF** -> **LAN Destination**. That is if you select the number 4 for destination selector in Alert Policy Entry page, then you have to configure the 4th slot (LAN Destination Number 4) in the LAN Destination tab.

- 9. In the **Alert String field**, enable the check box if the Alert policy entry is Event Specific.
- 10. In the **Alert String Key** field, choose any one value that is used to look up the Alert String to send for this Alert Policy entry.
- 11. Click Add to save the new alert policy and return to Alert Policy list.
- 12. Click Cancel to cancel the modification and return to Alert Policy list.
- 13. In the **Alert Policy Page**, to modify a configuration, select the slot to be modified and click **Modify**.
- 14. In the Alert Policy Page, to delete a configuration, select the slot and click Delete.

PEF Management LAN Destination Page

This page is used to configure the Event filter, Alert Policy and LAN destination. A sample screenshot of PEF Management LAN Destination Page is given below.

				admin(Adminis	strator)	Refresh	Print	Logout
Dashboard Server Info	ormation Server He	alth Configuration	Remote Control	Maintenance	Firmwa	re Update		HELF
PEF Managemen Use this page to configure I a new entry, select an unco	nt Event Filter, Alert Policy a nfigured slot and click "A	nd LAN Destination. To d dd".	elete or modify a entry,	select it in the list a	and click "[Delete" or "M	lodify". To	add
Event Filter	Alert Policy	LAN Destination						
LAN Channel: 1	Doctingti			Con	figured L	AN Destinati	ion count	:0
LAN Desunation -	Desunau	on type 🔺		Desunation Ad	aless 1	6		-
	,	*:		~				
2		18		ĩ				
3		•		~				
4		74 		~				
5	3	•		~				
6		•		~				
7	6			~				
8		• <u></u>		~				
9				~				-
10			St	end Test Alert	Add	Modify	Delete	

Figure 3-29. PEF Management - LAN Destination

The fields of PEF Management – LAN Destination Tab are explained below.

Table 18: PEF Management - LAN Destination

Ітем	DESCRIPTION
LAN Channel Number	Displays LAN Channel Number for the selected slot (read-only).
LAN Destination	Displays Destination number for the newly configured entry (read-only).
Destination Type	Destination type can be either an SNMP Trap or an Email alert. For Email alerts, the 3 fields – Username, Subject and body of the mes- sage needs to be filled. The SMTP server information also has to be added - under Configuration -> SMTP . For SNMP Trap, only the destination IP address has to be filled.
Destination Address	 If Destination type is SNMP Trap, then enter the IP address of the system that will receive the alert. Destination address will support the following: IPv4 address format. IPv6 address format.

Table 18: PEF Management - LAN Destination (Continued)

Procedure:

Delete

1. In the **LAN Destination Tab**, choose the slot to be configured. This should be the same slot that you have selected in the Alert Policy Entry- Destination Selector field. That is if you have chosen the Destination Selector as 4 in the Alert Policy Entry page of Alert Policy Tab, then you have to configure the 4th slot of LAN Destination Page.

To delete the selected configured LAN destination.

2. Double click on the slot and click Add. This opens the Add LAN Destination entry.

Add LAN Destination entry			X
LAN Channel Number	1		
LAN Destination	1		
Destination Type	Snmp Trap	•	
Destination Address			
Username		*	
Subject			
Message			
			Add Cancel

Figure 3-30. Add LAN Destination entry Page

3. In the **LAN Channel Number** field, the LAN Channel Number for the selected slot is displayed and this is a read-only field.

- 4. In the **LAN Destination** field, the destination for the newly configured entry is displayed and this is a read-only field.
- 5. In the **Destination Type** field, select the one of the types.
- 6. In the **Destination Address** field, enter the destination address.

If Destination type is Email Alert, then give the email address that will receive the email.

- 7. Select the **User Name** from the list of users.
- 8. In the **Subject** field, enter the subject.
- 9. In the **Message** field, enter the message.
- 10. Click Add to save the new LAN destination and return to LAN destination list.
- 11. Click Cancel to cancel the modification and return to LAN destination list.
- 12. In the **LAN Destination Tab**, to modify a configuration, select the row to be modified and click **Modify**.
- 13. In the **LAN Destination Tab**, to delete a configuration, select the slot and click **Delete**.

RADIUS

RADIUS is a modular, high performance and feature-rich RADIUS suite including server, clients, development libraries and numerous additional RADIUS related utilities. In MegaRAC GUI, this page is used to set the RADIUS Authentication.

To open RADIUS Settings page, click **Configuration** > **RADIUS** from the main menu. A sample screenshot of RADIUS Settings Page is shown in the screenshot below.

					admin(Administrator)		Refresh	Print	Logout
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmwa	are Update		HELP
RADIUS	Settings								_ 1
The RADIUS Authentication is currently disabled. To enable RADIUS Authentication and enter the required information to access the RADIUS server. Press the Save button to save your changes. To configure the Advanced settings, RADIUS Server Advanced Settings authentication should be enabled.									
RADI	US Authentication	🗖 Enable							
Port		1812							
Serv	er Address								
Secr	et								
Exter	nded privileges	Г КУМ Г	VMedia						
es.							Sav	Res	et
									-

Figure 3-31. RADIUS Settings Page
The fields of RADIUS Settings Page are explained below.

Table	19:	RADIL	JS :	Setting	qs	Page
					_	

Ітем	DESCRIPTION
RADIUS Authentication	Option to enable RADIUS authentication.
Dert	The RADIUS Port number. Note:
Port	Default Port is 1812.
	Port value ranges from 1 to 65535.
	The IP address of RADIUS server.
Server Address	 Note: IP Address made of 4 numbers separated by dots as in "xxx.xxx.xxx.xxx". Each Number ranges from 0 to 255. First Number must not be 0.
Secret	 The Authentication Secret for RADIUS server. Note: This field will not allow more than 31 characters. Secret phrase must be at least 4 characters long. White space is not allowed.
Extended Privileges	This field is used to assign KVM and VMedia privilege for the user.
Advanced Settings	For setting the advanced features.
Save	To save the settings.
Reset	To reset the modified changes.

Procedure:

- 1. Enable the **RADIUS Authentication** checkbox to authenticate the RADIUS.
- 2. Click on **Advanced Settings** button. This opens the Radius Authorization window as shown below.
 - For Authorization Purpose, configure the Radius user with Vendor Specific Attribute in Server side.

Example:1

testadmin Auth-Type := PAP, Cleartext-Password:= "admin"

Auth-Type := PAP, Vendor-Specific="H=4"

Example:2

testoperator Auth-Type := PAP,Cleartext-Password := "operator"

Auth-Type := PAP, Vendor-Specific="H=3"

If you change the Vendor-Specific value in server then you should change the same values in this page.

3. Click **Save** to save the changes made else click **Cancel** to go back to the previous screen.

Remote Session

In MegaRAC SP, use this page to configure virtual media configuration settings for the next redirection session. Encryption is disabled by default.

To open Remote Session page, click **Configuration > Remote Session** from the main menu. A sample screenshot of Remote Session Page is shown in the screenshot below.

					admin(Admi	inistrator)	Refresh	Print	Logout
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmwa	ire Update		HELP
Configu	re Remote Ses	sion							
This page is (used to configure Remote	e Session settings							
Single Po	ort Application	Enable							
Keyboar	d Language	Auto Detect (AD)						
Retry Co	unt	3							
Retry Tin	ne Interval	10 Seconds							
🗹 Loca	I Monitor OFF Feature St	atus							
🗆 Auto	matically OFF Local Mon	itor, When JViewer	Launches						
							Save	Res	et
									-

Figure 3-32. Remote Session

The fields of Remote Session Settings Page are explained below.

Table	20:	Remote	Session	Settings	Page

Ітем	DESCRIPTION				
Single Port Application	Enable/Disable single port support by runtime. On changing this configura- tion, KVM and VMedia Sessions will be restarted. If this support is enabled, KVM session will not use its dedicated port whereas both Web and KVM ses- sions will be established only via Web Port. If this support is disabled, KVM and Web sessions will use their own dedicated ports respectively.				
KVM Encryption	Enable/Disable Encryption of KVM data for the next redirection session. If KVM Encryption is enabled, the KVM session will use the Secure port which has been configured in Configuration > Services page. If KVM Encryption is disabled, the KVM session will use the Non-Secure port which has been configured in Configuration > Services page.				
	Note:				
	This option is disabled if Single Port is enabled.				
Keyboard Languages	This option is used to select the keyboard supported languages.				
Retry Count	This option is used to retry the redirection session for certain number of attempts.				
Retry Interval	This option is used to give time interval for each attempt.				

<u> </u>			

Ітем	DESCRIPTION
Automatically OFF Local Monitor, When JViewer Launches	Enable/disable Automatically OFF Local Monitor, When JViewer Launches.
	To save the current changes.
Save	Note: It will automatically close the existing remote redirection either KVM or Vir- tual media sessions, if any.
Reset	To reset the modified changes.

Table 20: Remote Session Settings Page (Continued)

Procedure:

- 1. In **KVM encryption**, check or uncheck the option **Enable**.
- 2. Choose the **Keyboard Language** from the list of supported keyboard languages.
- 3. Enter a value in the **Retry Count** field to set the number of attempts for retrying the redirection session.
- 4. Enter a value in the **Retry Interval** field to assign time interval for each attempt.
- 5. Select the **Local Monitor OFF** check box to enable Local Monitor ON/OFF command during runtime.
- 6. Select the **Automatically OFF Local Monitor**, **When JViewer Launches** check box to automatically lock the local monitor during JViewer launch.
- 7. In **Virtual media Attach mode**, select **Auto Attach** or **Attach** from the drop-down list as required.
- 8. Click **Save** to save the current changes.
- 9. Click **Reset** to reset the modified changes.

SMTP

Simple Mail Transfer Protocol (SMTP) is an Internet standard for electronic mail (e-mail) transmission across Internet Protocol (IP) networks.

Using MegaRAC GUI, you can configure the SMTP settings of the device.

To open SMTP Settings page, click **Configuration** > **SMTP** from the main menu. A sample screenshot of SMTP Settings Page is shown in the screenshot below.

					admin(Admi	inistrator)	Refresh	Print	Logout
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmwa	are Update		HELP
SMTP S	ettings								-
Manage SMT	P settings of the device.								
LAN Cha	nnel Number	1	•						
Sender	Address								
Machine	Name]					
Primary SMT	P Server								
SMTP S	upport	🔽 Enab	le						
Port		25							
Server A	Address								
SMT	P Server requires Authe	ntication							
User Na	me								
Passwo	rd								
🗆 Enat	ble STARTTLS Support								
Secondary S	MTP Server								
SMTP S	upport	🗖 Enat	le						-



The fields of SMTP Settings Page are explained below.

Table 21: SMTP Settings Page

Ітем	DESCRIPTION				
LAN Channel Number	Displays the list of LAN channels available.				
Sender Address	The 'Sender Address' valid on the SMTP Server.				
Machine Name	 The 'Machine Name' of the SMTP Server. Machine Name is a string of maximum 31 alpha-numeric characters. Space, special characters are not allowed. 				
Primary SMTP Server	Lists the Primary SMTP Server configuration.				
SMPT Support	Enable/Disable SMTP support for the BMC.				
Port	Specify the SMTP Port. Note: Default Port is 25. Port value ranges from 1 to 65535.				
Server Address	 The 'IP address' of the SMTP Server. It is a mandatory field. Note: IP Address made of 4 numbers separated by dots as in "xxx.xxx. xxx.xxx". Each Number ranges from 0 to 255. First Number must not be 0. Supports IPv4 Address format and IPv6 Address format. 				

Table 21: SMTP Settings Page (Continued)

Ітем	DESCRIPTION
	Enable/disable SMTP Authentication.
SMTP Server requires Authentication	 Note: SMTP Server Authentication Types supported are: CRAM-MD5 LOGIN PLAIN If the SMTP server does not support any one of the above authentication types, the user will get an error message stating, "Authentication type is not supported by SMTP Server"
	The username to access SMTP Accounts
Username	 Note: User Name can be of length 4 to 64 alpha-numeric characters. It must start with an alphabet. Special characters "(comma), ':'(colon), ';'(semicolon), ' (space) and '\'(backslash) are not allowed.
	The password for the SMTP User Account.
Password	 Note: Password must be at least 4 characters long. White space is not allowed. This field will not allow more than 64 characters.
Enable STARTTLS Support	 Check this option to enable STARTTLS support for the SMTP Client. SMTP CA Certificate File: File that contains the certificate of the trusted CA certs. SMTP Certificate File: Client certificate filename. SMTP Private Key: Client private key filename. Note: To enable STARTTLS support, the respective SMTP support option should be enabled.
Secondary SMTP Server	It lists the Secondary SMTP Server configuration. It is an optional field. If the Primary SMTP server is not working fine, then it tries with Secondary SMTP Server configuration.
Save	To save the new SMTP server configuration.
Reset	To reset the modified changes.

Procedure:

- 1. Select the LAN Channel Number from the drop-down list.
- 2. Enter the **Sender Address** in the specified field.
- 3. Enter the **Machine Name** in the specified field.
- 4. In Primary SMTP Server, check **Enable** to enable the **SMTP Support** option.

Note:

The Server Address can be edited only when the SMTP Support option is enabled.

- 5. Enter the **Port** value in the specified field.
- 6. Enter the Server Address in the specified field.
- 7. Enable the check box **SMTP Server requires Authentication** if you want to authenticate SMTP Server.
- 8. Enter your User name and Password in the respective fields.
- 9. 9. In Secondary SMTP Server, check **Enable** to enable the **SMTP Support** option.

Note:

The Server Address can be edited only when the SMTP Support option is enabled.

- 10. Enter the **Port** value in the specified field.
- 11. Enter the Server Address in the specific field.
- 12. Enable the check box **SMTP Server requires Authentication** if you want to authenticate SMTP Server.
- 13. Enter your User name and Password in the respective fields.
- 14. Click **Save** to save the entered details else click **Reset** to update the entered details.

SOL

Here, you can configure the Serial over LAN settings, select or change values for each attribute and click the Save button to save any changes.

					admin(Ad	ministrator)	Refresh	Print	Logout
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmware	e Update		HELF
Serial O	ver LAN Settin	gs							
You can confi	gure Serial Over LAN Set	lings on this page.							
Enable S	erial Over LAN								
Baud Ra	te	11	5200 bps 💌						
Channel	Privilege Level Limit	Us	er 🔽						
	Save A	dvanced SOL Sett	ings						
									Ĩ

Figure 3-34. SOL Settings Page

The fields of SOL Settings Page are explained below.

Table 22: SOL Settings Page

Ітем	DESCRIPTION
Enable Serial over LAN	Checked=Enabled; Unchecked=Disabled.
Channel Privilege Level Limit	 Select the IPMI Serial over LAN minimum user privilege: Administrator Operator User
Save	Use this button to save your settings.
Advanced SOL Settings	Use this button to go to advanced SOL page.

Use this page to configure the advanced SOL settings.

					admin(Ad	ministrator)	Refresh	Print	Logout		
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmware	e Update		HELF		
Serial Over LAN Advanced Settings											
You can configure Advanced Serial Over LAN Settings on this page.											
Characte	er Accumulate Interval	12									
Characte	er Send Threshold	96									
		Save	Cancel								

Figure 3-35. SOL Advanced Settings Page

Table 23: SOL Advanced Settings Page

Ітем	DESCRIPTION
Character Accumulate Interval	The amount of the time that the BMC will wait before transmitting a partial SOL character data package. 1-based 5ms increments. This value must be from 1 to 255
Character Send Threshold	The BMC will send an SOL character data package containing the char- acters as soon as this number of characters (or greater) has been accepted. 1-based units. This value must be from 1 to 255.
Save	Use this button to save your settings.
Cancel	Use this button to cancel your settings.

SSL

The **Secure Socket Layer** protocol was created by Netscape to ensure secure transactions between web servers and browsers. The protocol uses a third party, a **Certificate Authority (CA)**, to identify one end or both end of the transactions.

Using MegaRAC GUI, configure SSL certificate into the BMC. Using this, the device can be accessed in a secured mode.

To open SSL Certificate Configuration page, click **Configuration** > **SSL** from the main menu. There are three tabs on this page.

- **Upload SSL** option is used to upload the certificate and private key file into the BMC.
- **Generate SSL** option is used to generate the SSL certificate based on configuration details.
- View SSL option is used to view the uploaded SSL certificate in readable format.

A sample screenshot of SSL Management Page is shown in the screenshot below.

					aumin(Ad	ministrator)	Relifesti	Phil	Logoui
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmware	e Update		HELF
SSL Cer	rtificate Config	uration							
This page is of certificate and to view the up	used to configure SSL ce d private key file into the B loaded SSL certificate in	tificate into the BMC MC. Generate SSL (readable format.	C. Using this, the de	evice can be accessed enerate the SSL certific	in a secured mod ate based on conf	e. Upload SS iguration det	SL option is u ails. View SS	sed to upl L option is	oad the s used
	Genera	ite SSL	VIEW SSL						
Currer	nt Certificate	Wed Dec 3	1 19:00:00 1969						
New C	ertificate			Brow	se				
Currer	nt Private Key	Wed Dec 3	1 19:00:00 1969						
New P	rivate Key			Brow	se				
								Uplo	bad

Figure 3-36. SSL Certificate Configuration – Upload SSL

The fields of SSL Certificate Configuration – Upload SSL tab are explained below.

Table 24: SSL Certificate Configuration - Upload SSL

Ітем	DESCRIPTION
Current Certificate	Current certificate information will be displayed (read-only).
New Certificate	Certificate file should be of pem type
Current Privacy Key	Current privacy key information will be displayed (read-only).
New Privacy Key	Privacy key file should be of pem type.
Upload	To upload the SSL certificate and privacy key into the BMC.

Note:

Upon successful upload, HTTPs service will get restarted to use the newly uploaded SSL certificate.

								admin(Administrator)	Refresh	Print	Logo
ashboard	Server Informa	tion Server	Health	Configuration	Remote Control	Maintenance	Firmware Update				Н
SSL Cei	rtificate Cor	ifiguration	1								
This page is u Generate SSL	used to configure S L option is used to g	SL certificate into generate the SSL	o the BMC). Using this, the d e based on configu	levice can be access uration details. View S	ed in a secured mo SL option is used t	ide. Upload SSL option is us to view the uploaded SSL ce	ed to upload the certificate and pr rtificate in readable format.	ivate key file	into the BM	C.
Uploa	d SSL	Generate SSL		View SSL]						
Comn	non Name(CN)	Γ									
Organ	nization(O)	Γ									
Organ	nization Unit(OU)	Γ									
City o	or Locality(L)										
State	or Province(ST)	Γ									
Coun	try(C)	Γ		_							
Email	Address	Γ									
Valid	for	Γ		days							
Key L	.ength	5	12 -	bits							
										_	_
										Genera	ate

Figure 3-37. SSL Certificate Configuration – Generate SSL

The fields of SSL Certificate Configuration – Generate SSL tab are explained below.

Table 25: SSL Certificate Configuration - Generate SSL

Ітем	DESCRIPTION				
Common Name (CN)	 Common name for which certificate is to be generated. Maximum length of 64 characters. Special characters '#' and '\$' are not allowed. 				
Organization (O)	 Organization name for which the certificate is to be generated. Maximum length of 64 characters. Special characters '#' and '\$' are not allowed. 				
Organization Unit (OU)	 Over all organization section unit name for which certificate is to be generated. Maximum length of 64 characters. Special characters '#' and '\$' are not allowed. 				
City or Locality (L)	 City or Locality of the organization (mandatory). Maximum length of 64 characters. Special characters '#' and '\$' are not allowed. 				
State or Province (ST)	 State or Province of the organization (mandatory). Maximum length of 64 characters. Special characters '#' and '\$' are not allowed. 				
Country (C)	 Country code of the organization (mandatory). Only two characters are allowed. Special characters are not allowed. 				
Email Address	Email Address of the organization (mandatory).				

Ітем	DESCRIPTION
Vaild for	Validity of the certificate.Value ranges from 1 to 3650 days.
Key Length	The key length bit value of the certificate.
Generate	To generate the new SSL certificate.

Table 25: SSL Certificate Configuration - Generate SSL (Continued)

Note:

HTTPs service will get restarted, to use the newly generated SSL certificate.

							admin(Administrator)	Refresh	Print	Logo
shboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmware Update				HE
SL Cer	rtificate Config	uration								
is page is u	used to configure SSL ce	rtificate into the BM	IC. Using this, the (device can be access	ed in a secured mo	de. Upload SSL option is us	sed to upload the certificate and p	rivate key file	into the BM	C.
inerate SSL	L option is used to genera	ate the SSL certifica	ate based on config	uration details. View S	SSL option is used	to view the uploaded SSL or	ertificate in readable format.			
Uplos	d SSI Gana	rate SSI	View SSI							
opida	d SSL Gene	Hate SSL	VIEW 33L							
Basic Int	formation									
Versio	on	3								
Serial	Number	BD16DD20	0846F43A8							
Signa	ture Algorithm	sha1WithR	RSAEncryption							
Public	c Key									
Issued I	From									
Comm	non Name(CN)	AMI								
Organ	nization(O)	American I	Megatrends Inc							
Organ	nization Unit(OU)	Service Pr	ocessors							
City o	or Locality(L)	Atlanta								
State	or Province(ST)	Georgia								
Count	try(C)	US								
Email	Address	support@a	imi.com							

Figure 3-38. SSL Certificate Configuration – View SSL

The fields of SSL Certificate Configuration – View SSL tab are explained below.

Table 26: SSL Certificate	Configuration –	View SSL
---------------------------	-----------------	----------

Ітем	DESCRIPTION
Basic Information	 This section displays the basic information about the uploaded SSL certificate. It displays the following fields. Version Serial Number Signature Algorithm Public Key

Ітем	DESCRIPTION
Issued From	 This section describes the following Certificate Issuer information. Common Name (CN) Organization (O) Organization Unit (OU) City or Locality (L) State or Province (ST) Country (C) Email Address
Validity Information	This section displays the validity period of the uploaded certificate.Valid FromValid To
Issued To	 This section display the information about the certificate issuer. Common Name (CN) Organization (O) Organization Unit (OU) City or Locality (L) State or Province (ST) Country (C) Email Address

Table 26: SSL Certificate Configuration – View SSL (Continued)

Procedure:

- 1. Click the Upload SSL Tab, Browse the New Certificate and New Privacy key.
- 2. Click **Upload** to upload the new certificate and privacy key.
- 3. In Generate SSL tab, enter the following details in the respective fields
 - The Common Name for which the certificate is to be generated.
 - The Name of the Organization for which the certificate is to be generated.
 - The **Overall Organization Section Unit** name for which certificate to be generated.
 - The **City or Locality** of the organization.
 - The **State or Province** of the organization.
 - The **Country** of the organization.
 - The **email address** of the organization.
 - The number of days the certificate will be valid in the Valid For field.
- 4. Choose the Key Length bit value of the certificate.
- 5. Click **Generate** to generate the certificate.
- 6. Click **View SSL** tab to view the uploaded SSL certificate in user readable format.

Note:

- Once you Upload/Generate the certificates, only HTTPs service will get restarted.
- You can now access your Generic MegaRAC[®] SP securely using the following format in your IP Address field from your Internet browser: https://<your MegaRAC[®] SP's IP address here>
- For example, if your MegaRAC[®] SP's IP address is 192.168.0.30, enter the following: https://192.168.0.30
- Please note the <s> after <http>.You must accept the certificate before you are able to access your Generic MegaRAC[®] SP.

User Management

In MegaRAC GUI, the User Management page allows you to view the current list of user slots for the server. You can add a new user and modify or delete the existing users.

To open User Management page, click **Configuration** > **Users** from the main menu. A sample screenshot of User Management Page is shown in the screenshot below.

					admin(/	Administrator)	Refresh	Print	Logou
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmware	Update		HEL
User Ma	anagement								
The list below add a new us	v shows the current list of er, select an unconfigure	available users. To d slot and click "Ado	delete or modify I User''	a user, select the user n	ame from the list :	and click "Dele	ete User" or "I	Modify Use	er". To
							Number of c	onfigured	users: 2
UserID 🛆	username	Δ [Jser Access 🔺	Network Pr	ivilege 🔺		Email ID 🛽	1	
1	anonymous		Disabled	Adminis	trator		~		
2	admin		Enabled	Adminis	trator		~		
3	~		~	~			~		
4	~		~	~			~		
5	~		~	~			~		
6	~		~	~			~		
7	~		~	~			~		
8	~		~	~			~		
9	~		~	~			~		
10	~		~	~			~		
					Add	User Mo	dify User	Delete	User

Figure 3-39. User Management

The fields of User Management Page are explained below.

Table 27: User	Management	Page
----------------	------------	------

Ітем	DESCRIPTION
	Displays the ID number of the user.
User ID	Note:
	The list contains a maximum of ten users only.
User Name	Displays the name of the user.

Ітем	DESCRIPTION
User Access	To enable or disable the access privilege of the user.
Network Privilege	Displays the network access privilege of the user.
SNMP Status	Displays if the SNMP status for the user is Enabled or Disabled.
E-mail ID	Displays e-mail address of the user.
Add User	To add a new user.
Modify User	To modify an existing user.
Delete User	To delete an existing user.

Procedure:

Note:

The Free slots are denoted by "~" in all columns for the slot.

Add a new user:

1. To add a new user, select a free slot and click **Add User**. This opens the Add User screen as shown in the screenshot below.

Add User	×
Username	
Password Size	● 16 Bytes ○ 20 Bytes
Password	
Confirm Password	
User Access	Enable
Network Privilege	Administrator
SNMP Status	Enable
SNMP Access	Read Only
Authentication Protocol	SHA 🔽
Privacy Protocol	DES 🔽
Email ID	
Email Format	AMI-Format
New SSH Key	Browse
	Add Cancel

Figure 3-40. Add User Page

2. Enter the name of the user in the **User Name** field.

Note:

- User Name is a string of 4 to 16 alpha-numeric characters.
- It must start with an alphabetical character.
- It is case-sensitive.
- Special characters like '-' (hyphen), '_' (underscore) and, " (dot) are allowed , but not in the prefix and suffix.

3. In the **Password** and **Confirm Password** fields, enter and confirm your new password.

Note:

- Password must be at least 4 characters long.
- White space is not allowed.
- This field will not allow more than 20 characters if "20 Bytes" option is chosen.
- 4. Enable or Disable the **User Access** Privilege.
- 5. In the **Network Privilege** field, enter the network privilege assigned to the user which could be Administrator, Operator, User, Callback or OEM proprietary.
- 6. In the Extended Privileges, check the required options,
 - KVM
 - VMedia

Note:

It is recommended that the Extended privileges support to KVM and VMedia should be provided only to the ADMIN user and shouldn't be provided to USER and OPERATOR privilege level users. The Admin user can provide the Extended privilege support to USER and OPERA-TOR privilege level users at their own risk.

7. Check the **SNMP Status** check box to enable SNMP access for the user.

Note:

Password field is mandatory, if SNMP Status is enabled.

- 8. Choose the SNMP Access level option for user from the **SNMP Access** drop-down list. Either it can be Read Only or Read Write.
- 9. Choose the **Authentication Protocol** to use for SNMP settings from the drop-down list.

Note:

Password field is mandatory, if Authentication protocol is changed.

- 10. Choose the Encryption algorithm to use for SNMP settings from the **Privacy protocol** drop-down list.
- 11. In the **Email ID** field, enter the email ID of the user. If the user forgets the password, the new password will be mailed to the configured email address.

Note:

SMTP Server must be configured to send emails.

- Email Format: Two types of formats are available:
 - AMI-Format: The subject of this mail format is 'Alert from (your Hostname)'. The mail content shows sensor information, ex: Sensor type and Description.

- Fixed-Subject Format: This format displays the message according to user's setting. You must set the subject and message for email alert.
- 12. In the New SSK Key field, click Browse and select the SSH key file.

Note:

SSH key file should be of pub type.

- 13. Click Add to save the new user and return to the users list.
- 14. Click **Cancel** to cancel the modification and return to the users list.

Modify an existing user:

1. Select an existing user from the list and click **Modify User**. This opens the Add User screen as shown in the screenshot below.

Modify User		X
Username	admin	
	Change Password	
Password Size	◯ 16 Bytes ◯ 20 Bytes	
Password		
Confirm Password		
User Access	Enable	
Network Privilege	Administrator	
SNMP Status	Enable	
SNMP Access	Read Only	
Authentication Protocol	SHA 💌	
Privacy Protocol	DES 💌	
Email ID		
Email Format	AMI-Format	
Uploaded SSH Key	Not Available	
New SSH Key	Browse	
	Modify Cano	el

Figure 3-41. Modify User Page

- 2. Edit the required fields.
- 3. To change the password, enable the **Change Password** option.
- 4. After editing the changes, click **Modify** to return to the users list page.

Note:

SNMP related fields will not show at setting page while BMC did not support this function

Delete an existing User

To delete an existing user, select the user from the list and click **Delete User**.

Note:

There is a list of reserved users which cannot be added / modified as BMC users. Please Refer "MEGARAC SP-X Platform Porting Guide" section "Changing the Configurations in PMC File-> User Configurations in PMC File" for the list of reserved users.

Virtual Media

In MegaRAC GUI, this page is to configure Virtual Media device settings. If you change the configuration of the virtual media in this page, it shows the appropriate device in the JViewer Vmedia dialog. For example, if you select two floppy devices in Configure Virtual Media page, then in **JViewer** > **Vmedia**, you can view two floppy device panel, these virtual media devices will only setup when Launching the KVM.

To open Virtual Media page, click **Configuration > Virtual Media** from the main menu. A sample screenshot of User Management Page is shown in the screenshot below.

					admin(A	Administrator)	Refresh	Print	Logou
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmware	Update		HEL
Virtual I	Media Devices								
The following media device	option will allow to confi <u>c</u> s.	gure virtual media de	evices. Below, you o	can select the number	of instances that a	ire be suppor	ted for each t	ype of virtu	al
Floppy d	evices		4						
CD/DVD	devices		4						
Hard dis	k devices		4						
Remote	KVM Floppy devices		2 💌						
Remote	KVM CD/DVD devices		2 💌						
Remote	KVM Hard disk devices		2 💌						

Save Reset

Figure 3-42. Configure Virtual Media Devices

The following fields are displayed in this page.

Table 28: Configure	Virtual Media	Devices
---------------------	---------------	---------

Ітем	DESCRIPTION
Floppy devices	The number of floppy devices that support for Virtual Media redirec- tion.
CD/DVD devices	The number of CD/DVD devices that support for Virtual Media redirec- tion.
Hard disk devices	The number of hard disk devices that support for Virtual Media redirec- tion.
Remote KVM Floppy Devices	The number of floppy devices that support for KVM Virtual Media redirection.
Remote KVM CD/DVD Devices	The number of CD/DVD devices that support for KVM Virtual Media redirection.
Remote KVM Hard disk Devices	The number of Hard disk devices that support for KVM Virtual Media redirection.
Save	To save the configured settings.
Reset	To reset the previously-saved values.

Procedure:

1. Select the number of Floppy devices, CD/DVD devices and Hard disk devices from the dropdown list.

Note:

Maximum of two devices can be added in Floppy, CD/DVD and Hard disk drives.

- 2. Enable the Local Media Support if needed.
- 3. Click **Save** to save the changes made else click Reset to reset the previously saved values.

Note:

If there are two device panels for each device, and when you click the Connect button, then the redirected device panel will be disabled.

Services

This page used for port setting and displays the basic information about services running in the BMC. Only Administrator can modify the service.

To open Services page, click **Configuration** > **Services** from the menu bar. A sample screenshot of Services Page is shown below.

Dashboard Server Information Server Health Configuration Remote Control Maintenance Firmware Update HEL

admin(Adm

Refresh

1 000

Services

Below is a list of services running on the BMC. It shows current status and other basic information about the services. Select a slot and press "Modify" button to modify the services configuration.

							I	Number of Services: 8
# 4	Service Name	△ Current State △	Interfaces 🛆	Nonsecure Port Δ	Secure Port 🛆	Timeout 🛆	Maximum Sessions	△ Active Sessions △
1	web	Active	bond0	80	443	1800	20	View
2	kvm	Active	bond0	7578	7582	1800	2	View
3	cd-media	Active	bond0	5120	5124	N/A	4	View
4	fd-media	Active	bond0	5122	5126	N/A	4	View
5	hd-media	Active	bond0	5123	5127	N/A	4	View
6	ssh	Active	N/A	N/A	22	600	N/A	View
7	telnet	Inactive	N/A	23	N/A	600	N/A	View
8	solssh	Inactive	bond0	52123	N/A	60	N/A	View
								Modify



The fields of Services Page are explained below.

Table 29: Services

Ітем	DESCRIPTION
Service Name	Displays service name of the selected slot (read-only).
Current State	Displays the current status of the service, either active or inactive state.

Ітем	DESCRIPTION
Interfaces	It shows the interface in which service is running.
Nonsecure Port	 This port is used to configure non secure port number for the service. Web default port is 80 KVM default port is 7578 CD Media default port is 5120 FD Media default port is 5122 HD Media default port is 5123 Telnet default port is 23
	Note: SSH service will not support non secure port. If single port feature is enabled, KVM, CD Media, FD Media and HD Media ports cannot be edited.
Secure Port	Used to configure secure port number for the service. - Web default port is 443 - KVM default port is 7582 - CD Media default port is 5124 - FD Media default port is 5126 - HD Media default port is 5127 - SSH default port is 22
	Note: Telnet service will not support secure port. If single port feature is enabled, KVM, CD Media, FD Media and HD Media ports cannot be edited.
	Displays the session timeout value of the service. For Web, user can con- figure the session timeout value.
Timeout	 Note: Web timeout value ranges from 300 to 1800 seconds. KVM timeout value ranges from 300 to 1800 seconds. SSH and Telnet timeout value ranges from 60 to 1800 seconds. SSH and telnet timeout value should be in multiples of 60 seconds. SSH and telnet service will be using the shared timeout value. If you configure SSH timeout value, it will be applied to telnet service also and vice versa. If KVM is launched then the web session timeout will not take effect.
Maximum Sessions	Displays the maximum number of allowed sessions for the service.
Active Sessions	To view the current active sessions for the service.

Table 29: Services (Continued)

Procedure

1. Click **View** to view the details about the active sessions for the service.

2. This opens the **Active Session** screen (for example - Web Service screen) as shown in the screenshot below.



Session ID: Displays the ID number of the active sessions.

Session Type: Displays the type of the active sessions.

IP Address: Displays the IP addresses that are already configured for the active sessions.

User ID: Displays the ID number of the user.

User Name: Displays the name of the user.

User Privilege: Displays the access privilege of the user.

3. Select a slot and click **Terminate** to terminate the particular session of the service else click **Cancel** to cancel the modification and return to Services list.

Modify: To modify the existing services.

Procedure

1. Select a slot and click **Modify** to modify the configuration of the service. Alternatively, double click on the slot.

Note:

Whenever the configuration is modified, the service will be restarted automatically. User has to close the existing opened session for the service if needed.

2. This opens the Modify Service screen as shown in the screenshot below.

Modify Service			
Service Name	kvm		
Current State	 Active 		
Interfaces	both v		
Nonsecure Port	7578		
Secure Port	7582]	
Timeout	1800	seconds	
Maximum Sessions	2]	
			Modify



- 3. Service Name is a read only field
- 4. Activate the **Current State** by enabling the Activate check box.

Note:

Interfaces, Nonsecure port, Secure port, Time out and Maximum Sessions will not be active unless the current state is active.

- 5. Choose any one of the available interfaces from the **Interface** drop-down list.
- 6. Enter the Nonsecure port number in the Nonsecure Port field.
- 7. Enter the Secure Port Number in the Secure Port field.
- 8. Enter the timeout value in the **Timeout** field.

Note:

The values in the Maximum Sessions field cannot be modified.

9. Click **Modify** to save the entered changes and return to the Services Page else Click **Cancel** to exit.

LAN Port Settings

Here you can configure LAN Port setting of the BMC NIC.

					admin(A	dministrator)	Refresh	Print	Logout
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmware	Update		HELF
LAN Po	rt Settings								
You can confi	gure LAN Port Settings of	n this page.							
WARNING Changing	: Please make sure the to an un-configured dev	selected device has ice will result in BM	s been properly co IC connection lost,	nfigured with IP and it and require manually	t's connected to s re-install the HW	witch. connection.			
Select L	AN port De	dicated-NIC							
	50	ared-INIC (LOIVI)					Save	Reset	



Procedure:

- 1. Select LAN Port from the dropdown list
- 2. Click Save to save the change or click Reset to reset the previously saved values.

Remote Control

The Remote Control consists of the following menu items.

- Console Redirection
- Server Power Control
- Java SOL

					admin(A	Administrator)	Refresh	Print	Logout
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmware	Update		HELI
Concele	Dedirection			Console Redirect	ion				
Console	Redirection			Server Power Co	ntrol				
Press the but	on to launch the redirecti	on console and ma	nage the server rem	Java SOL					
	Java Console								

A sample screenshot of the Remote Control menu is given below.



A detailed description of the menu items are given ahead

Console Redirection

The remote console application, which is started using the WebGUI, allows you to control your server's operating system remotely, using the screen, mouse, and keyboard, and to redirect local CD/DVD, Floppy diskette and Hard disk/USB thumb drives as if they were connected directly to the server.

List of Supported Client Operating Systems

- WinXP
- W2K3 32 bit
- W2K3 64 bit
- RHEL 4 32 bit
- RHEL 4 64 bit
- RHEL 5.4 32 bit
- RHEL 5.4 64 bit
- RHEL 6.0 64 bit
- RHEL 6.0 32 bit
- Ubuntu 9.10 LTS 32 bit
- Ubuntu 9.10 LTS 64 bit
- Ubuntu 8.10 -32 bit
- Ubuntu 8.10 -64 bit
- OpenSuse 11.2 -32 bit
- OpenSuse 11.2 -64 bit

- FC 9 32 bit
- FC 9 64 bit
- FC 10 32 bit
- FC 10 64 bit
- FC 12 32 bit
- FC 12 64 bit
- FC 13 32 bit
- FC 13 64 bit
- FC 14 32 bit
- FC 14 64 bit
- MAC 32 bit
- MAC 64 bit

List of Supported Host OS

- RHEL 5
- RHEL 6
- W2K3
- W2K8
- RHEL 4
- OpenSuse 11.2
- OpenSuse 10.x
- Ubuntu 8.10
- Ubuntu 9.10
- Ubuntu 11.04

Supported JRE Version

Java[™] SE Runtime Environment 1.6.0 +

Note:

If OS use 32 bit then use JRE 32 bit version If OS use 64 bit then use JRE 64 bit version To get JRE version command in Linux/Windows: java -version Windows example:



Browser Settings

For Launching the KVM, pop-up block should be disabled. For Internet explorer, enable the download file options from the settings.

Java Console

This is an OS independent plug-in which can be used in Windows as well as Linux with the help of JRE. JRE should be installed in the client's system. You can install JRE from the following link.

http://www.java.com/en/download/manual.jsp

Procedure:

In MegaRAC GUI, the Java Console can be launched in two ways:

- 1. Open the Dashboard Page and click Launch for Java Console in Remote control section.
- 2. Open **Remote Control** > **Console Redirection** Page and click **Java Console**.

This will download the **.jnlp** file from BMC.

To open the **.jnlp** file, use the appropriate JRE version (Javaws).

When the downloading is done, it opens the Console Redirection window.

Note:

Web page will be timeout after open 30 minutes, but it will be connected continually when open RKVM.

The Console Redirection main menu consists of the following menu items.

- Video
- Keyboard
- Mouse
- Options
- Media
- Keyboard Layout
- Video Record
- Active Users
- Help

A detailed explanation of these menu items are given below.

Video

This menu contains the following sub menu items.

Table 30: Video

Ітем	DESCRIPTION
Pause redirection	This option is used for pausing Console Redirection.
Resume Redirection	This option is used to resume the Console Redirection when the session is paused.
Refresh Video	This option can be used to update the display shown in the Console Redirection window.
Compression mode	This option is used to select the video compression mode which includes YUV 420, YUV 444, YUV 444 + 2 colors VQ and YUV 444 + 4 colors VQ in Java console.
DCT Quantization table	There are eight levels to select the Video quality. If using low band- width, user can use lower level to get better video fluency but may not more clear. If using high bandwidth, user can use higher level to get clearer page.
Host video output	If you enable this option, the server display will be blank but you can view the screen in Console Redirection. If you disable this option, the display will be back in the server screen.
Full Screen	This option is used to view the Console Redirection in full screen mode (Maximize). This menu is enabled only when both the client and host resolution are the same.
Exit	This option is used to exit the console redirection screen.

Keyboard

This menu contains the following sub menu items.

Tab	le 31	1: Ke	eyboard	t
-----	-------	-------	---------	---

Ітем	DESCRIPTION
Hold Right Ctrl Key	This menu item can be used to act as the right-side < CTRL > key when in Console Redirection.
Hold Right Alt Key	This menu item can be used to act as the right-side < ALT > key when in Console Redirection.
Hold Left Ctrl Key	This menu item can be used to act as the left-side < CTRL > key when in Console Redirection.
Hold Left Alt Key	This menu item can be used to act as the left-side < ALT > key when in Console Redirection.
Left Windows Key	This menu item can be used to act as the left-side < WIN > key when in Console Redirection. You can also decide how the key should be pressed: Hold Down or Press and Release.

Table 31: Keyboard (Continued)

Ітем	DESCRIPTION
Right Windows Key	This menu item can be used to act as the right-side < WIN > key when in Console Redirection. You can also decide how the key should be pressed: Hold Down or Press and Release.
Alt+Ctrl+Del	This menu item can be used to act as if you depressed the <ctrl< b="">>, <alt< b="">> and <del< b="">> keys down simultaneously on the server that you are redirecting.</del<></alt<></ctrl<>
Full keyboard support	This menu item can be used to act as totally host OS keyboard in Con- sole Redirection. It will disable the hot-key of RKVM when enable "Full Keyboard Support". If the hot-key is used in client OS, It can't be used in RKVM host OS. Because the hot-key is used by client OS first.
Context menu	This menu item can be used to act as <context menu=""> key in Console Redirection.</context>
Hot Keys	This menu item is used to add Hot Keys as below screenshot.

г

Table 31: Keyboard (Continued)

Ітем	DESCRIPTION
	Procedure:
	1. Click Keyboard > Hot Keys > Add Hot Keys to show below snap-
	shot
	User Defined Macros
	Auu Delete Cuse
	Add: used to add User Defined Macros
	Delete: used to delete User Defined Macros
	Close: used to close User Defined Macros window
	Add User Defined Macro
	Place the cursor in the text box and Press the key event combination to defined a Macro
	Vindows Tab Ctrift.eth-ABI.eth-Delete
Add Hot Keys	Clear Clear All ne
Add Hot Keys	
	Windows: used to define Windows key
	• Tab : used to define Tab key
	Clear: used to delete the latest defined key
	Clear All: used to delete all defined key
	• ok : used to confirm and add defined macro
	Note:
	Please press key one by one to define the macro. If click 🗾 to close
	this window and then click Add to open again, defined macro kept is
	normal. Support maximum 6 combo keys in 1 macros
	3. Click ok to add this macro as below
	Ctrl(Left)+Alt(Left)+Delete
	Add Delete Close

Mouse

This menu contains the following sub menu items.

Table 32: Mouse

Ітем	DESCRIPTION
Show cursor	This option is used to display or hide the client mouse cursor in Java Console.
Mouse Calibration	It is used to adjust the mouse calibration.
Mouse mode	 Absolute mouse mode: To select mouse mode to "Absolute", depending upon the Host Operating System (All Windows versions; RHEL Linux versions not below than RHEL5.8; Fedora Linux versions not below than FC14). In this mode, the default value will enable "Show Cursor" feature and you will see two mice in remote KVM. The first mouse is in remote PC end; the second mouse is in local server end. On the different RHEL system, the mouse of acceleration setting is not different. So user will see two mice (remote/local mice) not synchronized sometimes Relative mouse mode: To select mouse mode to "Relative", depending upon the Host Operating System (RHEL Linux versions below than RHEL5.8; Fedora Linux versions below than RHEL5.8; Fedora Linux versions below than SLES11). Other mouse mode: For the Host Operating System which is neither "Absolute" nor "Relative" mouse mode (SLES Linux version SLES11). "Other Mouse Mode" does not support Zoom In/Zoom Out and Maximize Window button is removed like this when this mode is selected, scroll bar will disappear and video screen scaling function will resize the original video screen of remote to fit the current frame size of wideo display nanel.
	Note:
	When both Keyboard > Full Keyboard Support and Mouse > Other mouse mode are enabled at the same time, the mouse cursor will NOT be moved to outside the window unless to press "Alt+Tab" to switch window. And move mouse cursor to other window by pressing "Alt+C."

Options

This menu contains the following sub menu items.

Table 33: Options

Ітем	DESCRIPTION
Bandwidth	This option is used to select the bandwidth manually or automatically.
Keyboard/Mouse Encryption	This option is used to enable or disable encryption for the data payload of Keyboard/Mouse transferring.
Zoom	This option is used to adjust the video screen for zoom in or zoom out.

Media

Floppy Key Media1				
Floppy Image		•	Browse	Connect Floppy
Floppy Key Media2				
Floppy Image		•	Browse	Connect Floppy
D/DVD Media1			Browse	Connect CD/DVD
о коо нице О Е		200 200		
D/DVD Media2				
D/DVD Media2 ISO Image		•	Browse	Connect CD/DVD
D/DVD Media2 ISO Image			Browse	Connect CD/DVD
D/DVD Media2 ISO Image E Iso Image E Iard disk/USB Key Mee	fia2		Browse	Connect CD/DVD
CD/DVD Media2 ISO Image E Iard disk/USB Key Mee HD/USB Image	tia2		Browse	Connect CD/DVD Connect Hard disk/USB Key
CD/DVD Media2 ISO Image E Hard disk/USB Key Mee HD/USB Image PhysicalDrive0-[D-	lia2 F-C] - Fixed Drive		Browse	Connect CD/DVD
DDVD Media2 ISO Image ISO Image E Hard disk/USB Key Med HD/USB Image PhysicalDrive0-[D-] Status	lia2 F-C] - Fixed Drive		Browse	Connect CD.DVD
CD/DVD Media2 SISO Image E Hard disk/USB Key Mee HD/USB Image PhysicalDrive0-ID- Status Target Drive	fia2 F-C] - Fixed Drive Connected To		Browse Browse	Connect CD/DVD
CD/DVD Media2 SO Image E Hard disk/USB Key Mee HD/USB Image PhysicalDrive0-D- Status Target Drive Virtual Floppy 1	fia2 F-C] - Fixed Drive Connected To Not connected	▼ ▼ Read E n/a	Browse Browse	Connect CDIDVD
CD/DVD Media2 SISO Image ISO Image E Hard disk/USB Key Mer HD/USB Image PhysicalDrive0-[D- Status Target Drive Virtual Floppy 2	tia2 F-C] - Fixed Drive Connected To Not connected Not connected Not connected	Read E	Browse	Connect CD/DVD
CD/DVD Media2 Stormage E Hard disk/USB Key Mee HD/USB Image PhysicalDrive0-[D- Status Target Drive Virtual Floopy 1 Virtual Floopy 2 Virtual CD 1	fia2 F-C] - Fixed Drive Connected To Not connected Not connected Not connected Not connected Not connected	Read E	Browse Browse	Connect CD/DVD Connect Hard disk/USB Key

Figure 3-47. Virtual Media

Table 34: Virtual Media

Ітем	DESCRIPTION
	This menu item can be used to start or stop the redirection of a physical floppy drive and floppy image types such as <i>*.img</i> .
Floppy Key Media	Note: Floppy Redirection is not an available feature on all versions of the MegaRAC [®] SPs.
CD/DVD Media	This menu item can be used to start or stop the redirection of a physical DVD/CD-ROM drive and cd image types such as <i>*.iso</i> .
	This menu item can be used to start or stop the redirection of a Hard Disk/USB key image and USB key image such as <i>*.img</i> .
Hard disk/USB Key Media	Note: For windows client, if the logical drive of the physical drive is dismount then the logical device is redirected with Read/Write Permission else it is redirected with Read permission only. For MAC client, External USB Hard disk redirection is only supported. For Linux client, fixed hard drive is redirected only as Read Mode. It is not Write mode supported. For USB key image redirection, support FAT 16, FAT 32 and NTFS.

Keyboard Layout

Table 35: Keyboard Layout

Ітем	DESCRIPTION
Auto Detect	This option is used to detect keyboard layout automatically. The lan- guages supported automatically are English – US, French – France, Spanish – Spain, German- Germany, Japanese- Japan. If the client and host languages are the same, then for all the languages other than Eng- lish mentioned above, you must select this option to avoid typo errors.
Soft Keyboard	This option allows you to select the keyboard layout. It will show the dialog as similar to onscreen keyboard. If the client and host languages are different, then for all the languages other than English mentioned above, you must select the appropriate language in the list shown in JViewer and use the soft keyboard to avoid typo errors.
	Note: Soft keyboard is applicable only for JViewer Application not for other application in the client system.

Video Record

Note:

This option is available only when you launch the Java Console.

Table 36: Video Record

Ітем	DESCRIPTION	
Important	To view this menu option you must download the Java Media Frame- Work (JMF). It can be downloaded from the link http://www.oracle.com/technetwork/java/javase/download- 142937.html	
Start Record	This option is to start recording the screen.	
Stop Record	This option is used to stop the recording.	
Settings	To set the settings for video recording.	

Procedure:

Note:

Before you start recording, you have to enter the settings.

1. Click **Video Record > Settings** to open the settings page as shown in the screenshot below.

Video Length 20 Seconds	
Video to be Saved	
	Browse
	Ok

Figure 3-48. Video Record Settings Page

- 2. Enter the Video Length in seconds.
- 3. Browse and enter the location where you want the video to be saved.
- 4. Enable the option Normalized video resolution to 1024X768.
- 5. Click **OK** to save the entries and return to the Console Redirection screen.
- 6. Click **Cancel** if you don't wish to save the entries.
- 7. In the Console Redirection window, click Video Record > Start Record.
- 8. Record the process.
- 9. To stop the recording, click **Video Record > Stop Record**.

Active Users

Click this option to displays the active users and their system IP address.

Help

About Jviewer: Displays the copyright and version information

Quick Buttons

The lower right of Console Redirection windows displays all the quick buttons. These quick buttons helps you to perform these functions by just clicking them.

Note:

This option is available only when you launch the Java Console. The keyboard mapping is abnormal for number key(0-9) in remote KVM when console side is using laptop without dedicated number key. User need to press the "Num Lock" key to change its lock mode.

Multi-users in Remote KVM console

The Remote KVM console is only able to allow two users to login simultaneously. Regarding to KVM privilege, the first user has the greatest power to decide the second user access right.

The second user wants to launch remote KVM if first user already login remote KVM, and second user needs to wait for first user permit in 30 seconds, then second user will get the waiting information as shown below.



At the moment, first user needs to give permission to second user. And there are three options to decide the second user access right for the first user as below.

Allow Virtual Console: Second user is the same as first user access right, and second user can access the Keyboard, mouse, and Video function.

Allow only Video: Second user has only Video function.

Deny Access: Second user can not have any access right to access Keyboard, mouse, and Video function.



Server Power Control

This page allows you to view and control the power of your server.

In Power Control and Status page, you can click **Remote Control** > **Server Power Control** from the main menu, and then there are more options to control server system. Such as: reset system, power off (immediate), power off (orderly), power on and power cycle. A sample screenshot of Power Control and Status page is shown in the screenshot below.



Figure 3-49. Power Control and Status Page

The various options of Power Control are given below.

Ітем	DESCRIPTION	
Reset Server	This option will reboot the system without powering off (warm boot).	
Power off Server – Immediate	This option will immediately power off the server.	
Power off Server – Orderly Shut- down	This option will initiate operating system shutdown prior to the shut- down.	
Power On Server	This option will power on the server.	
Power Cycle Server	This option will first power off, and then reboot the system (cold boot).	
Perform Action	Click this option to perform the selected operation.	

Table 37: Server Power Control

Procedure:

Select an action and click **Perform Action** to proceed with the selected action.

Note:

You will be asked to confirm your choice. Upon confirmation, the command will be executed and you will be informed of the status.

Java SOL

This page allows you to launch the Java SOL. The Java SOL is used to view the host screen using the SOL Redirection.

To open Java SOL page, click **Remote Control** > **Java SOL** from the menu bar. A sample screenshot of Java SOL page is shown below.

					ad	imin(Administrator)	Refresh	Print
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmware Upda	te	
Java SC	L							
Press the but	ton to launch the Java SOi	L.						
Java SOL								

Figure 3-50. Java SOL Page

The various options of Power Control are given below.

Table 38: Server Power Control

Ітем	DESCRIPTION	
Reset Server	This option will reboot the system without powering off (warm boot).	
Power off Server – Immediate	This option will immediately power off the server.	

Ітем	DESCRIPTION
Power off Server – Orderly Shut- down	This option will initiate operating system shutdown prior to the shut- down.
Power On Server	This option will power on the server.
Power Cycle Server	This option will first power off, and then reboot the system (cold boot).
Perform Action	Click this option to perform the selected operation.

Table 38: Server Power Control (Continued)

Procedure:

1. Click the Java SOL button to open the Java SOL window.

- 2. Enter the BMC IP address, User Name and Password in the respective fields.
- 3. Select the Volatile-Bit-Rate and Non-Volatile-Bit-Rate from the drop down lists.

4. Click **Connect** to open the SOL redirection window as shown in the screenshot below.



Maintenance Group

This group of pages allows you to do maintenance tasks on the device. The menu contains the following items:

- Preserve Configuration
- Restore Factory Defaults



Figure 3-51. Restore Factory Defaults

Preserve Configuration

This page allows the user to configure the preserve configuration items, which will be used by the Restore factory defaults to preserve the existing configuration without overwriting with default configuration.



Preserve Configuration

This page allows you to select the specific configuration items to be preserved in the cases of "Restore Configuration", and "Firmware Update without Preserve Configuration option".

Click here to go to Firmware Update or Restore Configuration

Number of Preserved Items: 0

# 🛆	Preserve Configuration Item 🗳	Preserve Status
1	SDR	
2	FRU	
3	SEL	
4	IPMI	
5	Network	
6	NTP	
7	SSH	
8	KVM	
9	Authentication	
10	Syslog	
		Check All Uncheck All Save Reset



Item Verification Procedure

1. SDR

Step 1: add OEM record (Please refer to IPMI 2.0 Spec. page 468/644)

Command: ipmitool raw 0x0a 0x24 0x0 0x0 0x51 0xc0 4 0x57 0x01 0x0 0xf5

Response: 55 00 "» 55 is the last record ID

Step 2: get OEM record, to use the last record ID to check if added successfully (Please refer to IPMI 2.0 Spec. page 466/644)

Command: ipmitool raw 0x0a 0x23 0x0 0x0 0x55 0x0 0x0 0xff

Response: ff ff 55 00 51 c0 04 57 01 0 f5 "» ff ff means record ID 55 is the last record ID

Step 3: go to Web-UI to check "SDR" to be preserved

Step 4: upgrade firmware

Step 5: after Step 4, go to Step 2 and check if the OEM record is still preserved (if preserved then PASS, else FAIL)

2. SEL

Step 1: Please use IPMI command to add an event. Ex: ipmitool event 1

Step 2: go to Event Log to check if the event added

Step 3: go to Web-UI to check "SEL" to be preserved
Step 4: upgrade firmware

Step 5: after Step 4, go to Step 2 and check if the event is still preserved (if preserved then PASS, else FAIL)

3. IPMI

Step 1: Please add a new user by Web.

Step 2: check if the user added

Step 3: go to Web-UI to check "IPMI" to be preserved

Step 4: upgrade firmware

Step 5: after Step 4, go to Step 2 and check if the user is still exist (if preserved then PASS, else FAIL)

4. Network

Step 1: Please change BMC IPv4 address source to be STATIC or DHCP mode by Web.

Step 2: check if the mode changed

Step 3: go to Web-UI to check "Network" to be preserved

Step 4: upgrade firmware

Step 5: after Step 4, go to Step 2 and check if the mode is still preserved (if preserved then PASS, else FAIL)

5. SNMP (supported from Grantley platform)

Step 1: Please go to add a new user and enable SNMP function.

Step 2: check if the user added and SNMP function enabled

Step 3: go to Web-UI to check "SNMP" to be preserved

Step 4: upgrade firmware

Step 5: after Step 4, go to Step 2 and check if the setting is still preserved (if preserved then PASS, else FAIL)

6. SSH

Step 1: Please go to add a new user and update the NEW SSH key.

Step 2: check if the user added SSH key updated

Step 3: go to Web-UI to check "SSH" to be preserved

Step 4: upgrade firmware

Step 5: after Step 4, go to Step 2 and check if the mode is still preserved (if preserved then PASS, else FAIL)

7. KVM

Step 1: Please modify the "Remote Session", "Mouse Mode", and "Virtual Media Devices" setting by Web.

Step 2: check if the setting changed

Step 3: go to Web-UI to check "KVM" to be preserved

Step 4: upgrade firmware

Step 5: after Step 4, go to Step 2 and check if the setting is still preserved (if preserved then PASS, else FAIL)

8. Services (supported from Grantley and Microserver platform)

Step 1: Please change the default value of each item by Web.

Step 2: check if the setting changed

Step 3: go to Web-UI to check "Services" to be preserved

Step 4: upgrade firmware

Step 5: after Step 4, go to Step 2 and check if the setting is still preserved (if preserved then PASS, else FAIL)

Restore Factory Defaults

In MegaRAC GUI, this option is used to restore the factory defaults of the device firmware.

Note:

SSL cert doesn't support restore default



WARNING!

Please note that after entering restore factory widgets, other web pages and services will not work. All open widgets will be closed automatically. The device will reset and reboot within a few minutes.

To open Restore Factory Defaults page, click **Maintenance > Restore Factory Defaults** from the main menu. A sample screenshot of Restore Factory Defaults Page is shown in the screenshot below.

					admi	N(Administrator)	Refresh	Print	Logout
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmware Up	odate		HELF
Restore	Configuration								
This page all Configuration values. If non	ows you to restore the def ". Upon "Restore Configu e are selected, all the con	fault configuration fo iration", the selected ifiguration items wil	or your device. You o d configuration item I be restored to the	can select specific con is will be preserved wh ir default values, esser	figuration items to ille all the other co ntially restoring the	be preserved by nfiguration items device configura	clicking "Ento will be resto ation to its fac	er Preserv red to their tory defaul	e default ts.
WARNING automatic	Please note that once yearly. The device will reset	ou enter restore cor t and reboot within fe	nfiguration, widgets ew minutes.	, other web pages and	services will not v	vork. All open wid	dgets will be o	closed	
This section I items.	ists the configuration iten	ns, that will be pres	erved during restor	e configuration. Click "I	Preserve Configura	ation" to modify t	he preserve c	onfiguratio	n
# A		Preserve Confi	guration Item ム			Preserve S	Status 🗅		
				Data N/A					
					Enter Preserv	e Configuration	Restor	e Configur	ation

Figure 3-53. Restore Factory Defaults Page

Procedure:

Click **Restore Factory** to restore the factory defaults of the device firmware.

Firmware Update

This group of pages allows you to do Firmware Update on the device. The menu contains the following items:

- BMC Firmware Update
- BIOS Update

					admii	N(Administrator)	Refresh	Print	Log
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmware U	lpdate		HE
						Firmware L	Jpdate		
Firmwa	re Update					BIOS Upda	te		
Upgrade firm	ware of the device.HPM F	irmware Update							

Figure 3-54. Firmware Update Menu

BMC Firmware Update

In MegaRAC GUI, this wizard takes you through the process of firmware up gradation. A reset of the box will automatically follow if the upgrade is completed or cancelled. An

option to preserve configuration will be presented. Enable it, if you wish to preserve configured settings through the upgrade.



WARNING!

Please note that after entering update mode widgets, other web pages and services will not work. All open widgets will be closed automatically. If upgrade process is cancelled in the middle of the wizard, the device will be reset.

Note:

The firmware upgrade process is a crucial operation. Make sure that the chances of a power or connectivity loss are minimal when performing this operation.

Once you enter into *Update Mode* and choose to cancel the firmware flash operation, the MegaRAC[®] card must be reset. This means that you must close the Internet browser and log back onto the MegaRAC[®] card before you can perform any other types of operations.

To open Firmware Update page, click **Firmware Update** > **Firmware Update** from the main menu. A sample screenshot of Firmware Update Page is shown in the screenshot below.

ver Information	Server Health	Configuration	Remote Control	Maintenance	Firmware Update			HELF
pdate								
-								
of the device.HPM Fi	rmware Update							
ormation to be used	l for firmware image	transfer during this	s update is as follows.	. To configure, choo	se 'Protocol Configuration	' under Firmw	are Updat	e
: HTTP/HTTPs								
		CAMI						
				Cont	inue			
	of the device. HPM F i ormation to be used : HTTP/HTTPS	of the device. HPM Firmware Update ormation to be used for firmware image : HTTP/HTTPs	of the device. HPM Firmware Update ormation to be used for firmware image transfer during this : HTTP/HTTPS AMI	of the device.HPM Firmware Update ormation to be used for firmware image transfer during this update is as follows : HTTP/HTTPs C AMI	of the device. HPM Firmware Update ormation to be used for firmware image transfer during this update is as follows. To configure, choo : HTTP/HTTPS C AMI Conti	of the device. HPM Firmware Update ormation to be used for firmware image transfer during this update is as follows. To configure, choose 'Protocol Configuration : HTTP/HTTPs Continue	of the device. HPM Firmware Update ormation to be used for firmware image transfer during this update is as follows. To configure, choose 'Protocol Configuration' under Firmw : HTTP/HTTPs C AMI Continue	of the device.HPM Firmware Update ormation to be used for firmware image transfer during this update is as follows. To configure, choose 'Protocol Configuration' under Firmware Update : HTTP/HTTPs C AMI Continue

WARNING: Please note that after entering the update mode, the widgets, other web pages and services will not work. All the open widgets will be automatically closed. If the upgradation is cancelled in the middle of the wizard, the device will be reset.

Figure 3-55. Firmware Update Page

The types of Firmware Update are as follows.

- HPM
- AMI

HPM

This wizard takes you through the process of HPM based firmware upgrade.

To process **HPM** Firmware Upgradation, select **HPM** option and click **Continue** to upgrade the current device firmware. The screenshot of HPM Firmware Update is as shown below.

							adn	NIN(Administrator)	Refresh	Print	Logo
shboard Sen	ver Information	Server Health	Configuration	Remote Control	Maintenance	Firmware Update					HE
irmware U	Jpdate										
/pgrade firmware (of the device.HPM	Firmware Update									
The protocol info Protocol Type	formation to be use e : HTTP/HTTPs	d for firmware image	e transfer during t	this update is as follo	ws. To configure, (choose 'Protocol Configuration'	under Firmware Update	e menu.			
WARNING: Pleas	e note that after er	ntering the update m	ode, the widgets,	other web pages and	l services will not v	vork. All the open widgets will be	e automatically closed.	If the upgradation	n is cancelled	in the midd	le of
I configuration ite	ems below will be p	reserved as default	during the restore	e configuration operat	ion.						
configuration ite # \to \	ems below will be p	reserved as default	during the restore Preserve Con	configuration operat	ion.		Pre	eserve Status 🗳	7		
configuration ite # 1	ems below will be p	reserved as default	during the restore Preserve Con	e configuration operat ifiguration Item -> SDR	ion.		Pre	eserve Status – Overwrite	2		
configuration ite # → 1 2	ems below will be p	reserved as default	during the restore Preserve Con	e configuration operat figuration Item	ion.		Pre	eserve Status Overwrite Overwrite	2		
configuration ite #1 	ems below will be p	reserved as default	during the restore Preserve Con	e configuration operat ifiguration Item -> SDR FRU SEL	ion.		Pre	overwrite Overwrite Overwrite	2		
configuration ite 1 2 3 4	ems below will be p	reserved as default	during the restore Preserve Con	e configuration operat ofiguration Item (A) SDR FRU SEL IPMI	ion.		Pre	Overwrite Overwrite Overwrite Overwrite Overwrite	2		
configuration ite	ems below will be p	reserved as default	during the restore	e configuration operat ifiguration Item SDR FRU SEL IPMI etwork	ion.		Pre	Overwrite Overwrite Overwrite Overwrite Overwrite Overwrite	2		
configuration ite	ems below will be pr	reserved as default	during the restore	e configuration operat figuration Item SDR FRU SEL IPMI etwork NTP	ion.		Pre	Overwrite Overwrite Overwrite Overwrite Overwrite Overwrite Overwrite	2		
configuration its	ems below will be pr	reserved as default	during the restore	e configuration operat ifiguration Item SDR FRU SEL IPMI etwork NTP SSH	ion.		Pro	eserve Status - Overwrite Overwrite Overwrite Overwrite Overwrite Overwrite	۵ 		
configuration its	ems below will be p	reserved as default	during the restore Preserve Con 3 1	e configuration operat ifiguration Item SDR FRU SEL IPMI etwork NTP SSH KVM	ion.		Pre	Overwrite Overwrite Overwrite Overwrite Overwrite Overwrite Overwrite Overwrite	7		
configuration ite	ems below will be p	reserved as default	during the restore Preserve Con	e configuration operat Ifiguration Item SDR SDR FRU SEL IPMI etwork NTP SSH KVM entication	ion.		Pre	overwrite Overwrite Overwrite Overwrite Overwrite Overwrite Overwrite Overwrite Overwrite Overwrite	7		
Ul configuration its 1 2 3 4 5 6 7 8 9 10	ems below will be pr	reserved as default i	during the restore Preserve Con	configuration operation ifiguration (tem 2) SDR FRU SEL IPMI Etwork NTP SSH KVM entication yslog	ion.		Pre	eserve Status Overwrite Overwrite Overwrite Overwrite Overwrite Overwrite Overwrite Overwrite Overwrite	2		
Il configuration its 1 2 3 4 5 6 7 8 9 10	ems below will be pr	reserved as default	during the restore	e configuration operat figuration Item 3 SDR FRU SSL IPMI etwork NTP SSH KVM entication yslog	ion.		Pre	overwrite Overwrite Overwrite Overwrite Overwrite Overwrite Overwrite Overwrite Overwrite Overwrite	۵ 		

Note:

All configuration items below will be preserved as default during the restore configuration operation.

The various are listed below.

Preserve Configuration Item: The Preserve Configuration items will be listed.

Preserve Status: The status of the Preserve Configuration items.

Procedure

- 1. To proceed HPM Firmware Update, click **Continue**. The Firmware update undergoes the following steps:
 - a. Click Choose **File** to browse and select the Firmware image to flash and click **Ok**.



Note:

While creating HPM image with multiple components, Boot and App components should be placed at the end of the conf file.

- b. Preparing Device for Firmware Upgrade.
- c. Uploading Firmware Image.
- d. If flashing is required for all Components, select the option **Update All** to update all the Components or select any specific **Component Name** and click **Proceed** to update the Firmware. The list of components used to allow you to configure the Firmware image will be displayed as shown in the below screenshot.
- e. Flashing the image.
- f. Resetting the image. The sample screenshot of HPM Firmware update is as shown below.



Note:

You will not be able to perform any other tasks until firmware upgrade is completed and the device is rebooted. You can now follow the instructions presented in the subsequent pages to successfully update the card's firmware. The device will reset if update is canceled. The device will also reset upon successful completion of firmware update.

AMI

This wizard takes you through the process of AMI based firmware upgrade.

To process **AMI** Firmware Upgrade, select **AMI** option and click **Continue** to upgrade the current device firmware. The screenshot of AMI Firware Update is as shown below.

ashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmware Update				
Firmwa	re Update									
Upgrade firn	nware of the device.Pres	ss 'Enter Update Mo	ode' to put the devi	ce in update mode.						
The proto Protoco	col information to be use of Type : HTTP/HTTPs	ed for firmware ima	ge transfer during	this update is as folk	ws. To configure, o	choose 'Protocol Config	guration' une	der Firmware Update menu.		
WARNING: of the wizar	Please note that after e d, the device will be res	entering the update et.	mode, the widgets,	other web pages and	l services will not w	ork. All the open widge	ts will be au	utomatically closed. If the u	pgradation	is cancelled in the middle
Preserv All configura	e all Configuration. This tion items below will be p	will preserve all the preserved as defau	e configuration sett It during the restore	ings during the firmw configuration operat	are update - irrespe ion.Click " Enter Pr	ctive of the individual eserve Configuration "	items mark to modify	ed as preserve/overwrite in the Preserve status settings	the table b	elow.
#	4		Preserve Conf	iguration Item 🔺				Preserve Sta	tus ∆	
1			S	DR				Overwrite	2	
2			F	RU				Overwrite	2	
3			S	EL				Overwrite	2	
4			IF	MI				Overwrite	2	
5			Ner	twork				Overwrite		
6			N	TP				Overwrite	2	
7			S	SH				Overwrite	2	
8			K	VM				Overwrite	2	
9			Auther	tication				Overwrite	2	
10			Sy	slog				Overwrite	•	
						Upload Signima	e Kev	Enter Preserve Config	uration	Enter Update Mode

Note:

All configuration items below will be preserved as default during the restore configuration operation.

The various are listed below.

Preserve All Configurations: To preserve all the listed configurations.

Preserve Configuration Item: The Preserve Configuration items will be listed.

Preserve Status: The status of the Preserve Configuration items.

Enter Preserve Configuration: To redirect to the Preserve Configuration page.

Enter Update Mode: To upgrade the current device firmware.

WARNING:

Please note that after entering the update mode, the widgets, other web pages and servic-es will not work. All the open widgets will be automatically closed. If the upgradation is cancelled in the middle of the wizard, the device will be reset.

Procedure

Note:

To configure Protocol information, choose **Protocol Configuration** under Firmware Update menu. To configure Image to be booted from upon Reset, choose **Dual Image Configuration** under **Firmware Update** menu.

- 1. Check the option **Preserve All Configuration** to preserve all the listed configurations.
- 2. Click **Enter Preserve Configuration** to redirect to **Preserve Configuration** page, which is used to preserve the particular configuration not to be overwritten by the default configuration. The sample screenshot is shown below.

								 g
Dashboard	Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmware Up	date	HE

Preserve Configuration

This page allows you to select the specific configuration items to be preserved in the cases of "Restore Configuration", and "Firmware Update without Preserve Configuration option".

Click here to go to Firmware Update or Restore Configuration

Number of Preserved Items: 0

# △	Preserve Configuration Item Δ	Preserve Status
1	SDR	
2	FRU	
3	SEL	
4	IPMI	
5	Network	
6	NTP	
7	SSH	
8	KVM	
9	Authentication	
10	Syslog	
		Check All Uncheck All Save Reset

- 3. Select **Check All** to to select the configuration items to be preserved in the cases of "Restore Configuration", and "Firmware Update without Preserve Configuration option".
- 4. Click **Save** to preserve the Configuration Items.
- 5. Click **Enter Update Mode** to upgrade the current device firmware. The Firmware update undergoes the following steps:
 - a. Closing all active client requests
 - b. Preparing Device for Firmware Upgrade
 - c. Uploading Firmware Image

Note:

A file upload pop-up will be displayed for http/https but in the case of tftp files, the file is automatically uploaded displaying the status of upload.

d. Browse and select the Firmware image to flash and click **Upload**.

Upload Firmware		
Please select the firmware image	to flash	
	Browse_	
π.		Upload

e. Verifying Firmware Image

In Section Based Firmware Update, you can configure the firmware image for section based flashing. Check the required sections and click **Proceed** to update the firmware.

- If flashing is required for all images, select the option Full Flash.
- If you select **Version Compare Flash** option from web, the current and uploaded module versions, FMHlocation, size will be compared.
- If the modules differ in size and location, proceed with force firmware upgrade.
- If all the module versions are same, restart BMC by saying all the module versions are similar.
- If only few module versions are differ, those module will be flashed.

Note:

Only selected sections of the firmware will be updated. Other sections are skipped. Before starting flash operation, you are advised to verify the compatibility between image sections.

	y section is used to allo	w the user to configure the firr	nware image for section based	flashing.
	-	-	-	□ Version Compare Flash □ Full Flas
# ⊥	Section Name 🛆	Existing Version 🔺	Uploaded Version 🗅	Upgradable/Non-Upgradable
1	boot	1.4	1.4	
2	conf	1.4	1.4	
3	bkupcon	1.4	1.4	
4	root	1.4	1.4	
5	osimage	1.4	1.4	
6	www	1.4	1.4	
7	Imedia	1.4	1.4	
8	hornet	1.4	1.4	

- f. Flashing Firmware Image
- g. Resetting Device

Note:

You will not be able to perform any other tasks until firmware upgrade is complete and the device is rebooted. You can now follow the instructions presented in the subsequent pages to suc-cessfully update the card's firmware. The device will reset if update is canceled. The device will also reset upon successful completion of firmware update.

BIOS Update

This page allow user to update BIOS image, but only works when DC is off. Please note the filename extension of BIOS image shall be **.bin*. For example: BIOS3A22.bin. After BIOS update complete, system must perform AC cycle to take effect.

					admin(Administrator)	Refresh	P
Server Information	Server Health	Configuration	Remote Control	Maintenance	Firmware Update		
odate							
e note:							
wer Off the system whe	n you want to do Bl	OS update					
)S will become default a	fter BIOS flashed						
S NVRAM will be cleare	d and default Setup	Option will be load	led				
nter Update Mode							
	Server Information Odate e note: wer Off the system when DS will become default a DS NVRAM will be cleare	Server Information Server Health Odate e note: wer Off the system when you want to do BH OS will become default after BIOS flashed OS NVRAM will be cleared and default Setup inter Update Mode	Server Information Server Health Configuration Odate e note: wer Off the system when you want to do BIOS update OS will become default after BIOS flashed OS NVRAM will be cleared and default Setup Option will be load inter Update Mode	Server Information Server Health Configuration Remote Control Odate e note: wer Off the system when you want to do BIOS update OS will become default after BIOS flashed OS NVRAM will be cleared and default Setup Option will be loaded inter Update Mode	Server Information Server Health Configuration Remote Control Maintenance odate	Server Information Server Health Configuration Remote Control Maintenance Firmware Update odate e note: wer Off the system when you want to do BIOS update OS will become default after BIOS flashed OS NVRAM will be cleared and default Setup Option will be loaded inter Update Mode	admin(Administrator) Refresh Server Information Server Health Configuration Remote Control Maintenance Firmware Update odate Image: Server Off the system when you want to do BIOS update Image: Server Off the system when you want to do BIOS update Image: Server Off the system when you want to do BIOS update Image: Server Off the system when you want to do BIOS update Image: Server Off the system when you want to do BIOS update Image: Server Off the system when you want to do BIOS update Image: Server Off the system when you want to do BIOS update Image: Server Off the system when you want to do BIOS update Image: Server Off the system when you want to do BIOS update Image: Server Off the system when you want to do BIOS update Image: Server Off the system when you want to do BIOS update Image: Server Off the system when you want to do BIOS update Image: Server Off the system when you want to do BIOS update Image: Server Off the system when you want to do BIOS update Image: Server Off the system when you want to do BIOS update Image: Server Off the system when you want to do BIOS update Image: Server Off the system when you want to do BIOS update Image: Server Off the system when you want to do BIOS update Image: Server Off the system when you want to do BIOS update Image: Server Off the system when you want to do BIOS update Image: Server Off the system when you want to do BIOS update Image: Server Off the system when you want to do BIOS update Image: Server Off the system when you want to

Figure 3-56. BIOS Update Page

Log Out

To log out of the MegaRAC GUI, click the logout link on the top right corner of the screen.

User Privilege

Below table describes user privilege definition and the main different features.

Table 39: User Privilege Definition

User Privilege	DEFINITION
Administrator	All Web-UI functions are allowed.
Operator	Only allow to view all Web-UI functions.
OEM	Only allow to view all Web-UI functions. But Users, DNS, Network and PEF are not allowed to be viewed.
User/Callback	Support for ipmitool, not for Web-UI.

Note:

Command privilege level table defined in IPMI 2.0 Specification Appendix G – Command Assignments. According to IPMI 2.0 Specification, **Chassis Iden-tify** command is allowed for Operator privilege. Because this command didn't

change BMC configuration, just to trigger Identify LED used to display where Server is. So it is expected behavior. After checked other Operator privilege command by IPMI 2.0 Specification, **Chassis Control command** (Power On/ Off) is also allowed. But in our code base, we raise **Chassis Control** command to be Administrator to protect system. So, in **Server Power Control** page, only Administrator can control server power.

|--|

	PRIVILEGE ASSOCIATION BETWEEN IPMI AND WEB GUI			
WEB GUI PRIVILEGE LIST	Administrator	Operator	USER/ CALLBACK	OEM
login BMC from Web GUI	0	0	Х	0
configure BMC from Web GUI	0	Х	Х	Х
configure users from Web GUI	0	Х	Х	Х
clear logs from Web GUI	0	Х	Х	Х
execute server power control from Web GUI	0	Х	Х	Х
virtual KVM redirection	0	Х	Х	Х
virtual media	0	Х	Х	Х
View Users	0	0	Х	Х
View DNS	0	0	Х	Х
View Network	0	0	Х	Х
View PEF	0	0	Х	Х

Login BMC through SSH

- ID: sysadmin, Password: superuser
- Web Account can't login SSH
- SMASH

If supported SMASH then to login SSH will go to SMASH.

If NOT Support SMASH then to login SSH will go to BMC console.

Regulatory and Compliance Information

Chapter 4

This section provides regulatory and compliance information applicable to this system.

4.1 Electromagnetic Compatibility Notices

FCC Verification Statement (USA)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Europe (CE Declaration of Conformity)

This product has been tested in accordance too, and complies with the Low voltage Directive (2006/95/EC) and EMC Directive (2004/108/EC). The product has been marked with the CE Mark to illustrate its compliance.

VCCI (Japan)

この裝置は、クラスA情報技術裝置です。この裝置を家庭環境で使用すると電波妨害を引き起こす ことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。 VCCI-A

English translation of the notice above:

This is a Class A product based on the standard of the Voluntary Control Council for Interference (VCCI) from Information Technology Equipment. If this is used near a radio or television receiver in a domestic environment, it may cause radio interference. Install and use the equipment according to the instruction guide.

BSMI (Taiwan)

The BSMI Certification Marking and EMC warning is located on the outside rear area of the product

警告使用者:

此為甲類資訊技術設備,於居住環境中使用時,可能會造成射頻擾動,在此種情況下,使用者會被要 求採取某些適當的對策。

Regulated Specified Components

To maintain the UL listing and compliance to other regulatory certifications and/or declarations, the following regulated components must be used and conditions adhered to. Interchanging or use of other component will void the UL listing and other product certifications and approvals.

Updated product information for configurations can be found on the site at the following URL: http://www.QCT.io

If you do not have access to the Web address, please contact your local representative.

- Add-in cards: must have a printed wiring board flammability rating of minimum UL94V-1. Add-in cards containing external power connectors and/or lithium batteries must be UL recognized or UL listed. Any add-in card containing modem telecommunication circuitry must be UL listed. In addition, the modem must have the appropriate telecommunications, safety, and EMC approvals for the region in which it is sold.
- Peripheral Storage Devices: must be UL recognized or UL listed accessory and TUV or VDE licensed. Maximum power rating of any one device is 19 watts. Total server configuration is not to exceed the maximum loading conditions of the power supply.

Restriction of Hazardous Substances (RoHS) Compliance

Quanta Computer Inc. has a system in place to restrict the use of banned substances in accordance with the European Directive 2011/65/EU. Compliance is based on declaration that materials banned in the RoHS Directive are either (1) below all applicable threshold limits or (2) an approved / pending RoHS exemption applies.

RoHS implementation details are not fully defined and may change.

Threshold limits and banned substances are noted below:

- Quantity limit of 0.1% by mass (1000 PPM) for:
 - Lead
 - Mercury
 - Hexavalent Chromium
 - Polybrominated Biphenyls Diphenyl Ethers (PBDE)
- Quantity limit of 0.01% by mass (100 PPM) for:
 - Cadmium

End of Life / Product Recycling

Product recycling and end-of-life take-back systems and requirements vary by country. Contact the retailer or distributor of this product for information about product recycling and / or take-back.

4.2 Product Regulatory Compliance Markings

This product is marked with the following product certification markings:

Table 1: Product Regulatory Compliance Markings

REGULATORY COMPLIANCE	Region	Marking
cULus Listing Mark	USA / Canada	
CE Mark	Europe	CE
FCC Marking (Class A)	USA	This device complies with Part 15 of the FCC Rules. Operation of this device is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, includ- ing interference that may cause undesired operation.
VCCI Marking (Class A)	Japan	この裝置は、クラスA情報技術裝置です。この裝置を家 庭環境で使用すると電波妨害を引き起こすことがありま す。この場合には使用者が適切な対策を講ずるよう要求 されることがあります。 VCCI-A
BSMI Certification & Class A Warning	Taiwan	警告使用者: 此為甲類資訊技術設備,於居住環境中使用 時,可能會造成射頻擾動,在此種情況下, 使用者會被要求採取某些適當的對策。
ICES	Canada	CAN ICES-3(A)/NMB-3(A)
Recycling Package Mark	Other than China	Corrugated Recycles CFB
EAC Marking	Russia	EAC